

Dolphin[®] Power Tools

With Windows Mobile[®] 6.X for the:

Dolphin 7600 Mobile Computer - 6.0

Dolphin 9900 Mobile Computer - 6.1

Dolphin 9700 Mobile Computer - 6.5

User's Guide



Disclaimer

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

© 2007-2009 Honeywell International Inc. All rights reserved.

Other product names or marks mentioned in this document may be trademarks or registered trademarks of other companies and are the property of their respective owners.

Web Address: www.honeywellaidc.com





Table of Contents

Chapter 1 - Accessing and Upgrading Power Tools

Dolphin Power Tools Overview	1-1
Software Requirements	1-2
Power Tools Main Window	1-2
Additional Dolphin Power Tools	1-4
Upgrading Power Tools	1-5

Chapter 2 - EZConfig

Upgrades	2-1
EZConfig Editor.....	2-2
Installing EZConfig on the Workstation	2-2
Sample EXM Files.....	2-2
Opening EZConfig Editor on the Workstation	2-3
Menu and Toolbar Options	2-3
File Menu	2-3
Working with Open EXM Files	2-7
Working with Sections.....	2-7
Working with Keys.....	2-12
Creating New Configuration Documents.....	2-15
Associating Applications	2-16
Registry Documents.....	2-17
Processing Registry Documents on the Terminal	2-19
Creating Bar Codes	2-21
Converting Known INI and MNU Files	2-28
EZConfig Editor on the Terminal.....	2-30
Editing Sections	2-31
Editing Keys	2-32
Launching Associated Applications.....	2-33
EZConfig Client.....	2-34
Using EZConfig Client.....	2-34
EZConfig Client Window	2-36
Command Line Arguments	2-37

Chapter 3 - DeviceConfig

DeviceConfig.exm File	3-1
Settings in the WLAN Supplicant	3-1
DeviceConfig.exm Sections and Keys	3-2
Connections Section	3-2
Radio Manager Section.....	3-2
System Section	3-9
Applications Section.....	3-10
Launching DeviceConfig.exe Manually	3-13
Temporary Option for Bar Code Deployment	3-13

Chapter 4 - Autorun and AutoInstall

Autorun	4-1
Autorun.exm File.....	4-1
Start Options.....	4-4
AutoInstall.....	4-8
Program Install Locations	4-8
AutoInstall.exm	4-9
Command Line Arguments.....	4-10

Chapter 5 - ScanWedge

Enabling ScanWedge	5-1
ScanWedge.exm Sections	5-2
Settings Section.....	5-3
Comm Section	5-6
Decode Section	5-8
Centering Section	5-11
Formatting Section.....	5-12
Symbolologies Section	5-17
VK (Virtual Key) Mapping Section	5-20
Virtual Key Codes Table.....	5-21
Command Line Arguments.....	5-26

Chapter 6 - Additional Power Tools

BattMon	6-2
InstallerCE	6-4
HotKeys	6-5
Keyboard Status	6-7
NoSIP	6-9
RASMan	6-10
Reboot	6-13
Suspend	6-14
SysInfo.....	6-15
Sample SysInfo File.....	6-17

Chapter 7 - Using the Battery Analyzer

Requirements	7-1
Recommendation.....	7-1
Analyzing a Battery.....	7-2
Stopping an Analyze Cycle.....	7-2
Command Line Arguments.....	7-3
Advanced Mode.....	7-3

Chapter 8 - Registry Power Tools

Editing the Registry	8-1
Menus.....	8-3
File Menu	8-3
Edit Menu.....	8-3
View Menu	8-4
Importing Registry Files.....	8-5

Exporting Specific Registry Settings.....	8-5
Other Export Options.....	8-5
Backing Up the Registry.....	8-6
Restoring the Registry.....	8-6
RegBackup.exe.....	8-7
Command Line Arguments.....	8-9
Registry Edit Options in EZConfig.....	8-10

Chapter 9 - Network Utilities

Accessing Network Utilities.....	9-1
IP Config.....	9-2
Ping.....	9-4
Route.....	9-6
WiFi Status.....	9-10
Backup Radio Settings.....	9-12
Restore Radio Settings.....	9-12

Chapter 10 - EZMenu

Overview.....	10-1
Running Easy Menu.....	10-1
Default EZMenu Configuration Files.....	10-1
Sample Menu Configuration Files.....	10-1
Modifying Menu Configuration Files.....	10-2
Creating Menu Configuration Files.....	10-2
Menu Configuration File Sections.....	10-3
Settings Section.....	10-3
MenuEntries Subsections.....	10-4
Start Options.....	10-6
Locking Down the Application Window.....	10-10
Booting the Terminal to the Application Window.....	10-10

Chapter 11 - SetRAM

Accessing SetRAM.....	11-2
RAM Memory Allocation in DeviceConfig.....	11-2
SetRAM Window.....	11-2
RAM Memory Restrictions.....	11-3

Chapter 12 - Print Power Tools

Print Demo.....	12-1
BTPrint.....	12-2
IrDAPrintCE.....	12-2

Chapter 13 - Customer Support

Technical Assistance.....	13-1
Online Technical Assistance.....	13-1



Accessing and Upgrading Power Tools

Dolphin Power Tools Overview

Note: Screen captures/icons in this user's guide may differ from what appears on your device.

Dolphin Power Tools are installed in every Dolphin terminal. Different versions of Power Tools apply to different Dolphin terminals depending on their model or operating system.

Power Tool	Windows Mobile 5/6/ 6.1/6.5	Windows Mobile 2003 Second Edition	Windows CE 5.0
	6.0: 7600 (GSM) 6.1: 9900 6.5: 9700 5.0: 7850/7900/9500	7900/9500	7600
AutoInstall	•	•	•
Autorun	•	•	•
Battery Analyzer (only on the 9700/9900)	•		
BattMon	•	•	•
DeviceConfig	•	•	•
EZConfig Editor	•	•	•
EZConfig Client	•	•	•
EZMenu	•	•	•
HotKeys	•	•	
Keyboard Status	•	•	•
Network Utilities:			
IPConfig	•	•	•
Ping	•	•	•
Route	•	•	•
WiFi Status	•		
Backup Radio Settings	•		
Restore Radio Settings	•		
NoSIP	•	•	
RASMan	•	•	
Reboot	•	•	•
RegBackup	•	•	•
RegEdit	•	•	•
RegRestore	•	•	•
ScanWedge	•	•	•

Power Tool	Windows Mobile 5/6/ 6.1/6.5	Windows Mobile 2003 Second Edition	Windows CE 5.0
SetRAM	•		
Suspend	•	•	•
SysInfo	•	•	•

Software Requirements

Dolphin Terminals

Dolphin Power Tools are designed to work with Windows Mobile® 6


Desktop



The Power Tools installer and the workstation version of EZConfig Editor are designed to work with the following operating systems:














- Microsoft® Windows® XP
- Microsoft® Windows® 2000
- Microsoft® Windows® NT
- Microsoft® Windows® Vista
- Microsoft® .NET Framework 2.0
- Microsoft® ActiveSync® (version 4.5 or higher)

Power Tools Main Window

Tap **Start > Power Tools** and the Power Tools main window opens displaying the main Power Tools.



Icon	Name	Description	Page
 BattMon	BattMon	Programs the LEDs on the top panel to monitor battery power.	6-2
 EZConfig Utilities	EZConfig Utilities	Opens a window that displays the EZConfig utilities on the terminal. <ul style="list-style-type: none"> • EZConfig Editor on the Terminal (see page 2-30) • EZConfig Client (see page 2-34) 	2-1

Icon	Name	Description	Page
 HotKeys	HotKeys	Activates button assignments in the Buttons setting.	6-5
 Keyboard Status	Keyboard Status	Puts an icon on the Navigation bar that indicates the alpha-numeric status of the keyboard.	6-7
 NoSIP	NoSIP	Turns off the Soft Input Panel (SIP) in every application window.	6-9
 Network Utilities	Network Utilities	Opens a window that displays the Network utilities: <ul style="list-style-type: none"> • IP Config (see page 9-2) • Ping (see page 9-4) • Route (see page 9-6) • WiFi Status (see page 9-10) • Backup Radio Settings (see page 9-12) • Restore Radio Settings (see page 9-12) 	9-1
 RASMan	RASMan	Establishes a remote access service (RAS) connection.	6-10
 Reboot	Reboot	Performs a warm or cold boot from the touch screen, as opposed to the keyboard commands.	6-13
 RegBackup	RegBackup	Backs up the registry.	8-6
 RegEdit	RegEdit	Allows you to edit the registry and import and export registry keys.	8-1
 RegRestore	RegRestore	Loads the RegBackup file.	8-6
 ScanWedge	ScanWedge	Enables the Dolphin terminal to interpret as keystrokes data received via the decoder, serial port, or IrDA interface.	5-1
 SetRAM	SetRAM	Allows you to re-set the memory allocation.	11-1
 Suspend	Suspend	Manually puts the terminal into Suspend mode from the touch screen, as opposed to the keyboard commands or time-out settings.	6-14
 SysInfo	SysInfo	Displays system information.	6-15

Exiting the Power Tools Main Window




Exit .

- Scroll down and tap the **Exit** icon .
- Tap **File > Exit (ESC)**.
- Press ESC on the keyboard.

View Options

The View menu changes the organization of the Power Tools main window and is located at the bottom of the screen. A checkmark appears next to the selected view.



This menu enables you to choose between:

- Small Icon View
- Large Icon View (Default view)
- List View
- Detail View (This view displays a description of the Power Tool in a column to the right of the name.)

Additional Dolphin Power Tools

These Power Tools are in the Dolphin terminal but do not appear on the Power Tools main window.

Name	Function	Storage Location	Access Location	Page
AutoInstall	Installs CAB files after a hard reset.	\IPSM	\IPSM\AutoInstall	4-8
AutoRun	Programs which applications launch at startup.	\IPSM	\IPSM	4-1
BTPrint	Prints to a Bluetooth device.	\Program Files\Power Tools	\Program Files\Power Tools	12-2
DeviceConfig	Configures the terminal	\IPSM	\IPSM	3-1
EZMenu	Programs custom application windows.	\Program Files\Power Tools	\IPSM	10-1
InstallerCE	Stores CAB files after they install instead of deleting them.	\Program Files\Power Tools	You do not launch InstallerCE.	4-1
IrDAPrintCE	Prints to an IrDA device.	\Program Files\Power Tools	\Program Files\Power Tools	12-2

Upgrading Power Tools

Dolphin Power Tools come loaded in every Dolphin terminal and are included in system upgrades.

Acquiring Upgrades


Upgrades are available from [Customer Support](#) (see page 13-1) or www.honeywell.com/aidc.

Installing an Upgrade to the Workstation


Power Tools upgrades come in the form of an upgrade executable that installs upgrade files to the workstation. Transfer the appropriate upgrade files to the Dolphin terminal.

Requirements: An active Microsoft ActiveSync connection between a host workstation and the Dolphin terminal.


1. Download the new **Honeywell Power Tools and Demos for WM 6.0 Setup.exe** to the Program Files folder on the workstation.
2. Click the **Honeywell Power Tools and Demos for WM 6.0 Setup.exe** to install.




3. Click **Next**. If you accept the terms of the license agreement, select **I accept the terms...**




4. Click **Next**.




5. Accept or change the installation location then click **Next**.



-
6. Click **Install** and the programs begin installing.




7. The following screen appears when the programs have finished installing:



8. Click **Finish**.

Folder on the Workstation

After installation on the workstation is complete, the upgrade files are stored on the workstation at **C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0**.




Note: If a Honeywell folder does not already exist in the Program Files folder, the installation creates one.

- | | |
|---------------------------|--|
| Device Image | A ghost image of the IPSM upgrade. The contents of this folder should replace the contents of the \IPSM folder on the Dolphin terminal. |
| Docs | User guides for Demos and Power Tools (including this guide). |
| EZConfig EXM Files | Sample EXM files. These files contain the default configuration settings for Dolphin terminals with Windows Mobile 6. |

Installing an Upgrade on the Terminal

1. Using the appropriate Dolphin communication peripheral for your series, connect the Dolphin terminal to the workstation and ensure that the ActiveSync connection is running.
2. On the workstation, open Windows Explorer and navigate to the **\IPSM** folder on the Dolphin terminal.
3. Back up the terminal's **\IPSM** folder by copying and pasting its contents to the workstation.
4. Then, on the terminal, delete the entire contents of the **\IPSM** folder.
5. On the workstation, navigate to the **C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\Device Image**.
6. Copy all items (including the AutoInstall folder).



7. Navigate to the **\IPSM** folder on the Dolphin terminal and paste.
8. Copy and paste all custom CABs (radio drivers, applications, programs, etc.) to the **\IPSM** folder.
 - a. If you have custom EXM files with settings you want to keep and you want to have the upgrades in the new EXM files, merge those EXM files with the new EXM files instead of replacing them.
 - b. Then, paste the merged EXM files to the Dolphin terminal.

-
9. When all the files are pasted, cold boot the terminal.
 10. The Power Tools upgrade installs during startup.



Overview

EZConfig is a suite of products that configures Dolphin terminals quickly and efficiently. With the tools in the EZConfig suite, you can package data on the workstation, then deploy and unpackage that data on the Dolphin terminal.

Components

There are two main components to EZConfig: EZConfig Editor and EZConfig Client.

EZConfig Editor

Edits and creates configuration and registry documents in the EXM file format for Dolphin terminals. There are two versions of EZConfig Editor: one for the terminal and one for the workstation.

For details about the workstation editor, see [EZConfig Editor](#) on page 2-2.

For details about the terminal editor, see [EZConfig Editor on the Terminal](#) on page 2-30.

Capabilities

Both editors:

- Create and modify EXM files—[Working with Open EXM Files](#) (see page 2-7)
- Convert INI files to EXM files—[Converting Known INI and MNU Files](#) (see page 2-28)

In addition, EZConfig Editor on the workstation

- Generates bar codes from EXM files—[Creating Bar Codes](#) (see page 2-21)

EZConfig Client

Decodes the bar codes generated by EZConfig Editor on the workstation. For details, see [EZConfig Client](#) on page 2-34.

Upgrades

EZConfig Editor on the workstation must be installed on the workstation separately from the Power Tools upgrade. Obtain the **Honeywell EZConfig Editor Setup rXX.exe** from [Customer Support](#) (see page 13-1) or www.honeywellaidc.com and install it on your workstation.

All components on the terminal—the EZConfig Editor and the EZConfig Client—are installed during Power Tools and Demos upgrades. For more information, see [Upgrading Power Tools](#) on page 1-5.

EZConfig Editor

EZConfig Editor creates, edits, and manages EXM files for Dolphin terminals. There is an EZConfig Editor on the workstation and an EZConfig Editor on the terminal. In the workstation editor, EXM files are edited, saved, then transferred to the terminal. In the terminal editor, EXM files are edited and saved right on the terminal; see [EZConfig Editor on the Terminal](#) (page 2-30).

EXM Files

The EXM file format is an XML format customized for Dolphin terminals that are comprised of sections that sometimes contain child sections and keys. Keys contain the values that configure the terminal.

The EXM file format supports a multi-level, hierarchical, tree structure. The terminal reads the highest level section first and then reads the key values in each section.

EXM files replace INI files for Power Tools and terminal configuration settings. If both an INI file and an EXM file are present for the same application, the terminal defaults to the EXM file and a warning message appears at startup. Remove the INI file from the terminal to avoid this warning message.

Types of Configuration Files

There are two types of configuration files in the EXM file format:

Configuration Documents Program and configure the terminal; see [Opening EXM Files](#) on page 2-6.


Registry Documents Update and modify the registry; see [Registry Documents](#) on page 2-17.

Installing EZConfig on the Workstation

EZConfig Editor on the terminal installs automatically as part of the Power Tools CAB file. You must install EZConfig Editor on the workstation separately.


1. Obtain the **Honeywell EZConfig Editor Setup.exe** and save it to the workstation.
2. Double-tap this EXE and follow the installation guide.
3. When installation is complete, a **C:\Program Files\Honeywell\EZConfig Editor** folder is

created and an EZConfig icon appears on the Desktop



Sample EXM Files

After you install the new build on the workstation, default EXM files are stored in the **C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\EZConfig EXM Files** folder.




Use these files as templates to create new EXM files.

Opening EZConfig Editor on the Workstation

After you complete installation, EZConfig Editor is available on the workstation from the Start menu.



Click **Start > Programs > Honeywell > EZConfig Editor > EZConfig Editor**.






Menu and Toolbar Options

The menu and toolbar at the top of the window contains many options.

File Menu

Menu Item	Description
New 	Creates a new document. There are two options: <ul style="list-style-type: none">• Configuration Document - Creates a configuration file; Creating New Configuration Documents (page 2-15).• Registry Document - Creates a registry file in the EXM file format; Registry Documents (page 2-17).
Open 	Opens an EXM file located on the workstation.
Open from Device	Opens an EXM file located on the terminal. The location of the file appears in the title bar with the word "[Remote]" to identify that the open file is located on the terminal. <i>Note: Requires an ActiveSync connection between the workstation and the terminal.</i>

File Menu



Menu Item	Description
Save 	Saves the open file to the location you select on the workstation. This option is disabled for new and imported files; use Save As instead.
Save As	Saves the open file with a new name to the location you select on the workstation.
Save to Device As	Saves an open file to the terminal; see Saving to the Device on page 2-14. <i>Note: Requires an ActiveSync connection between the workstation and the terminal.</i>
Properties 	Associates the EXM file with an application on the terminal; see Associating Applications on page 2-16.
Create EZConfig Bar Code 	Embeds the open EXM file in an Aztec bar code; see Generating Bar Codes on page 2-22.
Exit	Closes EZConfig Editor.

Edit Menu

For Section Edit menu options, see [Working with Sections](#) on page 2-7.

For Key Edit menu options, see [Working with Keys](#) on page 2-12.

View Menu

Menu Item	Description
View Locks 	<p>Displays an icon over locked sections. For example,</p>  <p>The key icon means that the section's keys are locked. The lock icon means the section's subsections are locked.</p> <p>Information about locks on subsections and keys also appears in the Status Bar (see page 2-7).</p>

Tools Menu

Menu Item	Description
Simplify Document <i>Note: You cannot undo this action!</i>	<p>Simplifies the EXM file, which makes it smaller. Simplifying permanently removes</p> <ul style="list-style-type: none">• Disabled sections and keys• Descriptions• Bar code settings <p>When you create a bar code, you can simplify the file embedded in the bar code without affecting the open EXM file. This reduces the size of the bar code package yet keeps the disabled sections, descriptions, and bar code settings in the open EXM file for future reference. See Simplified (page 2-23) on the Advanced Tab (see page 2-24).</p>
Because the following menu items execute commands on the terminal, there must be an ActiveSync connection between the workstation and the terminal.	
Launch Associated Application	<p>If the open EXM file is associated with an application on the terminal, this item is active and launches the associated application on the terminal. <i>Note: You would use this option after saving the EXM file to the terminal; see Save to Device As on page 2-4.</i></p>
*Warm Boot	Warm boots the terminal.
*Cold Boot	Cold boots the terminal.
*Some settings affect the boot process and these menu items can help you run a test without switching to the terminal.	
Upgrade Remote INI Files	Launches the tool that converts existing INI files stored on a device to the EXM file format. For more details, see Converting Known INI and MNU Files on page 2-28.

Opening EXM Files

EZConfig Editor opens EXM files stored on the workstation or the terminal (if an ActiveSync connection is established).

Opening EXM Files on the Workstation

Click **File > Open** or the **Open** toolbar button  and select the EXM file.

When you select a known MNU or INI file, EZConfig Editor prompts you to convert the file. When you select **Yes**, EZConfig Editor imports the file and converts it to the EXM file format. Then, you can click **File > Save As** to save the file with the EXM extension.

You cannot save known INI or MNU files in their original format. For a list of known files, see [Known INI and MNU Files](#) on page 2-28.


The preferred conversion method is to use the batch conversion tool and then make your edits to the new EXM files. For details, see [Converting Known INI and MNU Files](#) on page 2-28.

Opening Remote EXM Files

The workstation and the terminal must be connected via ActiveSync!

EZConfig Editor can open EXM files located on the terminal so that you can make edits to the terminal's configuration real-time.

When the terminal and workstation are connected by ActiveSync, click **File > Open From Device** and the remote open window opens.




To open, double-tap on a file or select it and click **OK**.

Note: You can also open EXM files in the editor on the terminal; see [EZConfig Editor on the Terminal](#) (page 2-30).

Working with Open EXM Files


Whether you open an EXM or INI file, EZConfig Editor displays the content in four different sections of the window.



Status Bar


The Status Bar appears at the bottom of the window and displays information about selected sections and keys.

Selected Section



See [Section Locks](#) on page 2-10.

Selected Key



See [Key Types](#) on page 2-14.


Working with Sections



The EXM file format supports a multi-level tree structure. The section tree appears in the top left quadrant of the window. The root node identifies the EXM file and "Root" appears in the description.

Sections have a Name and Description and contain keys that appear in the upper right quadrant when you select the section name. Select a section by clicking on it. You can select only one section at a time.

Edit Menu Options

Select a section click **Edit** to see the available options.



Menu Item	Description
Rename	Activates the section name so that you can rename the section. <i>Note: You cannot modify the name if the section is locked; see Section Locks (page 2-10).</i>
Cut	Cuts a selected section.
Copy	Copies a selected section.
Paste	Pastes the section that was just cut or copied at the same level as the selected section.
Paste as Child	Pastes the section that was just cut or copied as a child of the selected section. <i>Note: You can cut, copy and paste sections within an EXM file or across EXM files.</i>
Delete	Deletes a selected section. <i>Note: Because you cannot undo a delete, consider disabling rather than deleting.</i>
Enable	Sections are enabled by default. This menu item enables sections that were previously disabled. You can enable a section only if its parent section is enabled. To enable all the keys inside a section you are enabling, SHIFT + right-click and select Enable All .
Disable All	Sections are enabled by default. This menu item disables sections and all of its keys. Disabled sections remain in the file with a gray folder  .  If you disable a section that has child sections, all of its child sections (and the child section keys) are disabled automatically. The child section folders are also in gray. When reading the EXM file, the terminal behaves as though disabled sections are not there and moves on to read the next enabled section. Disabled sections can be removed from the EXM file permanently using the Simplify Document (see page 2-5) option. If you want to keep disabled sections in the EXM file on the workstation but not in the file deployed to the terminal, use the Simplified option (see page 2-23) when creating the bar code.

Menu Item	Description
Insert Section	This menu item inserts a new section. You can also press the Insert key (INS).
Append Child Section	This menu item adds a new child section to a selected section. The new child section is inserted below the previous section.

Modifying Section Names

To change a section name, double-click on the folder and type in the new name or select **Rename** on the Edit menu. Type in the new name and press ENTER.

Note: You cannot modify the name if the section is locked or disabled; see [Section Locks](#) (page 2-10).

Modifying Section Descriptions

Descriptions are not required to process key values but do help document the EXM file and often contain valuable information. If you want to modify a section description, select the section, click inside the section description, and begin typing. You cannot modify descriptions of locked sections.

Moving Sections

To move sections within an EXM file, use the drag and drop method. By default, sections are dropped at the same level in the tree.

For additional functionality when dragging and dropping, press and hold:

- ALT to drop a section as a child section.
- CTRL to copy a section and drop the copy at the same level in the tree.
- CTRL + ALT to copy a section and drop the copy as a child section.




Note: You can select only one section at a time; you cannot use SHIFT+Click or CTRL+Click to select more than one section.

To move sections between EXM files, open **two instances** of EZConfig Editor and drag and drop sections between them. When dragging, a copy of the section is dragged to the new file. When dropping, drop the section directly on top of the section you want it to be a child section of.

Note: To drop the first section into a new file, press and hold the ALT key and drop the section on the root node. (All sections must be child sections of the root node.)

Section Locks

There are different types of locks on sections. The status bar indicates what type of lock is applied to a selected section.




Lock Type	Status Bar Indicator	Description	Effect
Name Lock		The section name is locked.	<ul style="list-style-type: none"> Section Name and Description cannot be modified.
Key Lock		All keys are locked.	<ul style="list-style-type: none"> Key Names and Descriptions cannot be modified. Keys cannot be added, moved, or deleted within the section.
Subsection Lock		All immediate subsections are locked.	<ul style="list-style-type: none"> Immediate subsection Names and Descriptions cannot be modified. Immediate subsections cannot be added, moved, or deleted.

Note: All locks are applied to each individual section and are not recursive. Only text that appears in blue can be modified.


Section-Level Merge Modes

EXM files ship with section-level merge modes already defined according to section content. Merge modes determine how section information is handled when an updated EXM file is deployed to the terminal where an existing version of that EXM file is stored.

Merge modes are indicated by folder icons and in the Status bar.

Mode	Description	Merge Effect
 Delete + Add	Deletes non-common children elements (i.e., subsections, and keys) in the target file, then adds the new information from the bar code. Basically, the new section replaces the old section. This is the default merge mode for new sections.	Exclusive
 Disable + Add	Disables non-common children elements (i.e., subsections, and keys) in the target file, then adds the new information from the bar code. <i>Note: Disabled sections and keys removed from the simplified bar code end up as disabled in the target file.</i>	
 Add Only	Adds new information (sections and keys) to the existing section. If this is a brand new section, the new section is added to the existing EXM file. <i>Note: Disabled sections removed from the simplified bar code are not modified in the target file.</i>	Inclusive

To change section-level merge modes, select a section and right click.




The folder colors change immediately after selection.

Working with Keys


Keys have a Name, a Description, and a Value and reside inside sections. For specific key values, consult the chapters of this user's guide that describe the EXM file you're attempting to edit.

Edit Menu Options

Select a key and right-click or click **Edit** to see the available options.



Menu Item	Description
Rename	Activates the key name so that you can rename the key. Rename is disabled if the key is locked or disabled; see Key Types (page 2-14).
Cut	Cuts a selected key.
Copy	Copies a selected key.
Paste	Disabled; keys can be pasted only as children of a section.
Paste as Child	Pastes the key just cut or copied in the selected section. Keys are not multi-level; all keys paste at the same level within a section. You can cut, copy and paste keys within an EXM file or across EXM files.
Delete	Deletes a selected key. You cannot undo a delete; you might want to consider disabling rather than deleting.
Enable	Enables keys that were disabled. When a key is enabled, the client application can read and apply its value. When you enable a key, make sure to specify a value for that key; do not leave it blank. To enable a key, its parent section must be enabled.

Menu Item	Description
Disable	<p>Disables keys. Disabled keys have key values in black. Enabled keys have key values in blue.</p>  <p>The terminal does not read disabled keys and disabled keys are removed if the file is simplified; see Simplify Document (page 2-5).</p> <p>Because many key values are 1 for enable and 0 for disable, remember that disabling a key means that the terminal behaves as if the key is not there when reading the file, NOT that the key's value is set to disabled. The terminal simply moves on to read the next enabled key.</p>
Insert New Key	<p>This menu item inserts a new key above the selected key. <i>Note: You can also press the Insert key (INS).</i></p>

Modifying Key Names

To modify key names, double-click on the key name or select **Rename** on the Edit menu. Type in the new name and press ENTER or TAB.

Note: You cannot modify the description if the key is locked; see [Key Types](#) (page 2-14). Only text that appears in blue can be modified.

Modifying Key Values

You can modify a key value only if its text appears in blue. In that case, double-click on the value or select the key and press ENTER. Type in the new value and press ENTER or TAB to save.

Modifying Key Descriptions

Descriptions are not required to process key values but do help document the EXM file and often contain valuable information. To modify a key's description, click on the key, then click in the key description area. When the cursor is active, you can type in the text.

Note: You cannot modify the description if the key is locked; see [Key Types](#) (page 2-14).

Moving Keys





To move keys within an EXM file, use the drag and drop method. Press and hold the CTRL key to drag and drop a copy of the key to the new location.

Note: You cannot move a key if it is locked by its section.

To move keys between EXM files, open **two instances** of EZConfig Editor and drag and drop keys between them. When you select the key and drag, a copy of the key is dragged to the new file. In the new file, drop the key in the key area of a selected section; keys are always dropped at the same level within a section.

Key Types


When a key is selected, its properties display in the Status bar.

Lock Type	Status Bar Indicator	Description	Effect
Name Lock		Keys are locked by the section.	<ul style="list-style-type: none">• Name and Description cannot be modified.• Keys cannot be added, moved, or deleted within the section.
		The key name is locked individually.	<ul style="list-style-type: none">• Name and Description cannot be modified.• These keys can be moved.
Read Only		Read-only keys cannot be modified in any way. They appear in red.	<ul style="list-style-type: none">• Name, Description, and Value cannot be modified.• Keys cannot be added, moved, or deleted within the section.
Encrypted		Key's value appears as asterisks (*) for added security.	<i>Note: Encrypted keys are also stored encrypted in the EXM file. If you open the EXM file in a text editor, you won't see the data as clear text.</i>

Note: Locked and Read Only properties are not recursive. Properties are applied to each individual key. Only text that appears in blue can be modified.

Saving to the Device

You can save EXM files directly to the terminal when there is an ActiveSync connection between the terminal and the workstation. Select **File > Save to the Device As** and the Save Remote File window opens.




Select the location on the terminal where you want to store the file and click **OK**. The file is downloaded directly to the terminal via ActiveSync.

Note: EXM files for Power Tools must be stored in the \IPSM folder.

Creating New Configuration Documents

To create new EXM files that are configuration documents, you can open an existing EXM file and save it with a new name or create an EXM file from scratch.

1. Click **File > New > Configuration Document**. The root node is created and appears as the top level section. All sections must be at least one level down from the root node. The name of the root node is always the same as the filename.



Note: You can also create registry documents in the EXM file format. For details, see [Registry Documents](#) on page 2-17.


2. To create the first subsection, select the root node, right-click, and select **Append Child Section**. Insert Section is disabled because you cannot insert sections at the same level as the root node.
3. Enter a **Name** and a **Description** and click **OK**. The name is required, the description is optional.
4. To add a new section at the same level, right-click and select **Insert Section**. To add a new section one level down, right-click and select **Append Child Section**.
5. To add keys, select a section, right-click in the key value section, and select **Append Key**.
6. Enter the **Name**, **Value**, and **Description** and click **OK**. The name is required, the description is optional.
7. Continue adding sections and keys.
8. If necessary, associate this EXM file with an application; see [Associating Applications](#) (page 2-16).
9. Click **File > Save As** to save the file. Save is disabled so that you save the document with a name other than "NewDocument.exm."

Associating Applications

The Properties function associates an EXM file with an application on the terminal. The associated application launches after EZConfig Client decodes the bar code containing the EXM file.

For more information, see [Creating Bar Codes](#) on page 2-21.

While the EXM file is open, click **File > Properties** or the **Document Properties** toolbar button .



Field	Description
Path	Enter the location of the EXE on the terminal.
Arguments	<p>Enter the command line argument you want applied when the application launches. When an application is entered in the Path field, the following command line appears as the argument: /exm %filename.</p> <p>Enter additional command line arguments (see Command Line Arguments on page 2-37) next to /exm %filename in this field.</p> <p>“%filename” means that the value immediately after the “%” is variable and the file name will be replaced with the remote path entered on the Bar Codes tab; for more information, see Remote Path on page 2-23.</p>
Execute	<p>Tells EZConfig Client to launch the application after decoding the bar code. Execute selects automatically when an application is entered in the Path field.</p> <p>You cannot de-select Execute for configuration documents.</p> <p>You can de-select Execute for registry documents; however, EZConfig Client cannot update the registry unless Execute is selected. For more information, see Default Application Association (page 2-17).</p>
Wait Until Finished	Tells EZConfig Client to wait until the associated application is finished processing before finalizing.

Registry Documents

EZConfig Editor creates registry documents in the EXM file format and also opens existing REG files and converts them to the EXM file format. EZConfig Editor cannot save registry documents in the REG file format.

Updating the Registry on the Terminal


To update the terminal's registry, you must

- Create an EXM file that is a registry document—[Creating Registry Documents](#) (page 2-18),
- Create a bar code package from that EXM file—[Creating Bar Codes](#) (page 2-21), and
- Scan the bar code with the terminal

By default, EZConfig Client on the terminal updates the Windows registry immediately after decoding the bar code.

Default Application Association


By default, registry documents are associated with EZConfig Client. While a registry document is open, click **File > Properties**.



Execute must remain selected for EZConfig Client to update the registry after decoding the bar code. If **Execute** is not selected, the registry document is deployed after decoding but the registry is not updated.


Creating Registry Documents

1. In EZConfig Editor, click **File > New > Registry Document**.



The new document contains the three top-level sections in a registry. These sections are locked and cannot be changed. You can add subsections to each section and then add keys to those subsections.

2. Click **File > Save As**.
3. Choose the name and location and click **Save**.
You cannot save the document as a .reg file; you must save it as an EXM file.
4. To add sections, select one of the registry levels, right-click, and select **Append Child Section**. Enter the section information, and click **OK**.




For more information about adding sections, see [Working with Sections](#) on page 2-7.

5. To add keys to the new section, select the section, and right-click in the key value area.
For details, see [Adding Registry Keys](#) on page 2-19.
6. Continue adding sections and keys.
7. Save the file.

Adding Registry Keys

To add a key, select a section, and right-click in the key area of the EZConfig Editor window.



Field	Description
Name	Enter the key's name.
Registry Value Type	Select the registry type from the drop down list. This value appears in the Type column.
Value	Enter the key's value.
Desc	Enter a description for the key; descriptions appear in the lower half of the EZConfig Editor window when the key is selected.

When you click **OK** to save the key, the data appears in columns in the key area of the EZConfig Editor window.

Key	Type	Value
Test Key	REG_SZ	001.123.456.001

Processing Registry Documents on the Terminal

After EZConfig Client updates the registry, the EXM file itself is deployed to the location entered in the [Remote Path](#) (page 2-23) field on the [Bar Codes Tab](#) (page 2-22).



Note: EXM files appear with an  icon on terminal windows.

If you do not want to store the registry EXM file on the terminal after updating the registry, select the [Temporary](#) (page 2-25) option on the [Bar Codes Tab](#) (page 2-22).

Persistent Registry Documents

If you want to update the registry during every cold boot, create a registry document in the EXM format, save it to the terminal in the `\IPSM\AutoInstall` folder, and cold boot. The registry settings in the EXM file will load during startup.

Note: Of course, if you want to save a registry file but not load it every startup, simply store the registry EXM file in the `\IPSM` folder.

Creating Bar Codes

EZConfig Editor embeds EXM files in bar codes. The EZConfig Client on the terminal decodes the bar code and deploys the data. Using bar codes quickly and easily configures Dolphin terminals without an IrDA, ActiveSync, or network connection to a workstation.

Document Types

EZConfig Editor produces two kinds of EXM files: configuration documents and registry documents. Both can be embedded in bar codes and processed by EZConfig Client on the terminal.

Configuration Documents


EZConfig Client deploys the EXM file in the terminal. If an EXM file is associated with an application, EZConfig Client deploys the data to that application for processing; see [Associating Applications](#) on page 2-16.

Note: The DeviceConfig.exm file must be associated with DeviceConfig.exe to be processed appropriately on the terminal.

Registry Documents

EZConfig Client updates the registry immediately without launching another application.

Bar Code Type



EZConfig Editor creates an Aztec bar code; for example,

Time and Date Stamp

EXM files are stamped with the time and date the moment EZConfig Editor creates the barcode.

Bar Code Size and Number

The amount of data in the EXM file determines how many bar codes are generated and the physical size of each bar code. More data means more bar codes and larger bar codes.

EZConfig Editor offers four ways to control how many bar codes are produced and adjust the size of each bar code:


1. Set byte size limits on how much data each bar code can contain—see [Max Barcode Size](#) on page 2-24.
2. Split the data across a specified number of bar codes—see [# Bar codes to generate](#) on page 2-23.
3. Simplify the EXM file in the bar code—see [Simplified](#) on page 2-23.
4. Scale the bar codes on the bar code sheet—see [Bar Code Scaling Factor](#) on page 2-26.


Bar Code Sheet

EZConfig Editor produces a bar code sheet that contains the generated bar codes. Bar code sheets can be printed from a laser printer, copied to the clipboard, and saved as an HTML file; see [Printing and Saving Options](#) on page 2-26.

In addition, individual bar codes can be saved as TIF or PNG graphic files that can then be emailed and printed; see [Bar Codes Tab](#) on page 2-22.

Generating Bar Codes

When creating a bar code, EZConfig Editor automatically encrypts and compresses the data in the EXM file. To generate a bar code, click **File > Create EZConfig Bar Code** OR the **Create Bar Code** toolbar button  while the EXM file is open. EZConfig Editor generates a bar code or codes. The Bar Codes tab window opens displaying the details of the bar code package generated.





The Bar Codes and Advanced tabs offers several processing options.

Note: The number of bar codes produced depends on the amount of data present in the EXM file. The more data present, the more bar codes generated. You must scan all bar codes to deploy the package!

Bar Codes Tab


The Bar Codes tab previews and customizes generated bar code(s).

Field/Option	Description
Display	Indicates which bar code is displayed in the preview area; the default is "1," the first bar code in the package. If more than one bar code was generated, you can use the up and down arrows to scroll through the bar codes.
(___ bytes)	Displays the exact byte size of the bar code displayed in the preview area. Total Package Size (page 2-26) is displayed at the bottom of the window. <i>Note: The sum of bar code size is typically larger than the package size.</i>

Field/Option	Description
Remote Path	Type in the location and filename where the EXM file should be deployed on the terminal. For instance, <code>\ipsm\deviceconfig.exm</code> Tap the browse button  to navigate to the location on the terminal. Your ActiveSync connection must be active.
Full Contents	Includes the full content of the EXM file in the bar code, without simplifying.
Simplified	Simplifies the EXM file in the bar code, which removes disabled sections, description information, and bar code settings (if any), which decreases the size of the bar code. The open EXM file is not simplified. Simplified is selected by default. The differences in total package size are displayed in the Package Size (page 2-26) field. Individual bar code size can be seen in the Display (page 2-22) field.
# Bar codes to generate	This is active only if the Always use minimum # bar codes (see page 2-24) is not selected. When this slider is active, you can move the slider toward minimum or maximum to change the number of bar codes generated. As you move the slider, you'll see the number of bar codes in the counter at the bottom of the window  and you'll notice the graphic of the bar code in the preview area change.
Copy to Clipboard	Copies the bar code displayed in the preview area to the clipboard. Use this option to paste the bar code into another application.
Save	Saves the bar code displayed in the preview area as a graphic file as a .png or .tiff. By default, the name of the graphic file is the same as the name of the open EXM file. You can enter a different name when saving.
Save All	Saves all bar codes in the package as individual graphic files. By default, the graphic files are saved with the same name as the open EXM file with a number at the end to distinguish the individual graphic files from each other.
Print	Opens the printing window where you can select print options and print the bar code package. For details, see Printing and Saving Options on page 2-26.

Advanced Tab

The Options tab contains settings that tell EZConfig Client how to process the EXM file on the terminal.



Field	Description
Bar Code Options —This section determines some of the basic bar code parameters.	
Max Barcode Size	Set the maximum amount of data (in bytes) one bar code can contain. The lower the number of bytes, the smaller the bar code. <ul style="list-style-type: none"> On the Bar Codes tab, bar code size appears in the Display field (see page 2-22). The total number of bar codes the are created as a result of the max bar code size limit appears at the bottom of the Advanced window; see Bar Codes (page 2-26).
Always use minimum # bar codes	This option is selected by default. It calibrates the data so that the minimum number of bar codes are used. When this option is selected, the number of bar codes slider on the Bar Codes tab is disabled.
Use custom password	This option enables you to password-protect the bar code you're creating. Select this option, then enter the password in the field provided. You will be able to see the password when you enter it; however, you will not be able to see the password again once you close the window because the password will be encrypted. If you password-protect the bar code, EZConfig Client on the terminal will prompt you to enter that same password on decoding.
Full screen progress dialog	This option runs the deployment progress dialog box on the terminal in full screen mode so that the user cannot open another application <u>while the bar codes are being deployed</u> on the terminal.
Warm boot after finished	This option automatically launches a warm boot on the terminal after the bar code is deployed. Use this options with EXM files that contain application information requiring a warm boot to take effect, such as registry settings.
Deployment Options —These options determine how to deploy the EXM file on the terminal.	

Field	Description
Merge each section... (Default selection)	Deploys information according to the section-level merge mode settings; see Section-Level Merge Modes on page 2-10. If already exists, deploy: <ul style="list-style-type: none"> • Always—Select to always use the section-level merge mode settings. • Only if newer—Select to use the section-level merge mode settings only if the sections are newer than the existing file.
Temporary	Deploys the EXM file temporarily. The settings in the EXM file are applied, but the file does not remain in the system after EZConfig Client is done. If the terminal contains a previous EXM file with the same name, the previous EXM file is preserved.
If already exists, deploy —This section determines how the EXM file will be deployed if there exists on the terminal an EXM file of the same name in the same location.	
Replace remote file	Replaces the existing file; no section-level merge modes are applied. If already exists, deploy: <ul style="list-style-type: none"> • Always—Select to always replace the existing file. • Only if newer—Select to replace the existing file only if the file in the bar code is newer than the existing. • Never—Do not deploy the new file; this preserves the existing file. • Prompt—EZConfig Client asks the user if they want to overwrite the existing file during deployment.
Persist Bar Code Settings	
Stores the settings from the Options, Bar Codes, and Web Page tabs within the EXM file so that the same bar code settings are applied the next time a bar code is created. This increases the size of both the EXM file and the bar code(s). If the Simplify option is selected, bar code setting information is not included in the bar code but remains in the open EXM file.	


Information at the Bottom of Tab Windows

Package Size: 651 bytes Compression:On Encryption:On Bar Codes: 1

Field	Description
Package Size	Displays the total size of the bar code package. This number changes with simplifying.
Compression On	Notifies you that compression and encryption are both on. Compression and encryption are always on by default. EZConfig Editor uses 128-bit encryption automatically.
Encryption On	
Bar Codes	Displays the total number of bar codes generated. This number changes as you move the slider on the Bar Codes tab.

Printing and Saving Options

On the Bar Codes tab, when you click **Print**, a bar code printing window opens offering you a number of printing options.



Field/Option	Description
Preview Area	This is the largest section of the tab window and displays a preview of the bar code sheet. Use the scroll bars to see all the bar codes.
Header	Type in a custom header for the page. "EZConfig Bar Code Sheet" is the default header.
Footer	Type in a custom footer for the page. "Hand Held Products" is the default footer.
Bar Code Scaling Factor	Adjusts the size of each bar code by scaling all of them up or down, which determines how many bar codes can fit on each page. This does not change the amount of data in each bar code, just the size of the bar code on the page.

Field/Option	Description
Save	Saves the bar code sheet as an HTML file.
Preview	<p>Click to see a print preview.</p> <div data-bbox="548 451 1308 993" data-label="Image"> </div> <p>Click Print on this window to print your bar codes.</p>

Converting Known INI and MNU Files

EZConfig Editor contains a batch conversion tool that converts known INI files on the terminal to the new EXM file format.

EZConfig Editor pulls INI files from the \IPSM folder of a remote device, converts them to the EXM file format, and saves both original INI files and the converted EXM files in folders created on the workstation. You don't lose your original INI files in the conversion.

Note: You must have an ActiveSync connection between the workstation and the device to use this tool.


Known INI and MNU Files

- *Autorun.ini
- RASMan.ini
- Scanwedge.ini
- RFSettings.ini
- ImageDemo.ini
- ScanDemo.ini
- *Any EZMenu file (INI or MNU)


*These files must be converted using this tool to run properly on Dolphin terminals.

Converting Files

1. In EZConfig Editor on the workstation, click **Tools > Upgrade Remote INI Files**. You receive a warning message describing what is about to happen.



2. Click **Yes** and EZConfig Editor retrieves remote INI files on the terminal and displays them in a list.




3. Select the files and the location on the workstation for the files. The default location on the workstation is:

C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\Device Image\Converted Files\Upgrade X.

The X increases by one each time you run a batch conversion.

- When you click **OK**, the conversion runs.
- EZConfig Editor creates two folders inside the Upgrade X folder: **Converted EXMs** and **Original INIs**.



Note: An Upgrade X folder with these two subfolders is created every time you run a conversion. Upgrades do not save over each other.

- Check each converted EXM file in EZConfig Editor.

Note: Even though conversion is complete, you have not yet upgraded your terminal! The old INI files remain in their original location on the terminal.

Upgrading Dolphin Terminals

Once you approve of the converted EXM files, you must transfer them to the Dolphin terminals manually.

- Delete the old INI files stored in the terminal.
- Follow the steps for installing an upgrade on a Dolphin terminal (see [Installing an Upgrade on the Terminal](#) on page 1-8) but don't cold boot yet.

Note: You want to install an upgrade to make sure that you have the latest versions of AutoInstall.exe, Autorun.exe, and EZConfig Editor on the terminal.


- Transfer the new converted EXM files to the terminal and say yes when you are asked to replace the existing files.
- Cold boot the terminal. The new, converted EXM files install during AutoInstall.

EZConfig Editor on the Terminal

EZConfig Editor on the terminal edits and creates EXM files in the terminal and contains the same basic functionality as the editor on the workstation.


Accessing EZConfig Editor


Tap **Start > Power Tools > EZConfig Utilities**



The EZConfig Utilities window provides access to both the EZConfig Editor and the EZConfig Client (see page 2-34) as well as the EXM files on the terminal.

Opening EXM Files

- Tap directly on an EXM file to open it in EZConfig Editor.
- Tap the EZConfig Editor icon to open EZConfig Editor. (Then tap **File > Open** to open an EXM file.)
- In File Explorer, navigate to an EXM file and tap once on the file  to open it in EZConfig Editor.



Available Menus

The menus in the Command bar contain the same items as the menus in the EZConfig Editor on the workstation.

File Menu

For details, see [File Menu](#) on page 2-3.

Note: The one difference in the file menu is that you cannot generate bar codes from EXM files on the terminal.

Edit Menu

The Edit menu pops up when you tap and hold on a section or key.
For details, see [Edit Menu](#) on page 2-4.

View Menu

This menu enables you to view the locked icon over locked section folders.

Tools Menu


For details, see [Tools Menu](#) on page 2-5.

Editing Sections


Modifying Text

To edit a section name or description, you have three options:

1. Select the section and tap **Edit > Modify**.
Select an item and press the ENTER key.
Tap and hold on the section name, then select **Modify** on the Edit menu that pops up.



2. All three options open the Edit Section window.



3. Tap inside the **Name** or **Description** fields and edit the text.

-
4. Tap **OK** to save changes. (You can also press the ENTER key.)
Tap **Cancel** to close the window without changes.

Moving Sections

You cannot drag and drop to move sections in the tree. Use the **Cut**, **Copy**, **Paste**, and **Paste as Child** items on the Edit menu to move sections.


Note: The Paste function pastes sections at the same level they were cut by default.

Editing Keys


Modifying Text

To edit a key's name, value, or description, you have three options:

1. Select the key and tap **Edit > Modify**,
Select the key and press the ENTER key, OR
Tap and hold on the key's name, then select **Modify** on the Edit menu that pops up.



All three edit options open the Edit Key window.




2. Tap inside the **Name**, **Value** or **Description** fields and edit the text.
3. Tap **OK** to save changes. (You can also press the ENTER key.)
Tap **Cancel** to close the window without changes.

Moving Keys

You cannot drag and drop to move keys. Use the **Cut**, **Copy**, and **Paste as Child** items on the Edit menu to move keys.


Launching Associated Applications

The Tools menu contains an item named **Launch Associated App**.



Launch Associated App is enabled only when there is an application associated with the EXM file. Selecting this item automatically saves the open EXM file and launches the associated application while the EXM file remains open.

To see the associated application, tap **File > Properties**.



The **Path** field contains the launch location of the application.

The **Args** field contains any command line arguments to execute when the application launches.

For more information about associating applications, see [Associating Applications](#) on page 2-16.

Example 1: You've saved changes to an open DeviceConfig.exm file.

To apply those changes immediately, tap **Tools > Launch Associated App**. Because the DeviceConfig.exm file is associated with DeviceConfig.exe by default, DeviceConfig launches and applies the settings in the DeviceConfig.exm file.

Example 2: You've saved changes to an open registry document.

Because registry documents are always associated with EZConfig Client, tapping **Tools > Launch Associated App** updates the registry. EZConfig Client always updates the registry when launched from an EXM file that is a registry document.

Example 3: You've saved changes to an open ScanWedge.exm file.

And that ScanWedge.exm file has the following parameters as the associated application:

Path: \\program files\power tools\scanwedge.exe

Args: /restart

Tapping **Tools > Launch Associated App** refreshes ScanWedge with the new settings.


EZConfig Client

EZConfig Client decodes bar codes created in EZConfig Editor and deploys the data in the terminal. In addition, if the EXM file in the bar code is associated with an application, EZConfig Client launches that application, which then processes the decoded data.

EZConfig Client decodes bar codes with 40-bit and 128-bit encryption.

Storage Location

The EZConfig Client executable is stored in the `\IPSM` folder.



For upgrades, EZConfig Client is located in the IPSM image installed on the workstation. This EXE **must** be copied and pasted into the `\IPSM` folder on the terminal. For more information, see [Installing an Upgrade on the Terminal](#) on page 1-8.


Using EZConfig Client

1. On the Dolphin terminal, tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) opens.

You can scan the first bar code from the Power Tools main window by pressing the SCAN key; see page 2-36 for details.


EZConfig Client can also be launched with a HotKey from any window; see page 2-37 for details.

2. Tap **EZConfig Utilities**  > **EZConfig Editor** . The EZConfig Client window opens.




3. Point the terminal at the first EZConfig Editor bar code, then press the SCAN key.
4. EZConfig Client decodes the bar code.


If there is only one bar code in the package, EZConfig Client deploys the package.
If there is more than one bar code in the package, EZConfig Client decodes the bar code, records that one bar code has been read, and waits for the next scan.



5. Scan all the bar codes in the package. Bar codes can be scanned in any order.
6. When all bar codes in the package have been scanned, the EZConfig client deploys the data.



Note: If the EXM file is programmed to launch an application such as ScanWedge, a window pops up informing you of initialization.



EXM File Processing

After decoding, EZConfig Client saves EXM files to the location in the terminal selected in the [Remote Path](#) (page 2-23) field on the [Bar Codes Tab](#) (page 2-22). (If the [Temporary](#), page 2-25, option is selected in the bar code, EZConfig Client does not save the EXM file.)

There are two types of EXM files: configuration documents and registry documents. EZConfig Client processes each type of file differently.

Configuration Documents

If the EXM file was associated with an application, EZConfig Client launches and deploys the data to that application for processing.

*Note: DeviceConfig.exm **must** be associated with DeviceConfig.exe to be processed on the terminal appropriately. After decoding the bar code, EZConfig Client deploys the data to DeviceConfig.exe, which applies the settings to the terminal.*


Registry Documents

Registry documents are always associated with EZConfig Client. The **Execute** option ([Execute](#), page 2-16) determines whether the registry is updated or not. If Execute is selected, EZConfig Client updates the registry immediately after decoding the bar code.

Multiple Bar Codes

Some EXM files generate more than one bar code. If multiple bar codes were generated, EZConfig Client recognizes that there is more than one bar code in the package and tracks each bar code scanned and decoded. Bar codes can be scanned in any order, but EZConfig Client does not deploy the data until **all** the bar codes in the package have been scanned.

EZConfig Client Window



Field	Description
Package ID	This is the ID of the entire package. EZConfig Editor assigns an ID to bar code packages when creating the bar code.
Status	This field displays the decode status of the bar codes scanned so far. If there is more than one bar code in the package, this field acts as a decode counter. The Status field displays: <ul style="list-style-type: none"> • How many bar codes have been scanned and • How many bar codes are in the package
Read # box	This box displays the list of bar codes scanned and decoded.
Accept Unsecure	This option allows EZConfig Client to scan bar codes that are not encrypted. <i>Note: By default, all bar codes created in EZConfig Editor are encrypted.</i>

Scanning Bar Codes Directly from the Power Tools Main Window

When the Power Tools or Demos main windows are open, press the SCAN key and:

- If there is only one bar code in the package, EZConfig Client decodes and deploys the bar code without opening the EZConfig Client window.
- If there are multiple bar codes in the package, EZConfig Client decodes the first bar code and opens the EZConfig Client window showing that one bar code in the package has been scanned.

Launching EZConfig Client with a HotKey

Pressing ALT + SCAN launches EZConfig Client from any application window after you activate the HotKeys Power Tool; see [HotKeys](#) on page 6-5.

ScanWedge

Bar code decoding in EZConfig Client is compatible with ScanWedge. You can set ScanWedge to pass bar code information to EZConfig Client for further processing.

For details, see [Accept EZConfig](#) on page 5-4.

Command Line Arguments

/%filename	Executes the EXM file; this is the default entry.
/q	Quiet mode
/s	Full screen
/o	No menu
/e	Exit if first scan fails to deliver a valid bar code
/u	Accept (decode) unsecure bar codes



Overview

DeviceConfig consists of the DeviceConfig.exe and the DeviceConfig.exm file located in the \IPSM folder. DeviceConfig.exe looks for and applies the settings in the DeviceConfig.exm file.

DeviceConfig.exm File

The DeviceConfig.exm file contains terminal configuration settings. Because this file is stored in the \IPSM folder, its configuration settings persist through cold boots and should be considered system defaults.

Enabling DeviceConfig Functionality

By default, all sections except the [About Section](#) (see page 3-9) are disabled, which means that the key values are not applied to the terminal. To use the DeviceConfig.exm file to configure the terminal, enable the sections and keys required by your configuration in [EZConfig Editor](#) (page 2-2) on the workstation or [EZConfig Editor on the Terminal](#) (page 2-30).

Autorun

[Autorun](#) (see page 4-1) launches DeviceConfig.exe, which applies the DeviceConfig.exm settings, then launches a cold boot followed by a warm boot.

Bar Code Delivery

When the DeviceConfig.exm file is delivered to the terminal via bar code, EZConfig Client launches DeviceConfig.exe automatically after decoding. DeviceConfig.exe then applies the settings in the DeviceConfig.exm file in the terminal. For more information, see [Creating Bar Codes](#) (page 2-21) and [EZConfig Client](#) (page 2-34).

The DeviceConfig.exm file **must** be associated with DeviceConfig.exe for EZConfig Client to launch DeviceConfig.exe after decoding the bar code. In EZConfig Editor, the associated application path must be

```
\IPSM\deviceconfig.exe
```

For more information, see [Associating Applications](#), page 2-16.

Settings in the WLAN Supplicant

Many settings in the DeviceConfig.exm file match the settings in the WLAN Supplicant on the terminal that allow the user to enter and save the same values. If a user changes a setting in the WLAN Supplicant, that setting is applied but stored in RAM memory and erased during the next cold boot. During the next cold boot, Autorun launches DeviceConfig, which then re-applies the settings in the DeviceConfig.exm file.

DeviceConfig.exm Sections and Keys

The sections and keys in the DeviceConfig.exm file are locked, which means that you can change values but not names or descriptions.

Section Name	Description	See Page
Connections	Configures communication parameters. There are child sections that configure the IrDA port, the on-board radios, and the ActiveSync connection.	3-2
System	Configures basic system settings.	3-9
Applications	Configures software applications.	3-10

Connections Section

The Connections section contains child sections that set communication parameters on the terminal.

Beam Section

The Beam section enables and disables the IrDA port.

Radio Manager Section

In the Radio Manager, typically, you would enable the radio in the **WiFi** section, enable DHCP in the **TCPIP** section, then configure the radio settings in the **Security\Supplicant\ProfileX** or **Security\NonSupplicant** section.

WiFi Section

The keys in the WiFi section control the settings of the WLAN radio.

Key	Description	Default Value	Available Values
Enable	Enables and disables the WLAN radio.	1	0=Disabled 1=Enabled; if enabled, the GSM radio section is disabled automatically
PowerMode	Specifies the power save mode.	1	1=Disable; radio is powered constantly (power save mode is not used) 2=Always Enable; power save mode is used 3=Auto Enable; EPSParm key defines radio vs. battery performance
EPSParm	When PowerMode is set to 3 (Auto Enable), this parameter specifies radio vs. battery performance.	N/A	X=A value between 1 and 10, where: 1=Best Radio Performance (Minimum) 10=Best Battery Life (Maximum)

WiFi Section

The keys in the WiFi section control the settings of the WLAN radio.

Key	Description	Default Value	Available Values
DriverName	Specifies the name of the radio driver. This string must match the name of the driver for the current device.	N/A	X=A value in the drop-down list; radio driver names are terminal-specific. Different Dolphins have different radio drivers.

TCPIP Section

The keys in the TCPIP section determine how the radio handles IP addresses.

Key	Description	Default Value	Available Values
DHCP	Enables and disables DHCP (Dynamic Host Configuration Protocol).	1	0=Disabled; the static IP address in the IPAddress key is used for the radio interface. 1=Enabled; the IP address for the radio interface is requested from a DHCP server.
The remaining keys need to be set when DHCP is disabled. When DHCP is enabled, these numbers are dynamically requested from a DHCP server.			
IPAddress	Static IP address for the radio interface.	N/A	Static IP address
SubnetMask	SubNet mask for the static IP address.	N/A	Subnet mask address
DefaultGateway	Default gateway for the static IP address.	N/A	Gateway address
DNS	Domain name server for the static IP address.	N/A	Domain name server address
Domain	Domain name for the terminal	N/A	Terminal's domain name
WINS	Windows name server.	N/A	Windows name server address

Security Section


The Security section has no keys and one child section named “Supplicant,” which contains several profile subsections.

Supplicant Section

The Supplicant section consists of a number of child sections. The default child section is named **Profile1** and contains all the keys necessary to create a configuration profile for the WLAN radio.

To create multiple radio configurations, copy the **Profile1** section and paste it at the root level of the Supplicant section. Then, rename that profile and configure the keys according to the desired network configuration. Each child section name is arbitrary, but each name must be different.

The Supplicant section contains one key named **ActiveProfile**. Type in the Value equal to name of one of the desired profile child sections.



When DeviceConfig is activated on the terminal, the terminal will apply the settings in the profile specified in the ActiveProfile key. If the ActiveProfile key does not have a matching profile, the radio will be enabled by DeviceConfig but no specific radio configuration will be activated, which means that the radio will not connect to your network.

Profile Subsections

Each Profile subsection contains the keys that configure the radio connection from the terminal to the network.

Key	Description	Default Value	Available Values
SSID	The service set identifier used to connect to network; usually the network name of the access point or peer station.	N/A	X=Your network's SSID Any=Connect to any network
Assoc. Mode	The general association mode (sometimes called “authentication”) of the radio.	N/A	<ul style="list-style-type: none">• None (no authentication or encryption)• WEP• IEEE 802.1X• WPA-Personal (PSK)• WPA-Enterprise (EAP)• WPA(2)-Personal (PSK)• WPA(2)-Enterprise (EAP)
Encryption	The encryption mode available for the association mode.	N/A	Open & Shared (WEP) TKIP, AES-CCMP, TKIP & CCMP (WPA)

Profile Subsections

Each Profile subsection contains the keys that configure the radio connection from the terminal to the network.

Key	Description	Default Value	Available Values
EAP Method	Available EAP methods for IEEE 802.1X and WPA(2)-Enterprise (EAP) association modes.	N/A	<ul style="list-style-type: none"> • LEAP • PEAPv0-MSCHAPV2 • PEAPv1-MSCHAPV2 • PEAPv1-GTC • PEAPv1-TLS • FAST-MSCHAPV2 • FAST-GTC • FAST-TLS • TLS • TTLS-MD5 • TTLS-MSCHAPV2 • TTLS-GTC
PSK	Enter the private share key for the WEP association mode.	N/A	User-defined
Identity	This is the 802.1X identity supplied to the authenticator. The identity value can be up to 63 ASCII characters and is case-sensitive.	N/A	User-defined
Password	This is the password used for MD5-Challenge or EAP authentication. It may contain up to 63 ASCII characters and is case-sensitive. Asterisks appear instead of characters for enhanced security.	N/A	User-defined
Anonymous ID	Enter the anonymous ID. This ID creates a tunnel through which the real ID (as entered in the Identity field) can pass. For additional security, make this ID different than the one entered in the Identity field.	N/A	User-defined
Tunnel PAC Machine PAC	For EAP-FAST, a one-time provisioning exchange establishes a shared secret, called a Protected Access Credential (PAC) Key. That PAC Key is used for all subsequent authentications.	N/A	Enter the address on the Dolphin terminal of either PAC (tunnel or machine). <i>Note: The PACs must be located on the Dolphin terminal!</i>
Provisioning	Provisioning refers to service activation and involves programming various network databases with the customer's information.	N/A	<ul style="list-style-type: none"> • No Provisioning • Anonymous • Authenticated • Anonymous + Authenticated
CA and/or Client Certificate	CA certificates are any certificates created by a certified authority (CA). Client certificates contain information that identifies the user, as well as information about the organization that issued the certificate. This ensures that you can encrypt data end-to-end.	N/A	Enter the address on the Dolphin terminal of either certificate (CA or Client). The certificates must be located on the Dolphin terminal!

Profile Subsections

Each Profile subsection contains the keys that configure the radio connection from the terminal to the network.

Key	Description	Default Value	Available Values
Private Key	Private keys are used with certain types of EAP authentication.	N/A	Enter the address on the Dolphin terminal of the private key. The private key must be located on the Dolphin terminal!
Priv Key Password	Private keys can be locked by passwords.	N/A	Enter the password that unlocks the private key.
WEP Key Mode	Mode being used by the WEP keys (in Key1–Key4 keys). Key validation occurs when DeviceConfig is loaded on the terminal (often during AutoInstall), not when you save the DeviceConfig.exm file.	N/A	ASCII uses all alpha numeric characters. HEX uses only numerics and A-F. Valid lengths are as follows: <ul style="list-style-type: none">• 64-bit ASCII=5• 128-bit ASCII=13• 64-bit HEX=10• 128-bit HEX=26
WEP Key1–Key4	In fields Key 1—Key 4, enter the specific key. The format of each key must match the key length type selected in the WEP Key Mode key. To use dynamic keys in your configuration, leave all the key fields blank.	N/A	User-defined
Active Key	Enter the number of the key that you want to be active in this configuration.	N/A	1, 2, 3, or 4

Bluetooth Section

The keys in this section enable the Bluetooth radio and configure a Bluetooth printer as a Favorite. If there is no Bluetooth radio installed in the terminal, disable this section.

Key	Description	Default Value	Available Values
Enable	Enable and disable the Bluetooth radio. This is the top level of the tree; printer settings are in a child section.	1	0=Disable 1=Enable; the GSM radio is disabled automatically
Default Printer	This is a child section that configures a Bluetooth printer as a Favorite Bluetooth Device. By entering the necessary information from the Bluetooth printer in the DeviceConfig.exm file, and then distributing that file to a group of terminals, you can bypass the manual process of setting up a printer as a Bluetooth Favorite on each terminal.		
Address	Bluetooth MAC Address of the printer; see Obtaining the MAC Address on page 3-7.	N/A	MAC Address
COMPort	Number to assign to the virtual COM Port. <i>Note: It's best to leave this value as 0.</i>	0	Min=0 Max=9
DeviceName	Friendly name of the printer.	N/A	Printer name

Bluetooth Default Printer Values


In general, to establish a printer as a Bluetooth Favorite Device, you must establish the printer as a Bluetooth Favorite on the terminal. The problem is that Bluetooth Favorite settings are stored in RAM memory and therefore erased during each cold boot. The Default Printer section stores these settings permanently in the DeviceConfig.exm file so the printer remains a Favorite after a hard reset.

Furthermore, you can distribute a DeviceConfig.exm file with the printer settings to multiple terminals. After DeviceConfig.exe applies the settings in the DeviceConfig.exm file (launched manually or after a hard reset), the printer is set up as a Favorite automatically, without any special configuration to each terminal.

After you have established a printer as a Bluetooth Favorite Device on an individual terminal, obtain the values for the **Address** and **Service** keys from the registry in RegEdit.

Obtaining the MAC Address

After you have set up the Bluetooth printer on the terminal, use RegEdit to find the printer values.

1. Tap **Start > Power Tools > RegEdit**  .
2. Navigate to **HKEY_LOCAL_MACHINE > SOFTWARE > Microsoft > Bluetooth > Device > [MAC Address]** .
3. Copy the name of the subsection; this is the MAC address of the printer.
4. Enter this address in the **Address** key in the **Bluetooth > DefaultPrinter** section of the DeviceConfig.exm file.

GSM Section

If there is no GSM radio installed in the terminal, disable this section.

Key	Description	Default Value	Available Value
Enable	Enables and disables the GSM radio.	0	0=Disable 1=Enable; when enabled, the WLAN radio turns off automatically.
APN	Enter the Access Point Name (APN) for the GPRS network.	Empty	APN value
IPAddress	Enter the IP Address.	Empty	Empty=GSM uses DHCP (server-assigned IP address) X=IP address
Protocol	Enter the protocol to use.	IP	Protocol type
Username	Enter the username for the GPRS connection.	Variable	Empty=Disabled 0=Disabled X=The username for the GPRS connection.
Password	Enter the password associated with the username for the GPRS connection. <i>Note: This key is encrypted; see Encrypted on page 2-14.</i>	Variable	Empty=Disabled 0=Disabled X=The password for the GPRS connection.

ActiveSync Section

The ActiveSync Section configures the terminal's ActiveSync connection parameters.

Key	Description	Default Value	Available Values
AutoConnect	Enables and disables the ActiveSync connection when the terminal first connects to the communication peripheral.	1	0=Disable ActiveSync connection 1=Enable ActiveSync connection
Connection	Specifies the connection type and baud rate.	'USB Connection	`USB Connection `115200 Default `19200 Default `38400 Default `57600 Default <i>Note: These values must be typed in exactly as they appear here.</i>

System Section

The System section contains child sections that configure various system settings. For specifics on each sections and their keys, refer to the Description sections in the DeviceConfig.exm file itself.

About Section


The About section sets a unique device name and description for the terminal. By default, this section is enabled and applied to the terminal after each cold boot.

Key Name	Description	Default Value	Available Values
DeviceName	Sets the name of the device.	ID [SerialNumber]	See DeviceName Restrictions on page 3-9.
DeviceDescription	Sets the device description.	N/A	User-defined; however, the description cannot exceed 15 characters in length.

Device ID Tab

The values of the **DeviceName** and **DeviceDescription** keys appear in the **Device name** and **Description** fields on the Device ID tab on the terminal.

On the Dolphin terminal, tap **Start > Settings > About > Device ID** tab.



Note: ActiveSync recognizes the Device name and Description from this applet.

DeviceName Restrictions

- The DeviceName must begin with a letter.
- The DeviceName cannot exceed 15 characters in length.
- Any text outside brackets (“[xxxx]”) will appear as text in the **Device name** field.

Content

[SERIALNUMBER]

What appears in the Device name field...

The terminal’s serial number pulled dynamically from the kernel. This is the serial number that appears in [SysInfo](#) (see page 6-15) as the [Terminal Serial Number](#) (see page 6-17).

[MODELNUMBER]

The terminal’s model number pulled dynamically from the kernel. This is the serial number that appears in [SysInfo](#) (see page 6-15) as the [Model Number](#) (see page 6-17).

RAM Section

The RAM section allows you to provision RAM memory on Windows Mobile 6.0-based terminals.

Key	Description	Default Value	Available Values
Split	This is the RAM split percentage; the percentage that will be allocated to the filesystem.	50	Min=0 Max=100 See Split Restrictions on page 3-10.
Prompt	Determines whether the system prompts you before the memory is re-allocated.	1	0=Disabled; you will not be prompted. DeviceConfig's settings are applied automatically. 1=Enabled; you are prompted before the memory is re-allocated. <i>Note: If the allocation is the same, nothing will occur.</i>

Split Restrictions

The percentage split you are able to enter is specific to each terminal's memory configuration. Min/max ranges can be retrieved from SysInfo or SetRAM.

- See [RAM INFO](#) on page 6-20.
- See [SetRAM Window](#) on page 11-2.

AutoInstall

When the RAM section is enabled on Windows Mobile 6.0-based devices, AutoInstall.exe launches DeviceConfig in a mode that checks **only** the memory allocation in the RAM section of DeviceConfig.exm against the terminal's current memory allocation.

If there is a discrepancy and the Prompt key in the RAM section is enabled, a prompt appears asking if you want to apply the memory allocation in DeviceConfig. If there is a discrepancy and the Prompt key in the RAM section is disabled, the memory allocation in DeviceConfig is applied.

Note: AutoInstall.exe launches the RAM section of DeviceConfig prior to installing cab files. No other DeviceConfig settings are applied at this time.

Applications Section

The Applications section configures specific software applications installed on the terminal.

Internet Explorer Section

The Internet Explorer section defines the home page for Pocket® Internet Explorer.

MobiControl Section

If the terminal includes the MobiControl Bootstrap Agent (/IPSM/MCBootstrapAgent.exe), then DeviceConfig can be used to configure the terminal to connect to a MobiControl Server and download the appropriate agent to the device.

This section is disabled by default and should only be enabled when configuring the device to connect to the MobiControl Server for the first time.

The root level of the MobiControl section contains the main ConfigPath. By default, this is "IPSM\MCBootstap.ini."

Key	Description	Default Value	Available Value
Device Subsection			
NameType	Mandatory The name the device will register as on the server.	1	1=Use Device ID as the device name 2=Use custom name
DeviceName	Mandatory when NameType is set to 2. This is the custom name of the device.	N/A	X=Custom name can contain customized macros; e.g., "%AUTONUM%"
DeviceClass	Optional The rule tag of the Add devices rule . When the rule tag is not specified here, the device will use an Open, Add devices rule.	N/A	X=The specific rule tag. Please refer to MobiControl Help on how to create an open rule.
DeviceIDType	Optional Specifies what is used for the device ID.	3	1=HAL Old Device ID 2=HAL New Device ID 3=HAL UUID 4=User Defined 5=Server specified 6=MAC
Info Subsection			
SiteName	Mandatory This is the site name of the MobiControl Server	N/A	X=MobiControl Server name
Method	Mandatory The installation method.	1	1 (Honeywell standard)
Comm Subsection			
Broadcast	Optional Enable broadcasting for discovering server addresses.	0	0=Disable 1=Enable
RetryDelay	Optional Retry delay time when connection to the server fails.	30000	X=Milliseconds
Connection Subsection			
DeploySvr1	Mandatory when Broadcast key is disabled. This is the MobiControl Server IP address and port.	N/A	X=IP address:port e.g., 192.168.1.238:5494


Command Line Arguments

- /q*** Quits the program; this command line in the Args field of the Associated Application window stops the confirmation message from appearing after DeviceConfig.exe finishes processing.
- /boot*** Reboots DeviceConfig.exe


Launching DeviceConfig.exe Manually

DeviceConfig.exe does launch automatically after each cold boot. However, if you make changes to the DeviceConfig.exm file that you want applied in the terminal immediately, manually launch DeviceConfig.exe.

1. Tap **Start > Power Tools > EZConfig Utilities > DeviceConfig.exm**.
2. Tap **Tools > Launch Associated App**.



3. The settings in the DeviceConfig.exm file are saved and applied to the terminal configuration by DeviceConfig.exe.
4. A message appears confirming that DeviceConfig.exe has finished processing the DeviceConfig.exm file.



Temporary Option for Bar Code Deployment

The [Bar Codes Tab](#) (see page 2-22) in EZConfig Editor contains a Temporary option (see page 2-25) that, when selected during bar code creation, applies the settings in the DeviceConfig.exm file temporarily, which means until the next cold boot.

In the terminal, EZConfig Client deploys the DeviceConfig.exm file and launches DeviceConfig.exe, which applies the settings in the DeviceConfig.exm file as usual. However, when the Temporary option is selected, the DeviceConfig.exm file is not saved after processing is finished. The original file is preserved instead, and its settings will be restored during the next cold boot.

Select this option when you want establish a temporary configuration in the Dolphin (such as access to a specific network in a facility) without changing the default configuration.



Autorun and AutoInstall


Overview

Startup is the launch sequence when a Dolphin terminal is booted. There are two startup Power Tools:

1. [Autorun](#) (see page 4-1)
2. [AutoInstall](#) (see page 4-8)

Autorun

Autorun specifies the software applications to launch after each hard reset. Autorun is located in the `\IPSM` folder and consists of an `Autorun.exe` that is programmed by the [Autorun.exm File](#) (page 4-1).



During startup, after a soft or hard reset, the operating system looks for and launches `\IPSM\Autorun.exe`. If the `Autorun.exe` is configured (by `Autorun.exm`) to launch an application, that application launches when `Autorun.exe` launches. `Autorun` can launch up to 32 applications or utility programs after each hard reset.

Note: The `Autorun.exm` file allows applications to be launched based on conditional situations, including the return code of another application launched previously and specific characteristics of the Dolphin terminal itself.

Autorun.exm File

The `Autorun.exm` file has a multi-level tree structure. There are two top level sections: Settings and Programs.

Settings Section

The Settings section stores general `Autorun` settings; see [Settings Section Keys](#) on page 4-2.

Programs Section

The Programs section contains many child sections and determines the sequence of events at startup, including which programs launch and when.

Program Sections and Launch Sequence

Each section is a program to launch at startup. The sequence of sections determines the launch sequence on the terminal; the terminal reads this file consecutively. To change the launch sequence, move the section up or down in the list; see [Working with Sections](#) (page 2-7).

Enabling and Disabling Sections

If you don't want the application to launch at startup, you can delete the section. However, program sections contain settings you'll want to keep when adding that same application back to startup. To keep the program section in the file for future reference, disable the program section instead of deleting it. Disabled sections appear in gray.

When processing files, the terminal behaves as though disabled sections are not there and moves on to the next enabled section.

Settings Section Keys

Note: This section and most of its keys are locked, which means that you can change the value but not the name or description.

Key	Function	Default	Available Values
Version	Stores the EXM file version.	22	You cannot modify this value!
ByPassKey	Defines the key that can be pressed to bypass Autorun	42=SCAN key	
StartMenu	Enables and disables the Start menu during Autorun	1	0=Disable; the Start menu is disabled during Autorun. 1=Enable; the Start menu is enabled.
Debug	Controls the debug function at AutoInstall.	0	0=Disable 1=Enable, an autorun.log file is created in the \IPSM folder.
TestMode	Runs the terminal in test mode and tests the functionality of AutoInstall. This is a diagnostic tool. When enabled, applications stored in the AutoInstall folder, including the radio drivers, are not loaded during startup.	0	0=Disable 1=Enable
EZConfigKey	Specifies a key that launches EZConfig Client before Autorun starts processing the Programs section; i.e., before Autorun starts launching programs.	9=Tab key	Empty=You must launch EZConfig Client to scan bar codes from EZConfig Editor

Programs' Subsections

Here are a few of the standard child sections of the Programs section:

Section	Description
Update	Attempts to launch an Update.exe application from the SD (Secure Digital) card, if one exists.
AutoRun SC1 & SC2	Attempts to process an Autorun configuration file from the SD card (if one exists); for example, to install CAB files from the AutoInstall folder in the SD card. One section applies to cold boots and the other to warm boots.
Reset	Initiates a warm boot after the cold boot during startup. Do NOT disable the Reset section!

Note: Other subsections launch the executable entered in the [Program](#) (see page 4-3) key.

Keys in Each Programs' Subsection

Each Programs' subsection contains or can contain the following keys:

Key	Function
Required Keys —These keys must be present in each Program subsection.	
Program	Specifies the command line to execute. This is the location of the program's executable. If you want a Power Tool to launch at startup, enter the location of that tool's EXE here.
Args	Specifies the command line arguments to execute at startup.
Wait	Determines if Autorun should wait for the program to complete and close before continuing to the next program in the sequence. <ul style="list-style-type: none">• 0=Continue to the next program immediately• 1=Wait enabled
StartOption	Specifies the startup options for the program. Autorun launches the program only if the startup options entered here are met. <ul style="list-style-type: none">• Blank= Always run the program.• X=See Start Options on page 4-4.
Optional Keys —These are keys you can add but don't appear in the default file.	
PNPID	Specifies a card description. This option needs to be entered only when PNPID or NONPNPID values are specified in the StartOption key.
DependIndex	Specifies the index of a dependent program.
DependExitCode	Specifies the required result of the dependent program. If the result of the dependent program does not equal the DependExitCode entered here, the current program will not be executed at startup.

Editing the Autorun.exm File

Edit Autorun.exm in EZConfig Editor. For details, see [Working with Open EXM Files](#) on page 2-7.

Adding a Program Subsection

To launch at startup, a new program **must** be a child section of the Programs section.

1. In EZConfig Editor, right click on the **Programs** section and select **Append Child Section**.
2. On the Add New Section window, enter the **Name** and **Description** and click **OK**.
3. The new section is added to the bottom of the list.
4. Use the click and drag method to move the section to the desired launch sequence. Press and hold the ALT key to make sure that you move the section at the same level. Do **not** append the section to an existing section!
5. Right-click in the key area and select **Append Key**. You must add all the required Autorun keys; see [Keys in Each Programs' Subsection](#) on page 4-3.

6. Save the file and transport it to the terminal.

Copying a File

If you want to copy a file and move it to another location, use AutoInstall and the `/copy` command line argument. For details, see [Command Line Arguments](#) on page 4-10.

Sample Autorun Configuration File

A sample Autorun.exm file installs on the workstation to **C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\EZConfig EXM Files**.

For more information, see [Sample EXM Files](#) on page 2-2.

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
DISABLED	Never, regardless of other startup options specified.	None
COLDBOOT	The terminal has performed a cold boot.	Boot type
WARMBOOT	The terminal has performed a warm boot.	
TOUCH	The terminal has a touch screen display installed.	Touch Screen
NONTOUCH	The terminal doesn't have a touch screen display installed.	
BATCH	The terminal is a batch unit (no RF or internal modem cards installed).	Mobility
RF	The terminal has an RF card installed (e.g., Cisco 802.11b).	
GSM	The terminal has a GSM radio.	
BT	The terminal has a Bluetooth radio.	
MODEM	The terminal has an internal modem card installed.	
IMAGER	The terminal has an imager installed.	Scanner
LASER	The terminal has a laser scanner installed.	
BLIND	The terminal has no laser or imager installed.	
ANYSCAN	The terminal has either an imager or a laser scanner installed.	

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
RFON	The RF radio is Enabled.	Radio
GSMON	The GSM radio is enabled.	
BTON	The Bluetooth radio is enabled.	
RFGSMBTOFF	The RF, GSM, & Bluetooth radios are disabled.	
29KEY	The terminal has a 29-key keyboard.	Keyboard
35KEY	The terminal has a 35-key keyboard.	
38KEY	The terminal has a 38-key keyboard.	
43KEY	The terminal has a 43-key keyboard.	
56KEY	The terminal has a 56-key keyboard.	
NO_KEY	The terminal has a 56-key keyboard.	

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
7300	It's a Dolphin 7300 terminal.	Model
7400	It's a Dolphin 7400 terminal.	
7450	It's a Dolphin 7450 terminal.	
74XX	It's any Dolphin terminal beginning with "74".	
7600	It's a Dolphin 7600 terminal.	
76XX	It's any Dolphin terminal beginning with "76".	
7850	It's a Dolphin 7850 terminal.	
78XX	It's any Dolphin terminal beginning with "78".	
7900	It's a Dolphin 7900 terminal.	
79XX	It's any Dolphin terminal beginning with "79".	
9500	It's a Dolphin 9500 terminal.	
9501	It's a Dolphin 9501 terminal.	
9550	It's a Dolphin 9550 terminal.	
9551	It's a Dolphin 9551 terminal.	
95XX	It's any Dolphin terminal beginning with "95".	
9700	It's a Dolphin 9700 terminal.	
9900	It's a Dolphin 9900 terminal.	
99XX	It's any Dolphin terminal beginning with "99".	
PNPID	The terminal has a card installed whose identification contains ALL of the strings specified in the PNPID setting.	Expansion Card
NONPNPID	The terminal doesn't have a card installed whose identification contains ALL of the strings specified in the PNPID setting.	

Multiple options can be specified for each category. For example, you can specify both 35KEY and 43KEY options to request that the program run in either a 35- or 43-key keyboard terminal. Separate multiple options with commas.

To ignore a category, don't specify any of its options.

Applying Startup Options to the Autorun Configuration File

For each category, Autorun validates each startup option specified in the StartOption key. If no specified option is valid in a category, Autorun does not execute the program. If at least one of the specified options is valid in each category evaluated, the program is executed.

To always execute a program, specify no options in the StartOption key.

AutoInstall

AutoInstall consists of an AutoInstall.exe that, when launched, installs the cab files in the AutoInstall folder. The AutoInstall folder is where you store cab files for software applications if you want them to persist through hard resets.




The AutoInstall program runs according to the settings in the AutoInstall.exm file.


Program Install Locations

When triggered by a hard reset, the CAB file installs the applications to the directories established in the CAB file. For most applications, this means that an EXE for the software application is placed in the **\Program Files** folder.

AutoInstall.exm

The AutoInstall.exm file controls the behavior and appearance of the AutoInstall window and install process.



Key	Function	Default Value	Available Values
Version	This is the current version of the AutoInstall.exm file. This key is read-only and cannot be modified.	3	N/A
Debug	Enable and disables logging of debug information to \IPSM\AUTOINSTALL.LOG .	0	0=Disabled 1=Enabled
Cancel	Enable and disables the Cancel button on the AutoInstall window.	0	0=Disabled 1=Enabled
FullScreen	Determines if the AutoInstall window runs in full screen mode (barring access to other windows).	1	0=Disabled 1=Enabled 2=Autoselects based on the operating platform.
HaltOnError	Sets the behavior of AutoInstall when an error is encountered. 	1	0=Log the error and continue AutoInstall 1=Halt AutoInstall and prompt the user to continue or cancel
MaskPassword	If a password is entered in the Password key, this key determines if that password is masked when entered on the screen.	1	0=Disabled 1=Enabled

Key	Function	Default Value	Available Values
Password	Establishes a password required to halt AutoInstall.	Blank	Blank=User can halt and exit AutoInstall without entering a password X=Password

Note: Remember! It's the Autorun.exm file that determines the programs and install sequence, not AutoInstall.exm.

Command Line Arguments

/copy Add **/copy** to the Autorun.exm file to automatically move a file from one location to another.

Usage: autoinstall /copy <sourcefilename> <destination>

Example: autoinstall /copy "/windows/data.mdf" "/storage card/data.mdf"

Overview

ScanWedge sends data from the decoder, serial port, or IrDA interface to the foreground application as keystrokes (as if the data were entered via the keyboard). The foreground application is the open software application whose window is currently active on the display.

As a result, you can review input data in Windows Mobile applications such as Pocket Word, Pocket Excel, and Inbox without having to load third-party applications.

Enabling ScanWedge




Tap the ScanWedge icon **once** ScanWedge. ScanWedge initializes and enables.

Command Bar Menu

When ScanWedge is enabled, a smaller ScanWedge icon appears in the command bar at the bottom of the Today screen.



Tap this icon to open the command bar menu.



Menu Item	This item ...
Enable	Enables and disables ScanWedge without exiting ScanWedge.
Settings	Opens the ScanWedge.exm file in EZConfig Editor.
About	Opens the About screen for ScanWedge.
Exit	Exits ScanWedge. The icon no longer appears in the Command bar.

Enabling ScanWedge at Startup

To run ScanWedge automatically when the Dolphin terminal boots up,

Add a link to the Scanwedge.exe in the `\WINDOWS\STARTUP` folder

OR

Enable the ScanWedge section of the [Autorun.exm File](#) (see page 4-1).

Disabling ScanWedge

Navigate to the [Power Tools Main Window](#) (see page 1-2) and tap the **ScanWedge** icon again.

OR

Select **Exit** on the [Command Bar Menu](#) (page 5-1).

Modifying the ScanWedge Configuration File

When ScanWedge is installed, a ScanWedge.exm file is inserted in the \IPSM folder. This file specifies configuration parameters for ScanWedge and must be located in the \IPSM directory. **Do not move ScanWedge.exm!**

Use EZConfig Editor on the workstation to modify ScanWedge.exm. For more information, see [Working with Open EXM Files](#) on page 2-7.

ScanWedge.exm Sections

Section	Description	See Page
Settings	Programs general settings for ScanWedge.	5-3
Comm	Specifies how the serial (RS-232) port interfaces with ScanWedge.	5-6
Decode	Specifies how the decoder/scanner interfaces with ScanWedge.	5-8
Centering	Defines the centering window for scanning bar codes when ScanWedge is interfacing with the decoder.	5-11
Formatting	Defines data formatting functionality.	5-12
Symbologies	Defines the symbologies that the scanner can decode and send to ScanWedge.	5-17
VK Mapping	Defines the virtual key sent to ScanWedge for any decoded ASCII character.	5-20

Basic Values

In each section, the following values apply (unless otherwise specified in the tables below):

0 = Disable

1 = Enable

Settings Section

The Settings section determines how ScanWedge interprets data from the decoder, serial port, and IrDA interface.

0 = Disable 1 = Enable

Settings Section Key	Description	Default Value	Available Values
Version	This is the version of ScanWedge	3	You cannot modify this value.
Debug	Enables and disables the logging of debug information to a SCANWEDGE.TXT file.	0	1=Enable. Debug data is logged in a Scanwedge.txt file stored in the \IPSM folder.
Sound	Enables and disables the audio notification for decode/data reception. There is one sound for success and another sound for an error.	1	0=Disable; no sound on decoding. 1=Enable; sound on decoding.
Leds	Enables and disables LED notification for decode/data reception.	1	0=Disable; no LEDs on decoding. 1=Enable; LEDs on decoding.
DataTerminator Specifies the character to recognize as the data terminator when receiving data from the IrDA interface or serial port.	When the data terminator character is received, ScanWedge considers the data received as successful, and sends the specified prefix key + data received + specified suffix key to the foreground application. <i>Note: The data terminator character itself will not be transmitted. If required, put this character in the suffix.</i>	13	Set to the desired character. This parameter is ignored for the decoder. The decoder knows when the data ends by itself.
PrefixKeys	Defines the ASCII keys to be sent prior to the decoded/received data. The ASCII keys are converted to virtual keys; for conversion parameters, see Virtual Key Codes Table on page 5-21. This field supports up to 16 ASCII keys; data is comma-delimited.	0 Empty, No prefix sent	For example: PrefixKeys=80,82,69,70,73,88 The example listed above would cause "PREFIX" to be sent prior to any decoded data.
SuffixKeys	Defines the ASCII keys to be sent after the decoded/received data. The ASCII keys are converted to virtual keys; for conversion parameters, see Virtual Key Codes Table on page 5-21. This field supports up to 16 ASCII keys; data is comma-delimited.	13 ENTER key	For example: SuffixKeys=83,85,70,70,73,88,13 The example listed above would cause "SUFFIX" and the ENTER key to be sent after any decoded data.
PrefixID	Specifies the symbology identifier sent prior to the decoded/received data.	0	0=No symbology identifier is sent. 1=The Code ID is sent. 2=The AIM ID is sent. 3=The SymModifier is sent.

Settings Section

The Settings section determines how ScanWedge interprets data from the decoder, serial port, and IrDA interface.

0 = Disable 1 = Enable

Settings Section Key	Description	Default Value	Available Values
SuffixID	Specifies the symbology identifier sent after the decoded/received data.	0	0=No symbology identifier is sent. 1=The Code ID is sent. 2=The AIM ID is sent. 3=The SymModifier is sent.
SoundConnect	Enables and disables <ul style="list-style-type: none">The sound that ScanWedge makes when starting up, shutting down, or restarting.The audio notification when an IrDA session is established and closed and the serial port is opened and closed.	1	0=Disabled 1=Enabled <i>Note: Audio notifications for errors can't be disabled.</i>
MessageConnect This key applies only to the IrDA and serial ports.	Enable and disables a notification message when an IrDA session is established and closed and the serial port is opened and closed.	0	0=Disabled 1=Enabled
Accept EZConfig This key applies only to the decoder .	Enables and disables ScanWedge's compatibility with EZConfig Client when decoding bar codes.	1	0=Disabled; ScanWedge processes EZConfig barcodes as it would any other barcode. 1=Enabled; ScanWedge recognizes EZConfig barcodes and passes them on to the EZConfig Client for further processing.

Settings Section

The Settings section determines how ScanWedge interprets data from the decoder, serial port, and IrDA interface.

0 = Disable 1 = Enable

Settings Section Key	Description	Default Value	Available Values
SendMode	<p>Specifies the method to use when sending the decoded message to the foreground application.</p> <p><i>Note: This setting affects only the decoded message; the prefix and suffix are always sent using the virtual key method to allow navigational functionality.</i></p>	0	<p>0=Virtual key method: each character is sent as a virtual keystroke. This method works well with almost any Windows Mobile application.</p> <p>1=Direct Text method: the decoded message is sent as text directly to the window that has the keyboard focus in the foreground application. This method is faster than the virtual key and supports barcodes with ASCII characters between 1 and 255 but works only if the foreground application uses standard Window's Edit controls for user input.</p> <p>2=Virtual Key (safe) method: each character is sent as a virtual keystroke using PostKeybdMessage(). This method only support bar codes containing ASCII characters and does not support VKMapping. This method only generates WM_CHAR messages, it does not generate WM_KEYDOWN and WM_KEYUP messages.</p>
GoodScanWav	Specifies a .wav file played on the completion of a successful decode/data reception.	Empty	<p>Empty=No .wav file is specified. The default beep or sound is played. Use the Sound (page 5-3) key to enable and disable all audio notification.</p> <p>X=The path to the specific .wav file you want played for either option. The .wav files should be 8-bit, 11KHz, mono, and PCM.</p>
BadScanWav	Specifies a .wav file played for an unsuccessful decode/data reception.	Empty	

Comm Section

The serial port settings in the Comm section determine the interaction between ScanWedge and the serial port.

Comm Section Key	Description	Default Value	Available Values
Enable	Enables (or disables) ScanWedge to receive and interpret data from the serial port.	0	0=Disabled; no data is received 1=Enabled; ScanWedge receives data from the serial port (specified in the Port key) as keystrokes to the foreground application.
AutoConnect	Enables or disables the auto-connection between ScanWedge and the serial port.	0	0=Disabled; ScanWedge opens the serial port immediately at startup and doesn't close until ScanWedge is closed. This is the recommended setting when the serial port is port 2 or 3. 1=Enabled; ScanWedge connects to the serial port when a power source is detected and disconnects when the power source is removed/not detected.
Port	Specifies the serial port to use to connect to ScanWedge. <i>Note: This setting is ignored for Port 4.</i>		The use of port 4/6 is not encouraged.
FlowControl	Specifies the flow control method to use—software only, hardware only, or software and hardware. <i>Note: This setting is ignored for Port 4.</i>	4	1=Software (Xon-Xoff) 2=Hardware 3=Hardware and software 4=No flow control
BaudRate	Specifies the baud rate for the serial port. <i>Note: This setting is ignored for Port 4.</i>	38400	X=The appropriate baud rate.
Parity	Specified the parity for the connection. <i>Note: This setting is ignored for Port 4.</i>	0	0=No parity 1=Odd parity 2=Even parity 3=Mark parity 4=Space parity
DataBits	Specifies the number of bits per byte to use. <i>Note: This setting is ignored for Port 4.</i>	8	X=Number of bits per byte
StopBits	Specified the number of stop bits to use. <i>Note: This setting is ignored for Port 4.</i>	0	0=1 stop bit 1=1.5 stop bits 2=2 stop bits

Comm Section

The serial port settings in the Comm section determine the interaction between ScanWedge and the serial port.

Comm Section Key	Description	Default Value	Available Values
Powerout	Enables and disables power out of the serial port for ScanWedge specifically. General power out settings are established in the registry. The serial port powers out 5V at 500mA.	0	0=Disabled; do not power out when scanning with ScanWedge 1=Enabled; power out when scanning with ScanWedge. 2=No change for ScanWedge. This means that ScanWedge is not altering the default power out setting in the registry. The terminal defaults to the power-out setting in the registry.
EnablePrefixData	Enables or disables all prefix data received via COM port after a successful scan. All prefix data is defined in the Settings Section (see page 5-3).	0	0=Disabled 1=Enabled
EnableSuffixData	Enables or disables all suffix data received via COM port after a successful scan. All suffix data is defined in the Settings Section (see page 5-3).	0	0=Disabled 1=Enabled

Decode Section

The Decode section specifies decoder settings when using the decoder with ScanWedge.

ScanWedge Entry	Description	Default Value	Available Values
Enable	Enables and disables the decoder for ScanWedge.	1	0=Disabled; decoder is not used. 1=Enabled; decoder sends bar code data as keystrokes to the active window.
Trigger	Sets the key used by ScanWedge to initiate a scan/decode. The key is registered as a system hotkey and cannot be registered as a hot key by any other applications.	42	42=OnScan or Scan key
ContScan	Enables and disables continuous scan.	0	0=Disabled; trigger key must be released between scans. 1=Enabled; data is continuously decoded and sent to the application while the trigger key is depressed.
PowerSave	Enables and disables power saving mode.	1	1=Enabled; the decoder automatically initializes and un-initializes as needed. A slight delay occurs when the trigger is activated. 0=Disabled; the decoder initializes when the utility starts and un-initializes when the utility terminates.
ScanTimeout	Specifies the decode time out in 1/1000th seconds. If a barcode is not decoded within the specified timeout an audio and visual notification indicates that an error occurred.	5000	X=Time in 1/1000th of a second.
ScanMode	Specifies the decode mode.	1	1=Full Omni/Normal 2=ALD (Aggressive Linear Decode) mode 4=Quick Omni
LinearRange	Specifies the linear search range to be used while in ALD mode.	3	X=Range from 1 to 6. 1 indicates a tight vertical range near the aimer. 6 indicates a vertical range of the entire height of the imager.


Decode Section

The Decode section specifies decoder settings when using the decoder with ScanWedge.

ScanWedge Entry	Description	Default Value	Available Values
AimerDuration	The number of milliseconds the scanner aimer is displayed, after the trigger key has been pressed down, before attempting to decode a barcode.	0 [Decode begins instantly.]	Enter times in 1/1000th of a second.
AimerDelay	The amount of time between scans before the aimer turns on again.	500	
AimerDurationALR	The amount of time the aimer stays on. This setting is for an ALR decoder.	2000	
AimerDelayALR	The amount of time between scans before the aimer turns on again. This setting is for an ALR decoder.	500	
DefaultEnabledSymbologies	Specifies which symbologies should be enabled before processing the Symbologies section. See Symbologies Section on page 5-17 .	0	0=Use internal list 1=All symbologies are disabled initially. Enable specific symbologies in the Symbologies section. 2=All symbologies are enabled initially. Disable specific symbologies in the Symbologies section.
EnablePrefixData	Enables or disables all prefix data received from the decoder after a successful scan. All prefix data is defined in the Settings Section (see page 5-3).	1	0=Disabled 1=Enabled
EnableSuffixData	Enables or disables all suffix data received via decoder after a successful scan. All suffix data is defined in the Settings Section (see page 5-3).	1	0=Disabled 1=Enabled

Decode Section

The Decode section specifies decoder settings when using the decoder with ScanWedge.

ScanWedge Entry	Description	Default Value	Available Values
GoodScanFreq	Sound frequency used for play a custom good scan beep. <i>Note: The Window's "Good Decode" sound (if defined in the control panel) takes precedence over this option.</i>	2749	Variable Use the up and down arrows to change the number  OR Type in the code for the sound you want.
GoodScanLen	Number of milliseconds to play the sound as specified in GoodScanFreq key.	50	
BadScanFreq	Sound frequency used for play a custom bad scan beep. <i>Note: The Window's "Bad Decode" sound (if defined in the control panel) takes precedence over this option.</i>	523	
BadScanLen	Number of milliseconds to play the sound as specified in BadScanFreq key.	25	

Centering Section

The Centering section determines the centering window for bar code scanning.

ScanWedge Entry	Description	Default Value	Available Values
CenteringEnable=	Enable and disables the decode centering window for the decoder.	0	0=Disabled; centering is disabled for ScanWedge. 1=Enabled; bar codes are decoded only if they are within the centering window specified by the rest of the keys in this section.
CenteringTop=	Specifies the top coordinate of the centering window.	210	Enter the coordinates in pixels.
CenteringBottom=	Specifies the bottom coordinate of the centering window.	270	
CenteringLeft=	Specifies the left coordinate of the centering window.	346	
CenteringRight=	Specifies the right coordinate of the centering window.	406	

Formatting Section

ScanWedge supports data formatting.

The Formatting section contains subsections and each subsection supports one data format.

Formatting Subsections

Subsection Key	Description	Default Value	Available Values
Format	Specifies data formatting parameters	Empty	See Available Data Formatting Commands on page 5-13 .
CodeID	Identifies the Code ID that the bar code's symbology must have for the format to be applied. The Code ID is a single character that is case-sensitive; e.g., set CodeID=j to apply the format to Code 128 only.	Empty	Empty=No Code ID X=See Code ID on page 5-14 .
Length	Determines the length the bar code data must have for the format to be applied.	Empty	Empty=Format applies to any length 0=Format applies to any length X=The length

Available Data Formatting Commands

These are the data formatting operations applied to the bar code data. The entire command string is entered into the Format key.

Command	Description
Send Commands	
F1xx	Send all characters followed by "xx" key or function code, starting from current cursor position.
F2nxxx	Send "nn" characters followed by "xx" key or function code, starting from current cursor position.
F3ssxx	Send up to but not including "ss" character (Search and Send) starting from current cursor position, leaving cursor pointing to "ss" character followed by "xx" key or function code.
F4xxnn	Send "xx" character "nn" times (Insert) leaving cursor in current cursor position.
E9nn	Send all but the last "nn" characters, starting from the current cursor position.
Move Commands	
F5nn	Move the cursor ahead "nn" characters from current cursor position.
F6nn	Move the cursor back "nn" characters from current cursor position.
F7	Move the cursor to the beginning of the data string.
EA	Move the cursor to the end of the data string.
Search Commands	
F8xx	Search ahead for "xx" character from current cursor position, leaving cursor pointing to "xx" character.
F9xx	Search back for "xx" character from current cursor position, leaving cursor pointing to "xx" character.
E6xx	Search ahead for the first non "xx" character from the current cursor position, leaving cursor pointing to non "xx" character.
E7xx	Search back for the first non "xx" character from the current cursor position, leaving cursor pointing to non "xx" character.
Miscellaneous Commands	
FExx	Compare character in current cursor position to the character "xx." If characters are equal, increment cursor. If characters are not equal, no format match.
EC	Check to make sure there is an ASCII number at the current cursor position. If character is not numeric, format is aborted.

Available Data Formatting Commands

These are the data formatting operations applied to the bar code data. The entire command string is entered into the Format key.

Command	Description
ED	Check to make sure there is a non-numeric ASCII character at the current cursor position. If character is numeric, format is aborted.
FBnnxyy...zz	Suppress all occurrences of up to 15 different characters, starting at the current cursor position, as the cursor is advanced by other commands. When the FC command is encountered, the suppress function is terminated. The cursor is not moved by the FB command. nn is a count of the number of suppressed characters in the list and xyy...zz is the list of characters to be suppressed.
FC	Disables suppress filter and clear all suppressed characters.
E4nnxx1xx2yy1yy2...zz1zz2	Replaces up to 15 characters in the data string with user specified characters. Replacement continues until the E5 command is encountered. nn is the total count of both characters to be replaced plus replacement characters; xx1 defines characters to be replaced and xx2 defines replacement characters, continuing through zz1 and zz2.
E5	Terminates character replacement.

Note: xx and ss stand for hex values of a character (00-FF), nn for a numeric count (00-99).

Code ID

Symbology Name	Code ID
Australian Post	A (0x41)
Aztec Code	z (0x7A)
Aztec Mesa Code	Z (0x5A)
British Post	B (0x42)
Canadian Post	C (0x43)
China Post	Q (0x51)
Codabar	a (0x61)
Codablock F	q (0x71)
Code 11	h (0x68)
Code 128	j (0x6A)
Code 16K	o (0x6F)
Code 32 Pharmaceutical (PARAF)	< (0x3C)

Code ID

Symbology Name	Code ID
Code 39	b (0x62)
Code 49	l (0x6C)
Code 93 and 93i	i (0x69)
Coupon Code	c (0x63)
Data Matrix	w (0x77)
EAN-UCC Composite	y (0x79)
UCC / EAN-128	l (0x49)
EAN-13	d (0x64)
EAN-8	D (0x44)
Interleaved 2 of 5	e (0x65)
ISBT	j (0x6A)
Japanese Post	J (0x4A)
KIX (Netherlands) Post	K (0x4B)
Korea Post	? (0x3F)
Matrix 2 of 5	m (0x6D)
MaxiCode	x (0x78)
MicroPDF417	R (0x52)
MSI	g (0x67)
OCR US Money Font, MICR (E 13 B) and SEMI Font	O (0x4F)
OCR-A	O (0x4F)
OCR-B	O (0x4F)
PDF417	r (0x72)
Planet Code	L (0x4C)
Plessey Code	n (0x6E)

Code ID

Symbology Name	Code ID
PosiCode	W (0x57)
Postnet	P (0x50)
QR Code	s (0x73)
Reduced Space Symbology (RSS-14,RSS Limited, RSS Expanded)	y (0x79)
Straight 2 of 5 IATA (two-bar start/ stop)	f (0x66)
Straight 2 of 5 Industrial (three-bar start/stop)	f (0x66)
TCIF Linked Code 39 (TLC39)	T (0x54)
Telepen	t (0x74)
Trioptic Code	= (0x3D)
UCC/EAN-128	I (0x49)
UPC-A	c (0x63)
UPC-E0	E (0x45)
UPC-E1	E (0x45)

Symbologies Section

The Symbologies section specifies the settings for each of the symbologies supported by the decoder.

The settings are in the form:

Symbology Name=Enable(1 or 0), Parm1, Parm2, Parm3, Parm4, Parm5, Parm6, Parm7, Parm8

Where

- Enable specifies that the symbology is enabled or disabled.
- Parm1–8 specify the settings for the symbology.

For more information regarding the individual settings for each of the symbologies, refer to the Honeywell Decode API documentation in the SDK documentation.

Symbologies Settings

0=Disabled 1=Enabled

ScanWedge Entry	Default Enabled/ Disabled Value	Default Value
Australian Post	0=Disabled	0,0,0,0,0,0,0,0,0
Aztec Code	1=Enabled	1,1,3750,0,0,0,0,0,0
Aztec Mesas	0=Disabled	0,0,0,0,0,0,0,0,0
British Post	0=Disabled	0,0,0,0,0,0,0,0,0
Canadian Post	0=Disabled	0,0,0,0,0,0,0,0,0
China Post	0=Disabled	0,4,80,0,0,0,0,0,0
Codabar	1=Enabled	1,0,0,0,4,60,0,0,0
Codablock	0=Disabled	0,1,2048,0,0,0,0,0,0
Code 11	0=Disabled	0,1,4,80,0,0,0,0,0
Code 128/EAN 128	1=Enabled	1,0,80,0,0,0,0,0,0
Code 16K	0=Disabled	0,1,160,0,0,0,0,0,0
Code 32	0=Disabled	0,0,0,0,0,0,0,0,0
Code 39	1=Enabled	1,0,0,0,0,0,0,48,0
Code 49	0=Disabled	0,1,81,0,0,0,0,0,0
Code 93	0=Disabled	0,0,80,0,0,0,0,0,0

Symbologies Settings

0=Disabled 1=Enabled

ScanWedge Entry	Default Enabled/ Disabled Value	Default Value
Coupon Code	0=Disabled	0,0,0,0,0,0,0,0,0
Data Matrix	0=Disabled	0,1,1500,0,0,0,0,0,0
Dutch Post	0=Disabled	0,0,0,0,0,0,0,0,0
EAN-8	0=Disabled	0,1,0,0,0,1,0,0,0
EAN-13	1=Enabled	1,1,0,0,0,1,0,0,0
EAN.UCC Composites	0=Disabled	0,1,300,0,0,0,0,0,0
Interleaved 2 of 5	1=Enabled	1,0,0,4,80,0,0,0,0
ISBT	0=Disabled	0,0,0,0,0,0,0,0,0
Japanense Post	0=Disabled	0,0,0,0,0,0,0,0,0
Korea Post	0=Disabled	0,4,48,0,0,0,0,0,0
Matrix 2 of 5	0=Disabled	0,4,80,0,0,0,0,0,0
MaxiCode	0=Disabled	0,0,1,150,0,0,0,0,0
MicroPDF417	1=Enabled	1,1,366,0,0,0,0,0,0
MSI	0=Disabled	0,4,48,0,0,0,0,0,0
OCR	0=Disabled	0,2,ddddddd,,,,0
PDF417	1=Enabled	1,1,2750,0,0,0,0,0,0
Planet Code	0=Disabled	0,0,0,0,0,0,0,0,0
Plessey	0=Disabled	0,4,48,0,0,0,0,0,0
PosiCode	0=Disabled	0,4,48,2,0,0,0,0,0
Postnet	0=Disabled	0,0,0,0,0,0,0,0,0
QR Code	0=Disabled	0,1,3500,0,0,0,0,0,0
Reduced Space Symbology (RSS)	0=Disabled	0,4,74,0,0,0,0,0,0

Symbologies Settings

0=Disabled 1=Enabled

ScanWedge Entry	Default Enabled/ Disabled Value	Default Value
Straight 2 of 5 IATA	0=Disabled	0,4,48,0,0,0,0,0,0
Straight 2 of 5 Industrial	0=Disabled	0,4,48,0,0,0,0,0,0
TCIF Linked Code 39 (TLC39)	0=Disabled	0,0,0,0,0,0,0,0,0
Telepen	0=Disabled	0,1,60,0,0,0,0,0,0
Trioptic Code	0=Disabled	0,0,0,0,0,0,0,0,0
UPC-A	1=Enabled	1,1,1,0,0,0,1,0,0
UPC-E0	0=Disabled	0,1,1,0,0,0,0,1,0
UPC-E1	0=Disabled	0,1,1,0,0,0,0,1,0

VK (Virtual Key) Mapping Section

The virtual key map settings are located in the VKMapping section in the ScanWedge configuration file. The virtual key map settings define the virtual key that will be sent to ScanWedge for any decoded ASCII character.

The settings are in the form: **ASCII Key = Virtual Key, ShiftMode**

Where

- ASCII Key is an ASCII value between 0 and 255 (decimal)
- Virtual Key is the virtual key to be sent when the specified ASCII key is decoded
- ShiftMode can have the following values:
 - 0=the virtual key is never shifted
 - 1=the virtual key must be shifted
 - 2=the virtual key needs to be shifted if Caps Lock is off
 - 3=the virtual key needs to be shifted if Caps Lock is on

For detailed information about the values in this section, see [Virtual Key Codes Table](#) on page 5-21.

Virtual Key Codes Table

The following table shows the symbolic constant names, hexadecimal values, and keyboard equivalents for the virtual-key codes used by Microsoft Windows Mobile 6.0. The codes are listed in numeric order.

Note: To use these codes in the VKMapping section, the hexadecimal values need to be converted to decimals.

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_LBUTTON	1	01	Touch screen
VK_CANCEL	3	03	Control-break processing
—	5-7	05-07	Undefined
VK_BACK	8	08	BACKSPACE key
VK_TAB	9	09	TAB key
—	10-11	0A-0B	Undefined
VK_CLEAR	12	0C	CLEAR key
VK_RETURN	13	0D	ENTER key
—	14-15	0E-0F	Undefined
VK_SHIFT	16	10	SHIFT key
VK_CONTROL	17	11	CTRL key
VK_MENU	18	12	ALT key
VK_CAPITAL	20	14	CAPS LOCK key
—	21-25	15-19	Reserved for Kanji systems
—	26	1A	Undefined
VK_CLEAR	12	0C	CLEAR key
VK_RETURN	13	0D	ENTER key
—	14-15	0E-0F	Undefined
VK_SHIFT	16	10	SHIFT key
VK_CONTROL	17	11	CTRL key

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_MENU	18	12	ALT key
VK_CAPITAL	20	14	CAPS LOCK key
—	21-25	15-19	Reserved for Kanji systems
—	26	1A	Undefined
VK_ESCAPE	27	1B	ESC key
—	28-31	1C-1F	Reserved for Kanji systems
VK_SPACE	32	20	SPACEBAR key
VK_PRIOR	33	21	PAGE UP key
VK_NEXT	34	22	PAGE DOWN key
VK_END	35	23	END key
VK_HOME	36	24	HOME key
VK_LEFT	37	25	LEFT ARROW key
VK_UP	38	26	UP ARROW key
VK_RIGHT	39	27	RIGHT ARROW key
VK_DOWN	40	28	DOWN ARROW key
VK_SELECT	41	29	SELECT key
—	42	2A	Original equipment manufacturer (OEM)– specific
VK_EXECUTE	43	2B	EXECUTE key
VK_SNAPSHOT	44	2C	PRINT SCREEN key for Windows 3.0 and later
VK_HELP	47	2F	HELP key
VK_0	48	30	0 key
VK_1	49	31	1 key
VK_2	50	32	2 key

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_3	51	33	3 key
VK_4	52	34	4 key
VK_5	53	35	5 key
VK_6	54	36	6 key
VK_7	55	37	7 key
VK_8	56	38	8 key
VK_9	57	39	9 key
—	58-64	3A-40	Undefined
VK_A	65	41	A key
VK_B	66	42	B key
VK_C	67	43	C key
VK_D	68	44	D key
VK_E	69	45	E key
VK_F	70	46	F key
VK_G	71	47	G key
VK_H	72	48	H key
VK_I	73	49	I key
VK_J	74	4A	J key
VK_K	75	4B	K key
VK_L	76	4C	L key
VK_M	77	4D	M key
VK_N	78	4E	N key
VK_O	79	4F	O key
VK_P	80	50	P key

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_Q	81	51	Q key
VK_R	82	52	R key
VK_S	83	53	S key
VK_T	84	54	T key
VK_U	85	55	U key
VK_V	86	56	V key
VK_W	87	57	W key
VK_X	88	58	X key
VK_Y	89	59	Y key
VK_Z	90	5A	Z key
—	91-95	5B-5F	Undefined
VK_NUMPAD0	96	60	Numeric keypad 0 key
VK_NUMPAD1	97	61	Numeric keypad 1 key
VK_NUMPAD2	98	62	Numeric keypad 2 key
VK_NUMPAD3	99	63	Numeric keypad 3 key
VK_NUMPAD4	100	64	Numeric keypad 4 key
VK_NUMPAD5	101	65	Numeric keypad 5 key
VK_NUMPAD6	102	66	Numeric keypad 6 key
VK_NUMPAD7	103	67	Numeric keypad 7 key
VK_NUMPAD8	104	68	Numeric keypad 8 key
VK_NUMPAD9	105	69	Numeric keypad 9 key
VK_MULTIPLY	106	6A	Asterisk (*) key
VK_ADD	107	6B	Plus sign (+) key
VK_SEPARATOR	108	6C	Separator key

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_SUBTRACT	109	6D	Minus sign (–) key
VK_DECIMAL	110	6E	Period (.) key
VK_DIVIDE	111	6F	Slash mark (/) key
—	88	88-8F	Unassigned
—	146-185	92-B9	Unassigned
—	186-192	BA-C0	OEM-specific
—	193-218	C1-DA	Unassigned
—	219-228	DB-E4	OEM-specific
—	229	E5	Unassigned
—	230	E6	OEM-specific
—	231-232	E7-E8	Unassigned
—	233-245	E9-F5	OEM-specific
VK_ATTN	246	F6	
VK_CRSEL	247	F7	
VK_EXSEL	248	F8	
VK_EREOF	249	F9	
VK_PLAY	250	FA	
VK_ZOOM	251	FB	
VK_NONAME	252	FC	
VK_PA1	253	FD	
VK_EM_CLEAR	254	FE	
VK_LWIN	91	5B	
VK_RWIN	92	5C	
VK_APPS	93	5D	

Virtual Key Codes Table

Symbolic Constant Name	Decimal Value	Hexadecimal Value	Touch Screen or Keyboard Equivalent
VK_LSHIFT	160	A0	
VK_RSHIFT	161	A1	
VK_LCONTROL	162	A2	
VK_RCONTROL	163	A3	
VK_LMENU	164	A4	
VK_RMENU	165	A5	









Command Line Arguments

- /restart*** Forces ScanWedge to process its configuration file (Scanwedge.exm) again, which applies changes immediately. If the [SoundConnect](#) (see page 5-4) is set to 1 (enabled), an ascending connect sound is played on restart.
- /quit*** Shuts down ScanWedge.

Additional Power Tools


Overview

This chapter describes the following Power Tools:


Power Tool	Icon	See Page
BattMon	 BattMon	6-2
InstallerCE	No icon	6-4
Hotkeys	 HotKeys	6-5
Keyboard Status	 Keyboard Status	6-7
NoSIP	 NoSIP	6-9
RASMan	 RASMan	6-10
Reboot	 Reboot	6-13
Suspend	 Suspend	6-14
SysInfo	 SysInfo	6-15

BattMon

BattMon programs the terminal's LEDs to monitor the charge status of the battery. The LEDs are located on the top, front panel of Dolphin terminals.



To Enable BattMon

1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.
2. Tap the **BattMon** icon **once** . After activation, BattMon monitors the battery's charge status.

When the battery is at 100%, the green LED lights solid green.
When the battery is charging the green LED flashes.

Note: To start BattMon automatically after each hard reset, enable the BattMon Program section of the [Autorun.exm File](#) (see page 4-1).

To Disable BattMon


Navigate to the [Power Tools Main Window](#) (see page 1-2) and tap the **BattMon** icon again.

OR

Select **Exit** on the [Command Bar Menu](#) (page 6-2).

Command Bar Menu

When BattMon is enabled, a smaller BattMon icon appears in the Command bar at the bottom of the Today screen.



Tap this icon to open the Command bar menu:

Menu Item	This item ...
Status	Displays the battery charge status in percentage.
Enable	Enables and disables BattMon without exiting BattMon.
About	Provides version and copyright information for BattMon.
Exit	Closes BattMon. The icon no longer appears in the Command bar.

Command Line Arguments

/quit Shut down BattMon.
/noicon Run BattMon with no icon.
/nosplash Hide the BattMon splash screen.


To Check Battery Power Manually

You can,

Tap the **BattMon** icon in the Command bar on the Today screen. The [Status](#) (page 6-2) menu item displays the charge percentage.

OR

Tap **Start > Settings > System** tab > **Power**. The Power window opens displaying the current charge status of the terminal's batteries.



InstallerCE

InstallerCE is a utility that saves CAB files after a manual install initiated by double-tapping on the CAB. Normally, when you install a program by double-tapping on its CAB, the CAB file is deleted after installation is complete. InstallerCE preserves the original CAB file in its original location.

Location InstallerCE is located in the `\Program Files\Power Tools` folder.


To Manually Install a CAB File

1. On the Dolphin terminal, open **File Explorer**.
2. Navigate to the `\IPSM\AutoInstall` folder.
3. Double-tap on a CAB file. The program begins installing.
4. If the program is already installed, the system will ask you if you want to re-install it. Click **Yes**.
5. After installation is complete, notice that the CAB file remains in the AutoInstall folder.

HotKeys

The HotKeys Power Tool activates the hardware button assignments in the Buttons setting. To start HotKeys automatically after each hard reset, enable the HotKeys Program section of the [Autorun.exm File](#) (see page 4-1).


To Enable HotKeys

1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.
2. Tap the HotKeys icon **once**  HotKeys. HotKeys is enabled and the button assignments in the Buttons setting are active.
3. Verify the assignment by tapping the button on the keyboard. To see button assignments, see [Buttons Setting](#) on page 6-5.

Buttons Setting

The Buttons System setting programs hardware buttons to launch applications or execute commands. To see the hardware button assignments that HotKeys activates, open the Buttons setting.

1. After HotKeys is enabled, tap **Start > Settings > Personal tab > Buttons**.



Note: The buttons that appear on this window are the only buttons that can be programmed in the Buttons setting. You cannot add hardware buttons to this window.

2. To change button assignment, tap on the name of the application in the **Assignment** column and select a program or command in the **Assign a program** drop down list.
3. Tap **OK** to save.

To Disable HotKeys


Navigate to the [Power Tools Main Window](#) (see page 1-2) and tap the **HotKeys** icon again.

OR

Select **Exit** on the [Command Bar Menu](#) (page 6-6).

Command Bar Menu

When HotKeys is enabled, a small HotKeys icon appears in the Command bar at the bottom of the screen.



Tap this icon to open the Command bar menu for HotKeys:

Menu Item	Selecting this item ...
Settings	Opens the Buttons setting.
Enable	Enables and disables HotKeys
About	Displays version and description information for HotKeys.
Exit	Closes HotKeys. The icon no longer appears in the Command bar.

Command Line Arguments

- /quit** Shut down HotKeys.
- /noicon** Run HotKeys with no icon.
- /nosplash** Hide the HotKeys splash screen.

Keyboard Status

Keyboard Status indicates whether the keyboard is in alpha, caps lock alpha, or numeric modes.

Each Dolphin terminal series has keyboards that switch between alpha and numeric modes, often by way of a keyboard combination. Keyboard Status displays an alpha-numeric indicator in the Navigation bar that tells you if the keyboard is in alpha or numeric mode so that you don't have to test type in your application to find out.

Navigation Bar Indicator



Indicator	Keyboard is in ...
	Alpha mode, lower case (CAPS lock off).
	Alpha mode, upper case (CAPS lock on).
	Numeric mode.

Keyboard Status is enabled automatically after each hard reset by default. This setting is programmed [Aurun.exm File](#) (see page 4-1).

Keyboard Status Menu


When Keyboard Status is enabled, the indicator icon appears in the Command bar at the bottom of the screen.




Tap this icon to open the Keyboard Status menu for:

Menu Item	Selecting this item ...
About	Displays version and description information for Keyboard Status.
Settings	Opens the Sounds & Notifications setting.
Enable	Enables and disables Keyboard Status.
Exit	Closes Keyboard Status. The icon no longer appears in the Command bar.

Notification Menu



When Keyboard Status is enabled, a Notification menu appears in the command bar on the Today screen that displays the keyboard status when tapped.



Note: You can also tap the icon in the Navigation bar to make this pop-up window appear.

Tap **Hide** to remove the keyboard status icon from the navigation bar. (The Keyboard Status Power Tool will continue to run in the background, and appear in the task tray on the Today screen.) The next time you switch keyboard modes

Tap **Dismiss** to remove the notification menu from the command bar. (If the terminal uses the phone, then the Phone menu appears in the command bar instead.)

Accessing the Keyboard Status Power Tool

Keyboard Status is enabled after each hard reset by default.


1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.

2. Tap the **Keyboard Status** icon **once**  and Keyboard Status is enabled. To disable Keyboard Status again.

Command Line Arguments


/debug	Log debug output to <code>\IPSMkeyboardstatus.log</code>
/quit	Shut down Keyboard Status.
/noicon	Run Keyboard Status with no icon.
/nosplash	Hide the Keyboard Status splash screen.

NoSIP

NoSIP toggles the Soft Input Panel (SIP) between enabled and disabled. When disabled, the SIP does not pop up over application windows automatically. In addition, the SIP icon  does not appear in the Command bar on application windows.

To Enable NoSIP

1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.

2. Tap the NoSIP icon  **once** NoSIP. The SIP should not pop up on application screens.

Note: To disable the SIP automatically after each hard reset, enable the NoSIP Program section of the [Autorun.exm File](#) (see page 4-1).

To Disable NoSIP

Navigate to the [Power Tools Main Window](#) (see page 1-2) and tap the **NoSIP** icon again.


OR

Select **Exit** on the [Command Bar Menu](#) (page 6-9).

Command Bar Menu

When NoSIP is enabled, a smaller NoSIP icon appears in the Command bar at the bottom of the Today

screen . Tap this icon to open the Command bar menu: .

Menu Item	Selecting this item ...
Enable SIP	Enables the SIP without stopping NoSIP. When this item is selected, the indicator in the Command bar changes to  to indicate that the SIP is now active, even though the NoSIP is still running.
About	Displays version and description information for NoSIP.
Exit	Disables NoSIP; the icon no longer appears in the Command bar.

Command Line Arguments


/noicon Run NoSIP with no icon
/nosound Turn off the sound
/nohotkey Disable the NoSIP hotkey
/enable Enable the SIP
/disable Disable the SIP

RASMan

RASMan establishes a PPP (Point-to-Point Protocol) connection with a RAS server.

To Enable RASMan

1. Tap **Start > Power Tools**. The **Power Tools Main Window** (see page 1-2) appears.

2. Click the RASMan icon **once** . The PPP connection is established according to the settings in the **RASMan Configuration File** (see page 6-11).

*Note: To start RASMan automatically after each hard reset, enable the RASMan Program section of the **Autorun.exm File** (see page 4-1).*


To Disable RASMan


Navigate to the **Power Tools Main Window** (see page 1-2) and tap the **RASMan** icon again.

OR

Select **Exit** on the **Command Bar Menu** (page 6-10).

Command Bar Menu

When RASMan is enabled, the RASMan icon appears in the Command bar at the bottom of the Today screen . Tap this icon to open the Command bar menu.



Menu Item	Selecting this item ...
Auto Connect	This item is selected by default; it means that the terminal is connected to the RAS server via PPP.
Connect	Re-establishes the PPP connection if it was disconnected.
Disconnect	Disconnects the PPP connection.
About	Displays version and description information about RASMan.
Exit	Disables RASMan; the icon no longer appears in the Command bar.

RASMan Configuration File

RASMan application settings are stored in the Settings section of `\IPSM\RASMan.exm`. Use [EZConfig Editor](#) (see page 2-2) to change the values in the RASMan.exm file.

Key	Description	Default Value	Available Values
AudioNotification	Enable and disable audio notifications on connecting and disconnecting.	1	0=Disable 1=Enable
AutoConnectOnDock	Connects and disconnects RASMan when the terminal is docked and removed from the communication peripheral.	1	0=Disabled; RASMan connection must be launched manually when the terminal is docked. 1=RASMan connects on an AC power event. 2=RASMan connects on RS-232/USB connection.
AutoConnectOnStartup	Controls the automatic connection when RASMan is started. <i>Note: RASMan attempts to connect only if the device is docked and AC power is detected.</i>	1	0=Disabled; the PPP connection is not established when RASMan is started. 1=Enabled; the PPP connection is established when RASMAN is started.
Connectoid	Indicates the connection RASMan should use.	`USB Connection	`USB Connection `115200 Default `19200 Default `38400 Default `57600 Default <i>Note: These values must be typed in exactly as they appear here.</i>
CommandLine	Command to execute on a successful connection.	Empty	Leave empty if no action is required.
CommandArgs	Command arguments for the CommandLine setting.	Empty	Leave empty if no action is required.
ConnectDelay	Specifies the amount of time to wait before establishing the PPP connection after RASMan is started.	2000	Enter values in milliseconds.
Debug	Enables and disables the creation of a debug log file.	0	0=Disabled; no log file 1=Enabled; Creates a log file of RASMan activity in the <code>\IPSM</code> folder.
DisableActiveSync	Disables the ActiveSync connection when RASMan is running.	1	0=Disabled; ActiveSync runs while RASMan is running. 1=Enabled; the ActiveSync connection is disabled while RASMan is running.

RASMan Configuration File

RASMan application settings are stored in the Settings section of `\IPSM\RASMan.exm`. Use [EZConfig Editor](#) (see page 2-2) to change the values in the RASMan.exm file.

Key	Description	Default Value	Available Values
Retry	Specifies the retry count.	10	
RetryDelay	Specifies the retry delay.	1000	Enter values in milliseconds.
ShowError	Enables and disables error messages on connecting.	1	0=Disable 1=Enable
ShowStatus	Enables and disables the appearance of status dialog boxes.	1	0=Disabled; status dialogs do not appear. 1=Enabled; status dialogs do appear.
StatusMessageDelay	Specifies a delay in milliseconds (i.e 1000 is 1 second) to apply after status and error messages are displayed.	25	X=Number of milliseconds.
StopOnCriticalError	Forces RASMan to stop running when a critical error occurs.	1	0=Disabled; RASMan continues to run when a critical error occurs. 1=Enabled; RASMan stops running when a critical error occurs.
TrayIcon	Enables or disables the RASMan tray icon.	1	0=Disable 1=Enable

Reboot

Reboot performs a warm or cold boot from the touch screen. All Dolphin terminals reboot with keyboard commands; Reboot offers you the option of using the touch screen instead.

Warm Boot

A warm boot is a soft reset. A soft reset re-boots the device without losing RAM data.

You would perform a soft reset when

- the terminal fails to respond.
- after installing software applications that require a re-boot.
- after making changes to certain system settings, such as network cards.

Cold Boot


A cold boot is a hard reset. A hard reset resets the operating system, restores the terminal back to factory defaults, and resets the terminal.

A hard reset erases all of the data stored in RAM memory and all RAM installed applications! Only data and applications stored in \IPSM memory persist.

Rebooting the Dolphin terminal

1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.

2. Tap the **Reboot** icon . The Reboot screen appears.



To perform a warm boot, tap the **Warm Boot** button.

To perform a cold boot, tap the **Cold Boot** button.

The Dolphin terminal begins booting immediately.

Command Line Arguments

`/r` Warm Reset

`/c` Cold Reset

Suspend

Suspend puts the terminal in Suspend mode. All Dolphin terminals have keyboard commands that put the terminal in Suspend mode; Suspend offers you the option of using the touch screen instead.

To Suspend the Dolphin Terminal

1. Tap **Start > Power Tools**. The [Power Tools Main Window](#) (see page 1-2) appears.

2. Tap the Suspend  once. The terminal goes into Suspend mode.


To Wake the Dolphin Terminal from Suspend Mode


Press the SCAN key.

SysInfo

SysInfo provides a read-out of important system information including firmware versions, DLL versions, system parameters, as well as network and radio information.

To See System Information

1. Tap **Start > Power Tools**. The **Power Tools Main Window** (see page 1-2) appears.
2. Tap the **SysInfo** icon once  SysInfo.
3. SysInfo queries the system, compiles the data and displays it on the SysInfo screen.



Name	Value
Hardware Revision	1
OS Version	WM50
Kernel	9.01 (Aug 25, ..
Service Pack	NONE
Boot Loader	9.01 (Aug 25, ..
Keyboard Firmware	9.01
Manufacture Date	20040720
Model Number	7900
Part Number	7900LOP-412-C2
Special Part Number	
Terminal Serial Num...	000032592
CPLD Version	31205342-005
Keyboard Type	25-key
Scanner Type	IT4300
Touch Panel Type	Installed


You **cannot** edit information in SysInfo. This information is gathered from the Dolphin terminal and changes only when the terminal's configuration has changed.

To refresh the system information, go to **File > Refresh**. The system re-compiles system information.

To Save the System Information to a Text File

Tap **File > Save to File**. A file named "SYSINFO.txt" is generated and saved to the **My Device** folder.


To open the file, tap **Start > Programs > File Explorer**. Navigate to the My Device folder. The SYSINFO.txt file appears in the list.



Name	Size
EZConfigMenu	14.2K
EZConfigPPC	99.0K
ImageDemo	2.95K
ImagingProfil...	6.26K
NetworkMenu	9.19K
PowerToolsM...	11.4K
PrintDemoMe...	8.34K
RASMan	3.34K
RegBackup	7.59K
RFSettings	1.76K
Scandemo	49.1K
ScanWedge	72.2K
SysInfo	6.01K

Viewing Options

If you tap on the SYSINFO.txt file in the My Device folder, the file opens in Pocket Word.



You cannot change system information by editing the text!

To Upload SYSINFO.txt to a Workstation

You can upload the SYSINFO.txt file to a workstation via ActiveSync.

1. On the workstation, open Windows Explorer.
2. Navigate to the **Mobile Device** folder.
3. Select **My Windows Mobile-Based Device**. The SYSINFO.txt file appears here.
4. Copy and paste this file to a folder on your workstation.

Sample SysInfo File

Field	Sample Data	This entry specifies the ...
SYSTEM DATE/TIME		
Date	1/14/2008	Date.
Time	10:38:36	Time.
SYSTEM INFO		
Sample Data		
This entry specifies the ...		
Hardware Revision	0	Hardware revision.
OS Version	WM60	Operating System version.
Kernel	22.06 (Dec 21, 2007)	Kernel version and date.
Service Pack	NONE	Service Pack level.
Boot Loader	0.00 ()	Bootloader version and date.
Keyboard Firmware	0.00	Keyboard firmware version.
Manufacture Date	20070711	Manufacture date.
Model Number	7600	Model number.
Part Number	7600EH-112-B4EE	Part number of the main board.
Special Part Number	7600EH-112-B4EE	Special part number, if any.
Terminal Serial Number	07193E0564	Terminal serial number.
CPLD Version	Unknown	CPLD firmware version.
Keyboard Type	29-key	Keyboard type.
Scanner Type	IT5300	Imager installed on the terminal.
Touch Panel Type	Installed	Touch panel type.
Display Type	Toppoly	Display type.
CPU INFO		
Sample Data		
This entry specifies the ...		
ProcessorName	S3C2440A	Name of the CPU
Architecture	ARM	Systems processor architecture.
ProcessorLevel	4	System's architecture-dependent processor level.
Processor Frequency	400 Mhz	System's processor operating frequency.
DLL VERSION INFO		
Sample Data		
This entry specifies the ...		
Decoder.dll	1.16.1.2	Current Decoder.dll api build revision.
Matrix Engine	4.84.1.11	Current Matrix engine build revision.
HHPScanInterface.dll	1.16	Current HHPScanInterface.dll api build revision.
Scan Driver	1.212.1.14	Current scan driver build revision.
HHPMT9V022HW.dll	1.00.02	Current HHPMT9V022HW.dll api build revision.

Sample SysInfo File

Field	Sample Data	This entry specifies the ...
ImgApi.dll	1.16	Current ImgApi.dll api build revision.
SYSTEM PARAMETERS	Sample Data	This entry specifies the ...
BatteryIdleTimeout	0	
ExternalIdleTimeout	0	
OEMInfo	Hand Held Products	Name of the OEM.
PlatformType	PocketPC	Type of operating system.
NETWORK INFO	Sample Data	This entry specifies the ...
Hostname	ID07193E0563	Terminal's ID (recognized by ActiveSync, for example)
NumberOfAdapters	2	Number of network adapters installed.
1: Mac Address	001641F81262	MAC and IP address of the on-board 802.11b/g radio. The 0.0.0.0 indicates that the 802.11b/g radio is using DHCP instead of a static IP address.
1: IP Address	0.0.0.0	
2: Mac Address	8200600FE800	MAC and IP address of the on-board Bluetooth radio.
2: IP Address	169.254.2.1	
RADIO INFO	Sample Data	This entry specifies the ...
Current Mode:	GSM/GPRS	On-board radio active when the SysInfo icon was pressed.
Bluetooth Hardware:	CSR	Bluetooth radio driver.
WiFi Hardware:	USI SPI	802.11b/g radio driver.
GSM Hardware:	Siemens MC-75	GSM radio driver.
IPSM/	Sample Data	
File(1)–File (XX):	AutoInstall.exe AutoInstall.exm Autorun.exe Autorun.exm DeviceConfig.exe DeviceConfig.exm EZConfigPPC.exe DemosMenu.exm EZConfigMenu.exm NetworkMenu.exm PowerToolsMenu.exm RASMan.exm ScanWedge.exm RegBackup.exm	These are the files in the \IPSM folder. They persist through cold boots.
IPSM/AutoInstall/	Sample Data	

Sample SysInfo File

Field	Sample Data	This entry specifies the ...
File(XX)–File(XX):	xDecoder.cab SDKRT_armv4i.cab Demos_armv4i.cab PowerTIs_armv4i.cab DefaultSettings.reg	These are the files in the \IPSM\AutoInstall folder. They persist through cold boots and install during AutoInstall.
POWER STATUS	Sample Data	This entry specifies the ...
ACLineStatus	AC online	AC power status.
BatteryFlag	High	Battery charge status.
BatteryLifePercent	100 %	Percentage of full battery charge remaining.
BackupBatteryFlag	High	Backup battery charge status.
BackupBatteryLifePercent	100 %	Percentage of full backup battery charge remaining.
STORE INFO	Sample Data	This entry specifies the ...
StoreSize	23711744	Size in bytes of the object store.
FreeSize	16615424	Amount of free space in bytes in the object store.
SYSTEM VERSION	Sample Data	This entry specifies the ...
MajorVersion	5	
MinorVersion	2	
BuildNumber	1944	
PlatformId	3	
CSDVersion		Latest Service Pack installed on the system.
GLOBAL MEMORY STATUS	Sample Data	This entry specifies the ...
MemoryLoad	24	Number between 0 and 100 that gives a general idea of current memory utilization. 0 = No memory use 100 = Full memory use
TotalPhysical	100204544	Total number of bytes of physical memory.
TotalPageFile	0	Number of bytes of physical memory available.
AvailPageFile	0	Total number of bytes that can be stored in the paging file.
TotalVirtual	33554432	Total number of bytes that can be described in the user mode portion of the virtual address space of the calling process.
AvailVirtual	30212096	Number of bytes of unreserved and uncommitted memory in the user mode portion of the virtual address space of the calling process.

Sample SysInfo File

Field	Sample Data	This entry specifies the ...
RAM INFO	Sample Data	This entry specifies the ...
Total Installed RAM	128 MB	Actual size of installed RAM chip.
Total User RAM	128 MB	Total RAM available for file system and program memory after kernel overhead.
Min File System Size	16 MB	Minimum sized allowed for the file system.
File System Size	23 MB	Current size of the file system.
Min Program Memory Size	64 MB	Minimum size allowed for program memory.
Program Memory Size	95 MB	Current size of the program memory.
Current Split %	18	Percentage of the Total User RAM allocated to the file system.
Valid Split % Range	12% - 50%	Valid % range that can be used when setting file system size. If set out of range value will be set to closest min or max.
IMAGER INFO	Sample Data	This entry specifies the ...
PSOC Version	2.3	Current PSOC revision.
AimerXoffset	448	Imager's AimerXoffset parameter.
AimerYoffset	239	Imager's AimerYoffset parameter.
BitsPerPixel	8	Imager's BitsPerPixel parameter.
EngineID	9	Imager's EngineID parameter.
ImagerCols	752	Imager's ImagerCols parameter.
ImagerRows	480	Imager's ImagerRows parameter.
Rotation	0	Imager's Rotation parameter.
YDepth	1	Imager's YDepth parameter.

Using the Battery Analyzer

Overview

The Battery Analyzer Power Tool helps you manage the battery power installed in the Dolphin 9700/9900 terminal.

Requirements

For the Battery Analyzer to work, you must have the following items installed on the Dolphin terminal in the following locations:

- The **BatteryAnalyzer.exe** is stored in the \Program Files\Power Tools folder.
- The **BatteryAnalyzer.exm** is stored in the \IPSM folder.
- The **Battalyzer.dll** is stored in the \Windows folder.

When all of these items are installed, the **Battery Analyzer** icon  appears on the [Power Tools Main Window](#) (see page 1-2).

Operating Temperature=0°—50°C

The operating temperature of the battery must be between 0°C and 50°C. If you attempt to analyze a battery when the operating temperature is outside this range, the analyze cycle stops. You will be notified that the analyze cycle was aborted due to temperatures below 0°C or above 50°C. If this happens, recharge the battery.

AC Power Supply

You must have a continuous supply of AC power to the terminal and installed battery prior to analyzing. If you attempt to analyze a battery and AC power is interrupted, the analyze process stops. You will be notified that the analyze cycle was aborted due to AC power interruptions. If this happens, recharge the battery.


Recommendation

Batteries should be analyzed only **once** every three months.

Analyzing a Battery

During the analyze cycle, the installed battery charges to 100%, then drains it to 0%, then charges it back up to 100%.

When the operating temperature of the battery is between 0°C and 50°C and there is a constant AC supply to the terminal and battery, tap **Start > Power Tools > Battery Analyzer**. The Battery Analyzer main window displays specific battery information for your review, including the operating temperature.



The status bar at the top of the window shows the progress of the analyze cycle.

The text box at the bottom of the window displays the details of the analyze cycle.

*Note: The **Charge Status** field indicates if the installed battery is charging or fully charged.*

The **Estimated Time** field displays the amount of time it will take to complete a full cycle.

Analyze Cycle Steps

There are three steps to the analyze cycle:

- Step 1:** The battery charges to 100%.
- Step 2:** The battery discharges to 0%.
- Step 3:** The battery re-charges to 100%.

Automatic Shut Down

The analyze cycle aborts if:

- The operating temperature drops below 0°C or above 50°C.
- AC power is lost.


The text box at the bottom of the window displays the details about why the process aborted.

Stopping an Analyze Cycle

You can stop the analyze cycle manually any time by tapping the **File** menu in the command bar. Tap **Stop Analyzing** or **Start Analyzing**.

Command Line Arguments

The following command line arguments can be used in the **CommandArgs** key of the Battery Analyzer section of the PowerToolsMenu.exm file.




- /a** Indicates “admin” and launches Battery Analyzer in [Advanced Mode](#) (see page 7-3).
- /d** Indicates “debug” and creates a log file that tracks the activity of Battery Analyzer from the moment the application is launched. The log file is: `\IPSM\BatteryAnalyzer.log`.
- /s** Indicates “autostart” and launches the analyze cycle the moment you launch Battery Analyzer from the main window.
- /q** Indicates “quit” and stops the analyze process if it’s running.

Advanced Mode

You run Battery Analyzer in advanced mode when you enter “/a” in the **CommandArgs** key of the Battery Analyzer section of the PowerToolsMenu.exm. The next time you open the Battery Analyzer Power Tool, it will be running in Advanced Mode.

When you do run the Battery Analyzer in advanced mode, additional fields appear on the Battery Analyzer window.



- Capacity** Displays the capacity of the installed battery.
- Log to File** Option to create a log file after the analyze cycle is complete.

Log File

The log file records data in the following order:

- Date
- Time
- Conditioning Flag
- Battery Temperature
- Battery Voltage
- Capacity Percentage
- Charge Percentage
- Charge State
- Charge Status
- Analyzing Start Time
- Elapsed Time
- Estimated Completion Time
- Formatted Estimated Completion Time
- Estimated Progress

The log file is stored as “BatteryAnalyzer.log” in the \IPSM folder. Open this file with Pocket Word.


Should the analyze cycle abort automatically for some reason, check the log file for details.

Registry Power Tools


Overview


The registry is the configuration database in all 32-bit versions of Windows that contains settings for the hardware and software, consisting of the SYSTEM.DAT and USER.DAT files. Many settings previously stored in the WIN.ini and SYSTEM.ini files in 16-bit Windows (Windows 3.x) are in the registry.

The RegEdit Power Tool enables you to edit the registry through an easy-to-use application window. You can also import and export specific registry keys.




Editing the Registry

1. On the [Power Tools Main Window](#) (see page 1-2), tap the RegEdit icon **once** . RegEdit opens to a split-pane window with a collapsible menu in top half.




This is the top level of the registry; it cannot be edited, copied, pasted, or renamed.

2. Click the + sign to expand the menu options.




3. RegEdit offers the following registry categories:
 - HKEY_CLASSES_ROOT
 - HKEY_CURRENT_USER
 - HKEY_LOCAL_MACHINE
4. Expand the appropriate menu by clicking on the + sign.

5. Drill-down to the appropriate registry entry. When you click on registry entry in the top half of the screen, the data appears in the lower half of the screen.




The two columns in the bottom half of the window show the Value Name and the Value Data of the selected entry.

6. Double-click on the **Value Name**. The Edit Value window pops up.



In the **Value Data** field, type the new value.



7. Press the ENT(ER) key or tap **OK**. The new data appears in the list.
8. After all your edits are complete, [Warm Boot](#) (see page 6-13) the terminal to save your changes to the registry.

Note: If you want your edits to persist through the next cold boot, run [RegBackup](#) after saving your changes; see [Backing Up the Registry](#) on page 8-6.


Menus

The menus on the RegEdit window offer you many editing options.

File Menu


The File menu allows you to create registry entries as well as import and export registry settings.





Menu Item	Description
New	Creates a new Key, String, or DWORD Value. 
Import	Imports a registry file; see Importing Registry Files on page 8-5.
Export	Exports the current registry; see Backing Up the Registry on page 8-6.
Exit	Closes RegEdit.

Edit Menu


The Edit menu helps you work with existing registry entries.



Menu Item	Description
Copy	Copies a selected item.
Paste	Pastes a copied item within RegEdit.

Menu Item	Description
Rename	Renames a registry entry.  Enter the new name and press the ENTER or OK key.
Delete	Deletes a selected registry entry.
Find	Searches for registry entries within a selected section. (Select an item in the top half of the window before tapping Edit > Find.)  Enter the search criteria and tap OK . RegEdit notifies you if the selected section contains data matching the entered criteria.
Find Next	Launches another search for the criteria entered in Find.

View Menu




These menu items shift focus between the **Keys Panel** and the **Values Panel**.

Importing Registry Files

The file must be loaded on the terminal and have a REG extension.


1. Tap **File > Import**. By default, the import function searches for REG files and displays the search results in the lower half of the window.



2. Tap once on the REG file and it loads automatically.

Exporting Specific Registry Settings

You can export specific registry settings. In RegEdit, navigate to the section you would like to export and select it.



Tap **File > Export** and select the parameters of the REG file that would contains these settings.

If you want these REG setting to load during AutoInstall, select **AutoInstall** in the **Folder** drop-down list and **IPSM** in the **Location** drop-down list.


Other Export Options


You can export

- The entire registry—see [Backing Up the Registry](#) on page 8-6.
- Radio settings—see [Backup Radio Settings](#) on page 9-12.

Backing Up the Registry

You can export the current registry by tapping the **RegBackup** icon on the **Power Tools Main Window**

(see page 1-2) . A `_RegBackup.reg` file containing the entire registry is created and stored in the `\IPSM\AutoInstall` folder.



Because this REG file is stored in the `\IPSM\AutoInstall` folder, AutoInstall will launch and install this REG file during the next cold boot.


Restoring the Registry

After you have backed up the registry, a `_RegBackup.reg` file of the entire registry is stored in the `\IPSM\AutoInstall` folder.

You have a number of options to restore the registry by loading the `_RegBackup.reg` file.

RegRestore

On the **Power Tools Main Window** (see page 1-2), tap the **RegRestore** icon .



Tap on the REG File:

Tapping on a REG file in any folder immediately tries to add the information in that file to the registry. A message appears asking if you want to add the information to the registry. Tap **Yes** to add the information.

Cold Boot

Because this REG file is stored in the `\IPSM\AutoInstall` folder, AutoInstall will launch and install this REG file during the next cold boot.

RegBackup.exm

The RegBackup.exm file is located in the \IPSM folder and determines the content of the _RegBackup.reg file.

The RegBackup.exm file does NOT contain registry settings! Only REG files contain registry settings.

Sections

TEMPLATE Section The _TEMPLATE_ section is a template of the basic registry sections. This section is not used when creating the _RegBackup.reg file. Use these subsections as a basis for modifications and additions to the file.

Backup Section When you backup the registry (see [Backing Up the Registry](#) on page 8-6), the include/exclude settings in this section indicate what content to backup.

This default section should never be removed as it contains default excludes specified by Honeywell. It can, however be added to. **Do NOT change the Mode** (page 8-8)!


SyChip & Philips Sections

When you backup radio settings (see [Backup Radio Settings](#) on page 9-12), the include/exclude settings in this section indicate what content to backup.

Modifying

Modifying the RegBackup.exm file allows you to include or exclude registry key sections and values during an export. Multiple subsections can be created below. All should be copied from the Template section which, itself, should not be modified.


To specify keys and values in the RegBackup.exm file, re-create the registry keys as sections and subsections in the tree structure just as they appear in the registry. The same rules that apply to copying directories apply here in that if you re-create a key from the registry, all the key's values and subkey's values will be copied unless there are values in the top-level key.



Only the key or value name is needed in the EXM file and not the associated value data. The EXM file is a structure used to define the backup file and not the actual registry data.

Mode and Kernel Check

In each Subsection root in the tree, there should be two key-value pairs: Mode and KernelCheck.



If these keys are not present, the defaults will be applied:

Mode=Exclude

KernelCheck=Enabled

Mode

The Mode key specifies export behavior of the values in the section.

1=Include Only the values that follow will be included.

0=Exclude Everything but the values that follow will be included.

KernelCheck

KernelCheck forces kernel version and service pack validation when a previously exported REG file is imported on a Dolphin terminal. This means that if you attempt to load a `_RegBackup.reg` file (during AutoInstall, for example), RegBackup.exe verifies that the REG file matches the kernel installed on the terminal. If yes, then the REG file loads. If not, you'll receive a warning message and the REG file will not load.

0=Disabled No kernel validation occurs on importing. In general (especially for radio settings), KernelCheck should be enabled. If the registry does not match the kernel, the terminal will not function properly.

1=Enabled Kernel validation occurs on importing.

Command Line Arguments

Argument	Description
/export <filename>	Export registry to <filename>. The <filename> part is optional. If no filename is entered, the file will default to \IPSM\AutoInstall_RegBackup.reg.
/import <filename>	Import <filename> to registry. The <filename> part is optional. If no filename is entered, the file will default to \IPSM\AutoInstall_RegBackup.reg.
/exm <filename>	Specify the non-default backup EXM file <filename>. Filenames with spaces must be wrapped in quotes. If omitted, the filename defaults to \IPSM\RegBackup.exm. This argument is only valid when used with /export.
/section <SectionName>	Specify the non-default section in the EXM file for exclude or include export, depending on the mode setting in that section. If omitted, this defaults to the Backup section of whatever EXM file is specified. This argument is only valid when used with /export.
/key <key>	Specify the top level of the registry key structure to export. This argument is not valid when using /export or /import.
/silent	Displays no dialogs.

Registry Edit Options in EZConfig

You can also use EZConfig Editor to create registry documents on the workstation, create a bar code, then use EZConfig Client to decode the bar code and update the registry on the terminal.


For more information, see

- [Registry Documents](#) on page 2-17
- [Creating Bar Codes](#) on page 2-21
- [EZConfig Client](#) on page 2-34

Accessing Network Utilities



Tap **Start > Power Tools > Network Utilities** . The Network Utilities window opens.



Standard Network Utilities

There are three Network Utilities that mirror DOS-prompt functions of your workstation:

- [IP Config](#) (see page 9-2)
- [Ping](#) (see page 9-4)
- [Route](#) (see page 9-6)

WiFi Status

WiFi Status helps you monitor the on-board 802.11b radio:

- [WiFi Status](#) (see page 9-10)

Radio Settings

There are two Power Tools on the Network Utilities window that enable you to backup and restore radio settings in the registry.


- [Backup Radio Settings](#) (page 9-12)
- [Restore Radio Settings](#) (page 9-12)

Note: WiFi Status and the Radio Settings Power Tools appear on this window only if an RF radio is installed in the terminal.

IP Config

IPConfig is a kernel utility that displays, releases, and renews IP parameters for on-board network


adapters. On the Network Menu window, click the **IPConfig** icon . The IPConfig screen opens displaying the Input tab.



Field	Description
Adapter	This drop-down list contains the network adapters currently installed in the Dolphin terminal. Every field and button on this screen pertains to the adapter selected in this drop-down list.
MAC Addr	Displays the MAC (Media Access Control) address of the selected Adapter. This is the serial number burned into the adapter that uniquely identifies it.
Subnet Mask	Displays the adapter's subnet mask. The subnet mask determines the subnet upon which the adapter resides.
Gateway	Displays the adapter's gateway information.
Release the IP address	Click this button to release the IP address.
Renew the IP address	Click this button to renew the IP address.
Display full configuration	Click this button to retrieve and review the full configuration of the terminal's IP setup. For more information, see Displaying the Terminal's IP Configuration (see page 9-3).

Displaying the Terminal's IP Configuration

On the Input tab, tap the **Display full configuration** button. The Dolphin terminal retrieves and displays the IP configuration for the entire terminal.



About Tab

The About tab displays information about this Power Tool.


Ping

Ping provides a GUI-based version of the traditional command line ping utility. Pinging sends out an echo request to a specific computer on the network. Use Ping to verify communication links or that a specific IP address is working.

Ping contains three tab windows: Input, Output, and About. On the Input tab, you enter and send packet information to a specified remote host and see the result on the Output tab.



On the Network Menu window, tap the **Ping** icon . The Pings screen opens to the Input tab.



Using the Input Tab

Note: You do not need to complete all the fields on the Ping window to successfully execute, just the Destination IP address.

Field	Description
Destination	Enter the IP address. This field is required.
Timeout (milliseconds)	Enter the timeout time in millisecond intervals; 1000 is the default.
Send buffer size	Indicate the buffer size for sending; 32 is the default.
Send count	Indicate the count for sending; 4 is the default. Check Infinite to make the send count infinite.
TTL	Short for Time To Live, this is the maximum amount of time a packet is allowed to travel through the network before it is discarded.
TOS	Enter the Type of Service (TOS); it should be eight bits broken into five subfields.
Rec route for count hops	Enter the number of hops to record in the IP header; 1–9. This field traces the route of the packets for each hop. The hop count is the number of network devices between the starting node and the destination node that an IP packet hits while traveling over a network. The number of hops is recorded in the IP header.


Using the Input Tab

Note: You do not need to complete all the fields on the Ping window to successfully execute, just the Destination IP address.

Field	Description
Timestamp route	Enter the number of timestamps to record for each hop; 1–4 The timestamp is the packet's arrival time at each hop.
Don't fragment	Check this box if you don't want the packet to fragment during routing.
DNS address required	Check this if you want the domain name server to be part of the route path.
Execute	Click Execute to send the ping. The Output tab displays the response.

Reading the Output Tab

After you enter the IP information on the Input tab and click **Execute**, the Output tab appears and begins displaying the ping results.



You can click the **Stop** button at any time to stop the ping. Any errors encountered display on the screen. When the Ping process is complete or if you stop the ping at any point, *****Ping Stopped***** displays.

About Tab

The About tab displays description and version information about Ping.


Route

Route is a kernel utility that allows the user to view and edit the rules that govern how packets destined for various subnets are routed. These rules tell the device which gateways on a given interface's subnet may be used to route packets to hosts on other subnets.

Route contains three tab windows: Input, Output, and About. You enter and execute the command on the Input tab and review the results on the Output tab.



On the Network Menu window, tap the Route icon **once**. The Route screen opens to the Input tab.



Using the Input Tab

Field	Description
Command	This drop-down list contains the available routing commands. Select from: <ul style="list-style-type: none">• PRINT - Prints the network routing tables to the Output tab; see page 9-6.• ADD - Adds a route; see page 9-7.• DELETE - Deletes a route with a specified destination; see page 9-8.• CLEAR - Clears routing tables of all gateway entries; see page 9-8.
Text under Command	The text describes each command. The content changes automatically when a command is selected from the Command drop-down list.
Execute	Click this button to execute the selected command. The Output tab displays the results.


Output tab

The Output tab displays the information that results from executing a command on the Input tab; it displays no information on its own. See the individual tasks below to see the Output tab for each command.

To Print Network Routing Tables

1. On the Input tab, select **PRINT** in the **Command** drop-down list.

- Click the **Execute** button. The Output tab appears displaying the network routing table.



The screenshot shows the 'Route' application window with the 'Output' tab selected. It displays a table of active routes with the following data:


Destination	Netmask
0.0.0.0	0.0.0.0
0.0.0.0	0.0.0.0
10.16.0.0	255.255.0.0
10.16.12.206	255.255.255.255
10.255.255.255	255.255.255.255
127.0.0.0	255.0.0.0
192.168.55.101	255.255.255.255
192.168.55.255	255.255.255.255
224.0.0.0	240.0.0.0

- This table displays Destination, Netmask, Gateway, Metric, and Interface columns. Scroll right to see all the columns.

To Add a Route

You can add a custom route with the Add command.

- On the Input tab, select **ADD** in the **Command** drop-down list. Fields appear on the Input tab.
- Specify the range of IP address to which this rule will apply using the **Destination** and **Netmask** fields. For example, the settings in the screenshot below specify an address range from 300.300.0.1 to 300.300.255.254.




The screenshot shows the 'Route' application window with the 'Input' tab selected. The 'Command' dropdown is set to 'ADD'. The following fields are filled in:

- Destination: 300.300.0.0
- Netmask: 255.255.0.0
- Gateway: 10.16.0.1
- Metric: (empty)
- Interface: (empty)

An 'Execute' button is visible at the bottom right of the form.

- Enter the **Gateway**.
- Enter the **Metric** (not required).
- Enter the **Interface** (not required).


-
6. Tap **Execute**. The system verifies your results and the Output tab lets you know if your entry was added successfully.




To Delete a Route

You can delete active routes.

1. On the Input tab, select **DELETE** from the Command drop-down list. The Destination field appears.




2. Enter the IP address in the **Destination** field.
3. Click the **Execute** button. The system processes the request and displays how many routes were deleted.



To Clear Gateway Entries

Executing this command clears routing tables of all gateway entries.


-
1. On the Input tab, select **CLEAR** in the Command drop-down list.
 2. Click the **Execute** button. The system processes your request and the number of entries deleted appears on the Output tab.



WiFi Status

The WiFi Status Power Tool displays information from the 802.11 adapter installed in the terminal and enables you to configure certain operating parameters.

Tap **Start > Power Tools > Network Utilities > WiFiStatus**  WiFiStatus .



Setup Tab


The Setup tab enables you to change specific parameters of the 802.11 adapter.

Field	Description
Adapter	Name of the radio module installed on the terminal.
Update inv	This is the update interval used to poll the 802.11 adapter for status information.
SSID	Displays the SSID value presently configured in the 802.11 adapter.
Power mode	Choose between the following power modes:
CAM	Continuous access mode (CAM); the device is always on.
Max PSP*	Maximum power saving; provides the greatest power savings for the 802.11 NIC radio.
Fast PSP*	Fast power saving mode; provides the best combination of network performance and power usage.
*PSP=Power Save Polling	
BSS Mode	Choose between the following modes: Automatic =Switches between Ad hoc and infrastructure modes as required. IBSS (Ad hoc) =Specifies independent basic service set (IBSS). Infrastructure (ESS) =Specifies infrastructure.
Enable & Disable	Tap these buttons to enable and disable the 802.11 radio

Field	Description
Apply	Tap this button to apply changes to the Update interval, SSID, Power mode, and BSS mode.

Status Tab


The Status tab displays statistics for the 802.11 radio.



The **Release IP** and **Renew IP** buttons enable you to release and renew the terminal's IP address.

BSSID Tab

When accessed, the BSSID tab causes the radio to scan for all APs in range and displays the results.




Backup Radio Settings

When the terminal's radios are configured, entries are made in the registry that contain those settings. However, those entries are removed during the next cold boot. Backup Radio Settings exports those radio settings into a RadioSettings.reg file and places it in the `\IPSM\AutoInstall` folder. By default, the settings in the RadioSettings.reg file will be added to the registry during the next cold boot and your radios will be configured automatically when the boot process is complete.



Backup
Radio ...

On the Network Utilities main window, tap the **Backup Radio Settings** icon. The RadioSettings.reg file is created and placed in the `\IPSM\AutoInstall` folder.

A screenshot of a Windows File Explorer window titled 'File Explorer' showing the contents of the 'AutoInstall' folder. The window has a blue title bar with standard Windows icons. The folder name 'AutoInstall' is shown in the address bar. The file list is as follows:

Name	Size	Modified
DefaultSettings	165B	1/5/05
Demos_320B...	173K	1/5/05
LeWM5220_OI	449K	1/1/05
ObWM5700_2I	179K	1/1/05
PowerTools_3...	528K	1/5/05
RadioSettings	2.95K	1/1/05
SbWM5700_2I	0.99M	1/1/05
SDKRT_105.w...	588K	1/5/05
SyWM5391Z_...	226K	1/1/05

The 'RadioSettings' file is highlighted with a red border.

Restore Radio Settings

You have a number of options to restore the registry by loading the RadioSettings.reg file.

Restore Radio Settings



RegRestore.

On the Network Utilities window, tap the **Restore Radio Settings** icon. A message appears asking if you want to load the RadioSettings.reg file. Tap **Yes** and RegEdit imports the radio registry entries to the current registry.

Tap on the REG File:

Tapping on a REG file in any folder immediately tries to add the information in that file to the registry. A message appears asking if you want to add the information to the registry. Tap **Yes** to add the information.

Cold Boot

Because this REG file is stored in the `\IPSM\AutoInstall` folder, AutoInstall will launch and install this REG file during the next cold boot.


Overview

EZMenu formats application windows to display and launch software programs on the terminal. For example, the [Power Tools Main Window](#) (see page 1-2) is managed by EZMenu.

EZMenu consists of


- Menu configuration files (i.e., EXM files that end in “*Menu.exm”) in the \IPSM folder that contain the settings for application windows.
- The EZMenu.exe in the \Program Files\Power Tools folder that applies those settings in the terminal. EZMenu.exe is launched during AutoInstall by default.

*Menu.exm Files



EXM files have an  icon.

EasyMenu.exe



Executables have an  icon.

Running Easy Menu

EZMenu runs when you access an application window that has a menu configuration file. EZMenu.exe calls that menu configuration file to format the window.

Default EZMenu Configuration Files

Dolphin terminals ship with a number of menu configuration files in the \IPSM folder:

- DemosMenu.exm** Programs the Demos main window (**Start > Demos**).
 - EZConfigMenu.exm** Programs the EZConfig Utilities window; see [EZConfig Editor on the Terminal](#) on page 2-30.
 - NetworkMenu.exm** Programs the Network Utilities window; see [Accessing Network Utilities](#) on page 9-1.
 - PrintDemoMenu.exm** Programs the Print Demo window (**Start > Demos > Print Demo**).
 - PowerToolsMenu.exm** Programs the Power Tools main window; see [Power Tools Main Window](#) on page 1-2.
- Default menu configuration files must be located in the \IPSM folder.

Sample Menu Configuration Files

Samples of these default menu configuration files install to the workstation in the following folder:

C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\EZConfig EXM Files.

Modifying Menu Configuration Files

Menu configuration files can be modified in EZConfig Editor on the workstation or the terminal, If modified on the workstation, the *Menu.exm file must be deployed to the terminal.

For details about modifying EXM files in EZConfig Editor:

- See [EZConfig Editor on page 2-2](#).
- See [EZConfig Editor on the Terminal on page 2-30](#).

Creating Menu Configuration Files

Save as the [Default EZMenu Configuration Files](#) (see page 10-1) to create new menu configuration files.

1. On the workstation, navigate to the following folder: **C:\Program Files\Honeywell\Power Tools and Demos for WM 6.0\EZConfig EXM Files**.
2. Open a sample menu configuration file in EZConfig Editor.
3. Tap **File > Save As** and save the file with a new name ending in “Menu.exm.”
4. Modify the file; to see the available values, see [Menu Configuration File Sections](#) on page 10-3.
5. Save or transfer the file to the **\IPSM** folder on the terminal.

Menu Configuration File Sections

Menu configuration files contain of two basic sections: **Settings** and **MenuEntries**. Both sections are locked, which means only their Values can be changed, not their section names.

Settings Section

The Settings section defines general EZMenu settings. The keys in this section are locked, which means that only their Values can be changed.

Key	Description	Default Value	Available Values
Sig	Identifies this file as a menu file.	EZMenu	These keys are read-only and cannot be changed.
Version	This is the EZMenu version number.	1	
EnableDebug	Enables system debugging.	0	0=Disable 1=Enable; an Easymenu.log file is created in the \IPSM folder.
ListViewMode	Determines the default view mode for the window. For details, see View Options on page 1-3.	3	0=Detail 1=List 2=Small Icon 3=Large Icon
Caption	Defines the caption or title displayed in the title bar of the application window.	Variable	User-defined
StartMenu	Enables and disables access to the Start menu from the application window.	Variable	0=Disable Start Menu 1=Enable Start Menu
OK	Enables and disables the OK button in the upper right corner of the application window.	Variable	0=Disable OK Button 1=Enable OK Button
Menu	Determines which menus appear in the Command bar. There are three menus: File, View, Help. Exit =File menu View =View menu Default =File, View & Help menus	3	0=No Menus 1=Default Menu + No Exit + No View 2=Default Menu + No Exit 3=Default Menu
The following three parameters determine the icon spacing in all view modes:			
ListViewIconSpacingY	Sets vertical icon spacing.	80	Spacing is measured in pixels.
ListViewIconSpacingX	Sets horizontal icon spacing.	75	Spacing is measured in pixels.
ListViewGradient	Determines whether the gradient background (horizontal blue and white lines) appears on the window.	1	0=Disable gradient background 1=Enable gradient background

Key	Description	Default Value	Available Values
MaskPassword	Determines if password entries on dialog boxes should be masked.	1	0=Disabled; passwords are not masked. 1=Enabled; passwords are masked.
TodayScreenSessionTimeout	When the device is left in suspend mode, this key specifies the number of hours that need to pass before the device returns to the Today screen.	0	0=Disabled; the terminal does not return to the Today screen while in suspend mode. X=Number of hours.


MenuEntries Subsections

The MenuEntries section determines which programs appear on the application window.

The MenuEntries section is locked, which means that you cannot change its Name or Description; however, its child sections are not locked and can have any name and description.

Each child section is a program that launches from the application window and must be at the same level underneath the MenuEntries section. The order of child sections from top to bottom determines the order that the programs appear on the application window.

Child Section Keys



The keys in the child sections are locked, which means only their Values can be changed.

Key	Description	Required	Available Values
Name	Name to display on the window. The name appears under the icon (if there is an icon).	Required	User-defined
Description	Description to display on the window in Detail view.	Required	User-defined

Key	Description	Required	Available Values
CommandLine	Command line to execute when the item is selected on the window. This is the location of the EXE file for the program to launch.	Required	Location of the EXE file. Also available: [ADMIN]=Toggles into Administrative mode [EXIT]=Exit menu
CommandArgs	Command line arguments used with the CommandLine parameter.	*Optional	Program-specific
Password	Use this key to password-protect access to the window. If no value is entered, the window is not password-protected.	Optional	Enter a password.
HotKey	Hotkey that can be used to launch the menu entry.	Optional	HotKey number
HotKeyModifier	Modifier for the hotkey.	Optional	Global: 16=No Modifier 17=ALT 18=CONTROL 20=SHIFT EZMenu only: 0=No Modifier 1=ALT 2=CONTROL 4=SHIFT
IconFile	Filename of the icon resource file.	Optional	The filename of the icon must be an EXE or DLL, an ICO file will not work.
Icon ID	Icon resource identifier contained in the file specified in the IconFile key.	Optional	X=Icon resource identifier
SupportFile	The key dependencies.	Optional	X=Variable
StartOption	Specifies startup options that must be met for the menu entry to appear on the window.	Optional	See Start Options on page 10-6 .

Exit Icon

[Default EZMenu Configuration Files](#) (see page 10-1) contain a section named **Exit** as a child section of the MenuEntries section.



Enabling the Exit section places this icon on the application window, which allows users to exit. If you want users to be able to exit the application window, make sure the Exit section is a child of the MenuEntries section. If you want users to be unable to exit the application window, disable or delete the Exit section.

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
DISABLED	Never, regardless of other startup options specified.	None
COLDBOOT	The terminal has performed a cold boot.	Boot type
WARMBOOT	The terminal has performed a warm boot.	
TOUCH	The terminal has a touch screen display installed.	Touch Screen
NONTOUCH	The terminal doesn't have a touch screen display installed.	
BATCH	The terminal is a batch unit (no RF or internal modem cards installed).	Mobility
RF	The terminal has an RF card installed (e.g., Cisco 802.11b).	
GSM	The terminal has a GSM radio.	
BT	The terminal has a Bluetooth radio.	
MODEM	The terminal has an internal modem card installed.	
IMAGER	The terminal has an imager installed.	Scanner
LASER	The terminal has a laser scanner installed.	
BLIND	The terminal has no laser or imager installed.	
ANYSCAN	The terminal has either an imager or a laser scanner installed.	
RFON	The RF radio is Enabled.	Radio
GSMON	The GSM radio is enabled.	
BTON	The Bluetooth radio is enabled.	
RFGSMBTOFF	The RF, GSM, & Bluetooth radios are disabled.	

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
29KEY	The terminal has a 29-key keyboard.	Keyboard
35KEY	The terminal has a 35-key keyboard.	
38KEY	The terminal has a 38-key keyboard.	
43KEY	The terminal has a 43-key keyboard.	
56KEY	The terminal has a 56-key keyboard.	
NO_KEY	The terminal has a 56-key keyboard.	

Start Options

Start Options define the required system parameters for a software application to launch. The following values can be entered for the StartOption key, wherever it appears:

Option Name	The program launches if ...	Category
7300	It's a Dolphin 7300 terminal.	Model
7400	It's a Dolphin 7400 terminal.	
7450	It's a Dolphin 7450 terminal.	
74XX	It's any Dolphin terminal beginning with "74".	
7600	It's a Dolphin 7600 terminal.	
76XX	It's any Dolphin terminal beginning with "76".	
7850	It's a Dolphin 7850 terminal.	
78XX	It's any Dolphin terminal beginning with "78".	
7900	It's a Dolphin 7900 terminal.	
79XX	It's any Dolphin terminal beginning with "79".	
9500	It's a Dolphin 9500 terminal.	
9501	It's a Dolphin 9501 terminal.	
9550	It's a Dolphin 9550 terminal.	
9551	It's a Dolphin 9551 terminal.	
95XX	It's any Dolphin terminal beginning with "95".	
9700	It's a Dolphin 9700 terminal.	
9900	It's a Dolphin 9900 terminal.	
99XX	It's any Dolphin terminal beginning with "99".	
PNPID	The terminal has a card installed whose identification contains ALL of the strings specified in the PNPID setting.	Expansion Card
NONPNPID	The terminal doesn't have a card installed whose identification contains ALL of the strings specified in the PNPID setting.	

Multiple options can be specified for each category. For example, you can specify both 35KEY and 43KEY options to request that the program run in either a 35- or 43-key keyboard terminal. Separate multiple options with commas.

To ignore a category, don't specify any of its options.


Locking Down the Application Window

You can program a menu configuration file to block access to the Start menu, OK button, and Command bar menus on the application window. When all of these items are blocked, the user must navigate the terminal from the application window.

EZMenu carries these settings forward to all windows opened from the application window. This way, access to the Start menu, **OK** button, and Command bar menus can be blocked globally.

1. Open the menu configuration file in EZConfig Editor.
For more information, see [Working with Open EXM Files](#) on page 2-8.
2. In the [Settings Section](#) (page 10-3), modify the following keys:
 - a. **StartMenu=0** (The Start menu won't appear on the application window.)
 - b. **OK=0** (The OK button won't appear on the application window.)
 - c. **Menu=0** (No menus appear in the Command bar.)
3. In the MenuEntries section, delete, disable, or password protect (see [Password](#) on page 10-5) the Exit subsection to remove the Exit icon.
4. If you are modifying the file in EZConfig Editor on the terminal, tap **Tools > Launch Associated App**. The application window opens displaying your changes.

If you are modifying the file in EZConfig Editor on the workstation, save, then transfer the file to the terminal. On the terminal, navigate to the application window to verify your changes.



Booting the Terminal to the Application Window

You can program the terminal to boot to the application window by modifying the [Autorun.exm File](#) (see page 4-1).

1. In EZConfig Editor, open Autorun.exm.
2. Open the Programs section and enable the EasyMenu section.
3. In the EasyMenu section, modify the **Args** key to call the EXM file of the application window. This is the path to the menu configuration file; i.e., `"/ipsm/***/menu.exm."`
By default, the **Args** key calls `/ipsm/demosmenu.exm`.
4. Warm boot the terminal and verify that startup finishes on the application window.






Overview

The SetRAM Power Tool adjusts the division of program memory vs. file system memory on Dolphin terminals running Windows Mobile 6.0.

Windows Mobile 6.0 Memory


Windows Mobile 6.0 is designed to use a persistent file store rather than a RAM object store. The allocation of file system RAM memory versus program memory must be made during hard resets. This change is a challenge in devices that use the RAM based file systems because there is no way to predict individual application requirements of program memory vs. RAM file store.

As a result, you cannot change the memory allocation in the Memory system setting.



The screenshot shows the 'Settings' application on a Windows Mobile 6.0 device, specifically the 'Memory' settings page. The status bar at the top indicates 'Settings', signal strength, battery level, and the time '8:01'. The 'Memory' section is divided into two columns: 'Storage' and 'Program'. The 'Storage' column shows a total of 31.41 MB, with 10.17 MB in use and 21.24 MB free. The 'Program' column shows a total of 89.17 MB, with 15.32 MB in use and 73.85 MB free.

Memory	
Storage	Program
Total: 31.41 MB	Total: 89.17 MB
In use: 10.17 MB	In use: 15.32 MB
Free: 21.24 MB	Free: 73.85 MB





The screenshot shows the 'Main' menu of the Windows Mobile 6.0 device. The menu items are 'Main', 'Storage Card', and 'Running Programs'. The 'Main' item is currently selected and highlighted.

Main	Storage Card	Running Programs
------	--------------	------------------

On Dolphin terminals, the default memory allocation between file store and program memory is 50/50.

Accessing SetRAM

1. On the [Power Tools Main Window](#) (see page 1-2), tap the **SetRAM** icon . The SetRAM window displays the current memory distribution.



2. To change the memory allocation, use the slider to adjust the memory allocation:
File MB=File Storage Memory
Prog MB=Program Memory
3. Tap **Set RAM Allocation** to make the change.
4. The terminal launches a hard reset, then a soft reset.
 This reset process launches AutoInstall, which launches DeviceConfig's RAM memory allocation settings. Therefore, make sure that the RAM section is disabled in DeviceConfig.exm or that it contains the same memory settings as SetRAM. For more information, see [RAM Memory Allocation in DeviceConfig](#) on page 11-2.

RAM Memory Allocation in DeviceConfig


DeviceConfig contains a RAM section (see page 3-10) that—if enabled—sets the RAM memory allocation for the terminal during startup. Dolphin terminals default to the RAM allocation in DeviceConfig. Therefore, if you want the changes you make in SetRAM to persist through hard resets, make sure that the RAM section in DeviceConfig is disabled or, if enabled, matches the parameters in SetRAM.

For more information about DeviceConfig, see [RAM Section](#) on page 3-10.

SetRAM Window

Field	Value	Description
Total Installed RAM	128 MB	Actual size of installed RAM chip.
Memory Statistics: Total User RAM: 121 MB Min Program RAM: 31 MB Min File Sys RAM: 16 MB RAM File %: 50 % Actual File RAM: 60 MB Actual Prog RAM: 60 MB		The values displayed in these fields are pulled from the terminal dynamically when SetRAM opens. When SetRAM acquires the information successfully, the SetRAM window displays the following message: "RAM Info read success."

SetRAM Window

Field	Value	Description
Total User RAM	121 MB	Total RAM available for file system and program memory minus kernel overhead.
Min Program RAM	31 MB	Minimum amount of memory allowed for program memory.
Min File Sys RAM	16 MB	Minimum amount of memory allowed for the file system.
RAM File %	50	Percentage of the Total User RAM allocated to the file system.
Actual File RAM	60 MB	The actual amount of memory allocated for the file system.
Actual Prog RAM	60 MB	The actual amount of memory allocated for the program memory.
Slider 		
XX%	50%	The RAM file % represented by the slider position. This percentage updates as you move the slider.
Valid Split % Range	13%–75%	Valid % range that can be used when setting file system size. If set out of range, value will be set to closest min or max.
File MB: & Prog MB:	60	The actual file and program memory (in MBs) represented by the slider position. These numbers update as you move the slider.

RAM Memory Restrictions

RAM memory allocation restrictions are built into SetRAM; the slider will not allow you reset the memory beyond the terminal's capabilities.



Overview

Dolphin terminals contain two print utilities:

BTPrint.exe BTPrint prints to a Bluetooth device via the Bluetooth wireless radio; see page 12-2.

IrDAPrintCE.exe IrDAPrint prints to an IrDA device via the IrDA port; see page 12-2.

Both .exes are located in the **\Program Files\Power Tools** folder.

Print Demo

All Dolphin terminals contain a Print Demo (**Start > Demos > Print Demo**) that prints a sample receipt or bar code to a Bluetooth or IrDA printer. The Print Demo calls the BTPrint.exe when printing to a Bluetooth device and the IrDAPrintCE.exe when printing to an IrDA device.

For more information about the Print Demo, please refer to the Print Demo chapter of the Demos User's Guide, which is available for download from the web site: www.honeywell.com/aidc.

Note: You can also call either EXE to print to a Bluetooth or IrDA printer via command line.

BTPrint

BTPrint allows you to print to a Bluetooth printer via the command line, provided that the Bluetooth printer is set up as a Bluetooth Favorite on the Dolphin terminal.

For more information about setting up Bluetooth Favorite devices, please see the Bluetooth section of the Print Demo chapter in the Demos User's Guide, which is available on the User CD or from the Partners area of www.honeywell.com/aidc.

Calling a Bluetooth Printer

Call BTPrint.exe from the command line `\Program Files\Power Tools\BTPrint.exe` – with the path of the document as the command line argument.

IrDAPrintCE

IrDAPrintCE allows you to print to an IrDA printer via the command line.

Calling an IrDA Printer

Call the IrDAPrintCE.exe from the command line `\Program Files\Power Tools\IrDAPrintCE.exe` with the path of the document as the command line argument.

Technical Assistance

If you need assistance installing or troubleshooting your device, please call your distributor or the nearest technical support office:

North America/Canada

Telephone: (800) 782-4263

E-mail: hsmnasupport@honeywell.com

Latin America

Telephone: (803) 835-8000

Telephone: (800) 782-4263

E-mail: hsmlasupport@honeywell.com

Brazil

Telephone: +55 (21) 3535-9100

Fax: +55 (21) 3535-9105

E-mail: brsuporte@honeywell.com

Mexico

Telephone: (803) 835-8000

E-mail: hsmlasupport@honeywell.com

Europe, Middle East, and Africa

Telephone: +31 (0) 40 7999 393

Fax: +31 (0) 40 2425 672

E-mail: hsmeurosupport@honeywell.com

Hong Kong

Telephone: +852-29536436

Fax: +851-2511-3557

E-mail: aptechsupport@honeywell.com

Singapore

Telephone: +65-6842-7155

Fax: +65-6842-7166

E-mail: aptechsupport@honeywell.com

China

Telephone: +86 800 828 2803

Fax: +86-512-6762-2560

E-mail: aptechsupport@honeywell.com

Japan

Telephone: +81-3-3839-8511

Fax: +81-3-3839-8519

E-mail: aptechsupport@honeywell.com

Online Technical Assistance

You can also access technical assistance online at www.honeywellaidc.com.





Honeywell Scanning & Mobility
9680 Old Bailes Road
Fort Mill, SC 29707

www.honeywellaidc.com