

Printer Handstrap Instructions




The handstrap (P/N 074789) provides a convenient way to carry your PB21, PB22, PB31, PB32, PB42, PB50, or PB51 printer. With the handstrap attached, you can also attach the shoulder strap (P/N 074788). The handstrap kit contains these items:

- Handstrap accessory
- This instruction sheet

To attach the handstrap to the printer

- 1** Remove both ends of the handstrap from the strap adjusters that secure them to the strap.
- 2** Insert one end of the handstrap through the handstrap clip on the printer. Make sure the D-rings on the handstrap are facing away from the printer.
- 3** Pull the end of the handstrap through the handstrap clip and then insert the end of the handstrap back through the strap adjuster and pull tight.



- 4** Repeat step 3 with the other end of the handstrap. You are now ready to use the printer with the handstrap, or you can attach the shoulder strap to the D-rings on the handstrap.

Printer Handstrap Instructions



P/N 074579-004



Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2009 Intermec Technologies
Corporation. All rights reserved.