

PR₂ | PR₃

Belt Clip Replacement Instructions

皮帶夾更換說明

皮帶夾更換說明

Instructions pour le remplacement de la pince de ceinture

Anleitung zum Ersetzen des Gürtelclips

Istruzioni per la sostituzione della clip da cintura



벨트 클립 교체 지침

Instruções para a Substituição do Clipe de Cinto

Инструкции по замене зажима для крепления к ремню

Instrucciones de reemplazo de la pinza para cinturón

Kemer Mandalı Değişirme Talimatları





Worldwide Headquarters
6001 36th Avenue West
Everett, Washington 98203
U.S.A.

tel 425.348.2600

fax 425.355.9551

www.intermec.com

© 2012 Intermec Technologies
Corporation. All rights reserved.



PR2 and PR3 Belt Clip Replacement Instructions



P/N 943-343-001