

210241-000 LP3 Shoulder Strap



Parts List

- 210241-000 Should Strap

Removing the Strap

1. Push in the locking keys on the printer's snaps (Figure 1) and detach the strap.




Figure 1

Installing the Shoulder Strap

Note: The shoulder strap included in this kit is not adjustable and does not have a gripped handle.

1. Insert the strap's clips into the printer's snaps so that they click into place (Figure 2). Use the following guidelines:
 - The lettering on the strap's clips face down.
 - The locking keys on the printer's snaps align with the notches on the strap's clips.



Figure 2

The locking keys should easily snap into place. Do not force the strap into place.

Warranty

The Company warrants that Datamax-O'Neil products are free from defects in manufacturing materials and workmanship for one (1) year from date of original purchase to Buyer/Distributor (OEMs 90 days from the date of purchase). Batteries, cables, power supplies, and other accessories will be warranted for ninety (90) days. Datamax-O'Neil makes no other warranties, expressed or implied, including implied warranties of merchantability and fitness of purpose.

If you try to repair, disassemble, or change the product in any way, or use parts not provided by Datamax-O'Neil without prior, written authorization, all warranties are void.

For complete warranty and service information, see the Warranty Card included in your printer's original packaging.

No Liability for Negligent Use

In no event shall Datamax-O'Neil be held liable for any damages whatsoever (including, without limitations, damages for loss of profits, business interruption, loss of information, or other pecuniary loss) arising out of negligence in use and care of the product.