



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	US	BELGIAN	FINISH (SWEDISH)	FRENCH	GERMAN	ITALIAN	SWISS (German)	BRITISH	DANISH	NORWEGIAN
	Country ID	0	1	2	3	4	5	6	7	8	9
Terminal ID	Terminal Name										
1	IBM XT	+	+	+	+	+	+	+	+	+	+
2	IBM PS2	+	+	+	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+	+	+	+
6	IBM 3486 102	+	+	+	+	+	+	+	+	+	+
7	IBM 3191 122	+	+	+	+	+	+	+	+	+	+
8	IBM 3486 122	+	+	+	+	+	+	+	+	+	+
24	IBM 3180 122	+	+	+	+	+	+	+	+	+	+
25	Telex 88	+	+	+	+	+	+	+	+	+	+
35	BDS 7	+	+	+	+	+	+	+	+	+	+
45	Telex 102	+	+	+	+	+	+	+	+	+	+
46	Telex 122	+	+	+	+	+	+	+	+	+	+
71	DDC 3496 / Nokia/ICL 472 122	+	+	+	+	+	+	+	+	+	+
72	ADI 1496	+	+	+	+	+	+	+	+	+	+
84	DDC 3496 102	+	+	+	+	+	+	+	+	+	+
97	IBM THINKPAD PS2	+	+	+	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	+	+	+	+	+	+	+	+	+	+
106	IBM THINKPAD AT	+	-	+	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	+	-	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	+	-	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+	+	+	+
125	APPLE USB Keyboard	+	+	+	+	+	+	+	+	+	+

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	SPANISH	DUTCH	HEBREW	PORTUGUESE	LATIN AMERICA	CZECH DEC	BRAZILIAN	GREEK DEC	CANADIAN FRENCH	HUNGARIAN
	Country ID	10	11	12	13	14	15	16	17	18	19
Terminal ID	Terminal Name										
1	IBM XT	+	-	-	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+	+	+	+
6	IBM 3486 102	+	-	-	-	+	-	-	-	-	-
7	IBM 3191 122	+	-	-	-	+	-	-	-	-	-
8	IBM 3486 122	+	-	-	-	+	-	-	-	-	-
24	IBM 3180 122	+	-	-	-	+	-	-	-	-	-
25	Telex 88	+	-	-	-	-	-	-	-	-	-
35	BDS 7	+	-	-	-	-	-	-	-	-	-
45	Telex 102	+	-	-	-	+	-	-	-	-	-
46	Telex 122	+	-	-	-	+	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	+	-	-	-	+	-	-	-	-	-
72	ADI 1496	+	-	-	-	+	-	-	-	-	-
84	DDC 3496 102	+	-	-	-	+	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	+	+	+	+	+	+	+	+	+	+
106	IBM THINKPAD AT	+	+	+	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+	+	+	+
125	APPLE USB Keyboard	+	+	+	+	+	+	-	-	+	+

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	POLISH	SCS	SLOVAKIAN DEC	SWEDISH	TURKISH Q	ROMANIAN	RUSSIAN	TURKISH F	JAPANESE ASCII	SWISS (FRENCH)
	Country ID	20	21	22	23	24	25	26	27	28	29
Terminal ID	Terminal Name										
1	IBM XT	-	-	-	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	+	+	+	+	+	+	+	+	-	+
106	IBM THINKPAD AT	+	+	+	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+	+	+	+
125	APPLE USB Keyboard	+	+	+	+	+	+	+	+	-	-

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	USA INTERNATIONAL	SLOVENIAN	CROATIAN	BOSNIAN	MACEDONIAN	ALBANIAN	SERBIAN LATIN	SERBIAN CYRILLIC
	Country ID	30	31	32	33	34	35	36	37
Terminal ID	Terminal Name								
1	IBM XT	-	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	-	+	+	+	+
3	IBM AT	+	+	+	-	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	-	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	-	+	+	+	+
104	DEC VT500 LK411 Keyboard	-	+	-	-	-	-	-	-
106	IBM THINKPAD AT	+	+	+	-	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	-	+	+	+	+
125	APPLE USB Keyboard	-	-	-	-	-	-	-	-

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	CZECH QWERTZ	CZECH QWERTY	CZECH PROGRAMMERS	ESTONIAN	LATVIAN	LATVIAN QWERTY	LITHUANIA	LITHUANIAN IBM
	Country ID	38	39	40	41	42	43	44	45
Terminal ID	Terminal Name								
1	IBM XT	-	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	-	-	-	-	-	-	-	-
106	IBM THINKPAD AT	+	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+	+
125	APPLE USB Keyboard	-	-	-	-	-	-	-	-

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	SLOVAKIAN QWERTZ	SLOVAKIAN QWERTY	HUNGARIAN 101 KEY	SPANISH VARIATION	BULGARIAN CYRILLIC	BULGARIAN LATIN	CANADIAN FRENCH LEGACY
	Country ID	48	49	50	51	52	53	54
Terminal ID	Terminal Name							
1	IBM XT	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	-	-	-	-	-	-	-
106	IBM THINKPAD AT	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+
125	APPLE USB Keyboard	-	-	-	-	-	-	-

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	CANADIAN MULTILINGUAL	ITALIAN 142	POLISH 214	POLISH PROGRAMMERS	BRAZILIAN MS	GREEK POLYTONIC	GREEK 220	GREEK 319	GREEK LATIN
	Country ID	55	56	57	58	59	60	61	62	63
Terminal ID	Terminal Name									
1	IBM XT	-	-	-	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	-	-	-	-	-	-	-	-	-
106	IBM THINKPAD AT	+	+	+	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+	+	+	+
125	APPLE USB Keyboard	-	-	-	-	-	-	-	-	-

+ indicates supported
- indicates not supported



Supported International Country and Terminal IDs

(Applies to
3800g/3800i/3800r/3820/
4600g/4600r/4800i/4820/4820i/
2020-5A/2020-5B)

	Keyboard Layouts	GREEK 220 LATIN	GREEK 319 LATIN	GREEK MS	RUSSIAN MS	RUSSIAN TYPEWRITER	IRISH
	Country ID	64	65	66	67	68	73
Terminal ID	Terminal Name						
1	IBM XT	-	-	-	-	-	-
2	IBM PS2	+	+	+	+	+	+
3	IBM AT	+	+	+	+	+	+
5	DEC VT500 PC Keyboard	+	+	+	+	+	+
6	IBM 3486 102	-	-	-	-	-	-
7	IBM 3191 122	-	-	-	-	-	-
8	IBM 3486 122	-	-	-	-	-	-
24	IBM 3180 122	-	-	-	-	-	-
25	Telex 88	-	-	-	-	-	-
35	BDS 7	-	-	-	-	-	-
45	Telex 102	-	-	-	-	-	-
46	Telex 122	-	-	-	-	-	-
71	DDC 3496 / Nokia/ICL 472 122	-	-	-	-	-	-
72	ADI 1496	-	-	-	-	-	-
84	DDC 3496 102	-	-	-	-	-	-
97	IBM THINKPAD PS2	+	+	+	+	+	+
104	DEC VT500 LK411 Keyboard	-	-	-	-	-	-
106	IBM THINKPAD AT	+	+	+	+	+	+
112	Telex 88 DATA ENTRY	-	-	-	-	-	-
114	IBM 3180 DATA ENTRY 122	-	-	-	-	-	-
124	USB EPC Keyboard	+	+	+	+	+	+
125	APPLE USB Keyboard	-	-	-	-	-	-

+ indicates supported
- indicates not supported