

Congratulations! You've just purchased an accessory that will allow your rugged Datamax-O'Neil printer to go the extra mile. Proper use of this case will allow our OC Series printer to be used in harsh, dusty, or rainy environments.

This case is certified to be an IP54 rating, so when properly used, it will protect your product against particles as small as dust, and water from any direction.

## Installation Instructions

1. Remove the case from any protective wrapping and packaging.
2. Unzip and detach all velcro and/or hook and loop fasteners.
3. Install the printer, as shown in Figure 1. Be sure that the printer's edges are completely covered by the case.



Figure 1

4. Zip the printer flap to secure the printer in place (Figure 2).



Figure 2

5. Close the top cover, then secure all covers with the hook and loop fasteners.
6. The power jack and communication ports are located under the velcro flap. To access the ports, turn the case over. A female swivel clip is also located under the velcro flap.



Figure 3

## Options

- The printer can be worn in the IP54 case with a swivel belt clip or swivel belt loop (Figure 3).



Figure 4

- The printer can be worn with a shoulder strap (included) (Figure 5).



Figure 5

---

NOTE: When the printer is in transport or not in use, it is necessary to fully secure the paper flaps to allow maximum protection of the printer.

---

- The top cover flap can also be tucked under itself to ease removal of media while maintaining additional protection to the printer (Figure 6). (NOTE: This configuration does not offer full IP54 protection.)



Figure 6

## Agency Approvals



Applicable Directive

- 89/336/EEC, 73/23/EEC

Applicable Standards

- EN55022 (1998)
- EN55024 (1998)
- EN60950 (1992)

## Warranty

The Company warrants that Datamax-O'Neil products are free from defects in manufacturing materials and workmanship for one (1) year from date of original purchase to Buyer/Distributor (OEMs 90 days from the date of purchase). Batteries, cables, power supplies, and other accessories will be warranted for ninety (90) days. Datamax-O'Neil makes no other warranties, expressed or implied, including implied warranties of merchantability and fitness of purpose.

If you try to repair, disassemble, or change the product in any way, or use parts not provided by Datamax-O'Neil without prior, written authorization, all warranties are void. For complete warranty and service information, see the Warranty Card included in your printer's original packaging.

## No Liability for Negligent Use

In no event shall Datamax-O'Neil be held liable for any damages whatsoever (including, without limitations, damages for loss of profits, business interruption, loss of information, or other pecuniary loss) arising out of negligence in use and care of the product.