

# **EasyParse for Motor Vehicle Documents**

---

TotalFreedom<sup>™</sup> Formatting Plug-In

## **Integration Guide**

---

## ***Disclaimer***

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein: nor for incidental or consequential damages resulting from the furnishing, performance, or use of this manual.

This document contains propriety information that is protected by copyright. All rights reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

© 2011-2012 Honeywell International Inc. All rights reserved.

Web Address: [www.honeywellaidc.com](http://www.honeywellaidc.com)

## ***Trademarks***

Total*Freedom* are trademark or registered trademark of Metrologic Instruments, Inc. in the United States and/or other countries.

Other product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are the property of their respective owners.

## ***Patents***

For patent information, please refer to [www.honeywellaidc.com/patents](http://www.honeywellaidc.com/patents).

---



# Table of Contents

<b>Introduction .....</b>	<b>1</b>
Overview .....	1
<b>Getting Started</b>	
EasyParse for Motor Vehicle Documents Software Installation.....	3
EasyParse for Motor Vehicle Documents Software Activation .....	4
To Enable EasyParse for Motor Vehicle Documents Software Plug-In .....	4
<b>Data Transmission Configuration</b>	
Configuration .....	5
Enter/Exit Programming Mode Bar Codes .....	6
Start/End Configuration Bar Codes .....	6
Data Field Options for Programming Mode .....	7
Header Options .....	29
Formatting Options for Select Data Fields.....	30
Separators for Programming Mode .....	37
<b>EasyParse for Motor Vehicle Documents Configuration Utility .....</b>	<b>57</b>
<b>Inserting Delays between Fields.....</b>	<b>59</b>
<b>EasyParse for Motor Vehicle Documents Version Identification .....</b>	<b>61</b>
<b>End User License Agreement .....</b>	<b>63</b>
<b>Customer Support.....</b>	<b>71</b>
Technical Assistance.....	71





# Introduction

## Overview

Honeywell's EasyParse for Motor Vehicle Documents (MVD) software plug-in parses bar code data found on Motor Vehicle Commission issued American Association of Motor Vehicle Administrators (AAMVA) documents for specific field information such as titling number, vehicle make, owner's name, etc. EasyParse for Motor Vehicle Documents may be purchased pre-installed on select Honeywell area-imaging products or purchased as a standalone upgrade. Refer to EasyParse for Motor Vehicle Documents Data Sheet, available at [www.honeywellaidc.com](http://www.honeywellaidc.com), for a complete list of supported products.

*Note: Honeywell cannot be held responsible for motor vehicle administration documents that do not comply with the formatting standards set forth by AAMVA.*

*EasyParse for Motor Vehicle Documents parses only those documents that are present in the AAMVA specification and does not parse jurisdiction specific documents.*



# Getting Started

## EasyParse for Motor Vehicle Documents Software Installation

*Note: Honeywell products ordered with EasyParse for Motor Vehicle Documents do not require software installation or software activation. Skip to page 4 for instructions on how to enable the software plug-in.*

Items required for EasyParse for Motor Vehicle Documents installation:

- A computer with access to the internet
- The imager's User's Guide
- The firmware upgrade cable specified in the imagers User's Guide
- EZConfig-Scanning software, downloadable at no additional cost from [www.honeywellaidc.com](http://www.honeywellaidc.com)

The following installation procedure is not applicable for imagers that do not support firmware updates through EZConfig-Scanning download feature. Consult the imager's User's Guide to verify the capabilities of the imager before proceeding.

To install the EasyParse for Motor Vehicle Documents software plug-in:

1. Download and save the EasyParse for Motor Vehicle Documents<sup>®</sup> plug-in trial software available at [www.honeywellaidc.com](http://www.honeywellaidc.com).
2. Consult the imager's User's Guide for information on the specific cable required for firmware updates.
3. Connect the cable to the imager and an available RS232 serial or USB port on the host system.
4. Start the EZConfig-Scanning software. Click on the *Help* file in the menu bar. Select *Help Topics* and follow the steps under *Connecting to a Device*.
5. In the Application Explorer, select Download. In the Main Workspace, click on the "..." button to browse for the EasyParse for Motor Vehicle Documents flash image file (\*.moc.) Click on the Download to Device button.

◆ *The free trial version of EasyParse for Motor Vehicle Documents has unlimited trials, however inserts "X" characters in the data stream. To prevent "X" characters from appearing in the transmitted data stream, a full EasyParse for Motor Vehicle Documents license must be purchased. Contact customer service for more information on how to purchase an EasyParse for Motor Vehicle Documents license. See page 71 for contact information.*

- 
6. After the firmware has been downloaded to the imager, scan the Save Custom Defaults bar code in the User's Guide.
  7. To activate EasyParse for Motor Vehicle Documents software, scan the *Activate Plug-in* bar code followed by the *Reset* bar code:

Activate Plug-in



PLGFOE1;PLGFONEasyAAMVACnf.

Reset



RESET\_.

## ***EasyParse for Motor Vehicle Documents Software Activation***

A license key is required to activate the full version of EasyParse for Motor Vehicle Documents. Contact a customer service representative for information on purchasing a licensing key. Regional contact information is on page 71.

## ***To Enable EasyParse for Motor Vehicle Documents Software Plug-In***

Scan the **Enable EasyParse for Motor Vehicle Documents** bar code to enable the EasyParse for Motor Vehicle Documents software plug-in.

- \* Enable EasyParse for Motor Vehicle Documents



9902A0021#ACTIVATE#.

Disable EasyParse for Motor Vehicle Documents



9902A0021#DEACTIVATE#.

\* *Factory Default.*



# Data Transmission Configuration

Before starting the configuration process, identify the necessary data fields required for the application and the order with which the data must be transmitted to the electronic form or database.

The default format of parsing configuration is TD\_Title Number [horizontal tab] TD\_Vehicle Make [horizontal tab] TD\_Vehicle Model Year [horizontal tab] RG\_Vehicle Make [horizontal tab] RG\_Vehicle Model Year [horizontal tab] RG\_Vehicle Identification Number (VIN) [horizontal tab] MC\_Carrier Name [horizontal tab] MC\_City [horizontal tab] MC\_Jurisdiction [horizontal tab] VS\_Vehicle Make [horizontal tab] VS\_Inspection Form Number Current [horizontal tab] VS\_Inspection Form Number Previous [horizontal tab] OW\_First Owner Total Name [horizontal tab] OW\_Second Owner Total Name [horizontal tab] VH\_Vehicle Make [horizontal tab] VH\_Make Year [horizontal tab] VH\_Vehicle Identification Number [horizontal tab] VH\_Number of Cylinders [horizontal tab] VH\_Number of Doors.

## Configuration

To configure the imager for Programming Mode configuration:

1. Scan **Enter Programming Mode** bar code on page 6.
2. Scan the **Start Configuration** bar code on page 6.
3. Scan each required data field bar code in the order of the desired transmission sequence (pages 7 - 28), if necessary, desired formatting option (page 30) with desired separators for data fields (see pages 32 - 55.)
4. Scan the **End Configuration** bar code on page 6.
5. Scan **Exit Programming Mode** bar code on page 6.

*Note: The bar codes must be scanned in this sequence. If scanned out of sequence the imager will razz and no action will be taken.*

---

## Formatting Option Notes

EasyParse for Motor Vehicle Documents supports various formats for different fields present in different documents. For example, TD\_Vehicle Purchase Date, in Title Document, has 15 different date formats available. If formatting is required, scan the data field bar code **followed by** the desired format for the field (see page 30.)

### Enter/Exit Programming Mode Bar Codes

Enter Programming Mode



9902EntA0021.

Exit Programming Mode



99Exit.


### Start/End Configuration Bar Codes

Start Configuration



9902#START#.

End Configuration



9902#END#.







---

## Data Field Options for Programming Mode



The prefixes TD, RG, MC, IR, VS, OW, and VH correspond to sub-files Title, Registration, Motor Carrier Cab Card, Registrant and Vehicle Data, Vehicle Safety, and Vehicle documents respectively.

For detailed field descriptions, please refer to AAMVA BPR Migration Specification, *Bar Code Data Encoding Requirements – AAMVA International Specification – Motor Vehicle Documents: Version 01.0.*

<i>Title Document Bar Codes</i>		
Field Name	Menu Command	Programming Code
TD_Titling Jurisdiction	9902F00	
TD_Title Number	9902F01	
TD_Title Issue Date	9902F02	
TD_Vehicle Model Year	9902F03	
TD_Vehicle Make	9902F04	

Field Name	Menu Command	Programming Code
TD_Vehicle Identification Number (VIN)	9902F05	
TD_Odometer Reading - Mileage	9902F06	
TD_Vehicle Purchase Date	9902F07	
TD_Family Name (Last Name)	9902F08	
TD_Given Name (First Name)	9902F09	
TD_Address - Street	9902F0A	
TD_Address - City	9902F0B	

Field Name	Menu Command	Programming Code
TD_Address – Jurisdiction Code	9902F0C	
TD_Address – Zip Code	9902F0D	
TD_Odometer Disclosure	9902F0E	
TD_Previous Titling Jurisdiction	9902F0F	
TD_Previous Title Number	9902F10	
TD_Title Brand	9902F11	
TD_Vehicle Body Style	9902F12	

Field Name	Menu Command	Programming Code
TD_Odometer Date	9902F13	
TD_New / Used Indicator	9902F14	
TD_First Lien Holder Name	9902F15	
TD_First Lien Holder ID	9902F16	
TD_Vehicle Model	9902F17	
TD_Odometer Reading – Kilometers	9902F18	
TD_Business Name	9902F19	

Field Name	Menu Command	Programming Code
TD_Vehicle Color	9902F1A	
<i>Registration Document Bar Codes</i>		
RG_Registration Issue Date	9902F1B	
RG_Registration Expiry Date	9902F1C	
RG_Registration Plate Number	9902F1D	
RG_Registrant Family Name	9902F1E	
RG_Registrant Given Name	9902F1F	

Field Name	Menu Command	Programming Code
RG_Address – Street	9902F20	
RG_Address – City	9902F21	
RG_Addresss – Jurisdiction Code	9902F22	
RG_Address – Zip Code	9902F23	
RG_Vehicle Identification Number (VIN)	9902F24	
RG_Vehicle Make	9902F25	
RG_Vehicle Model Year	9902F26	



Field Name	Menu Command	Programming Code
RG_Vehicle Body Style	9902F27	
RG_Registration Year	9902F28	
RG_Registration Window Sticker Decal	9902F29	
RG_Vehicle Use	9902F2A	
RG_Fuel	9902F2B	
RG_Axles	9902F2C	
RG_Gross Vehicle Weight	9902F2D	

Field Name	Menu Command	Programming Code
RG_Vehicle Model	9902F2E	
RG_Business Name	9902F2F	
RG_Vehicle Color	9902F30	
<i>Motor Carrier Cab Card Document Bar Codes</i>		
MC_USDOT Number	9902F31	
MC_Carrier Name	9902F32	
MC_Street Address	9902F33	

Field Name	Menu Command	Programming Code
MC_City	9902F34	
MC_Jurisdiction	9902F35	
MC_Zip	9902F36	
<i>Registrant and Vehicle Date Document Bar Codes</i>		
IR_Carrier Name – Registrant	9902F37	
IR_Address - Street	9902F38	
IR_City	9902F39	

Field Name	Menu Command	Programming Code
IR_Jurisdiction	9902F3A	
IR_Zip Code	9902F3B	
IR_Unit Number	9902F3C	
IR_Vehicle Identification Number (VIN)	9902F3D	
IR_Model Year	9902F3E	
IR_Vehicle Make	9902F3F	
IR_Type of Vehicle	9902F40	

Field Name	Menu Command	Programming Code
IR_Number of Axles	9902F41	
IR_Number of Seats	9902F42	
IR_Registration Year	9902F43	
IR_Registration Issue Date	9902F44	
IR_Registration Plate Number	9902F45	
IR_Registration Decal Number	9902F46	
IR_Registration Enforcement Date	9902F47	

Field Name	Menu Command	Programming Code
IR_Registration Expiration Date	9902F48	
IR_Gross Vehicle Weight	9902F49	
IR_Base Jurisdiction Registered Weight	9902F4A	
<i>Vehicle Safety Document Bar Codes</i>		
VS_Inspection Station Number	9902F4B	
VS_Inspector Identification Number	9902F4C	
VS_Vehicle Make	9902F4D	

Field Name	Menu Command	Programming Code
VS_Vehicle Model Year	9902F4E	
VS_Vehicle Body Type – Style	9902F4F	
VS_Odometer Reading at Inspection	9902F50	
VS_Inspection Address	9902F51	
VS_Inspection Air Pollution Device Conditions	9902F52	
VS_Inspection Facility Identifier	9902F53	
VS_Inspection Form Number – Current	9902F54	

Field Name	Menu Command	Programming Code
VS_Inspection Form Number - Previous	9902F55	
VS_Inspection Smog Certificate Indicator	9902F56	
VS_Inspection Sticker Number – Current	9902F57	
VS_Inspection Sticker Number – Previous	9902F58	
<i>Vehicle Owner Document Bar Codes</i>		
OW_First Owner Total Name	9902F59	
OW_First Owner Last Name	9902F5A	



Field Name	Menu Command	Programming Code
OW_First Owner Name (First Name)	9902F5B	
OW_First Owner Middle Name	9902F5C	
OW_Second Owner Total Name	9902F5D	
OW_Second Owner Last Name	9902F5E	
OW_Second Owner Name (First Name)	9902F5F	
OW_Second Owner Middle Name	9902F60	
OW_Mailing Address 1	9902F61	

---

Field Name	Menu Command	Programming Code
OW_Mailing Address 2	9902F62	
OW_Mailing City	9902F63	
OW_Mailing Jurisdiction Code	9902F64	
OW_Mailing Zip Code	9902F65	
OW_Residence Address 1	9902F66	
OW_Residence Address 2	9902F67	
OW_Residence City	9902F68	

Field Name	Menu Command	Programming Code
OW_Residence Jurisdiction Code	9902F69	
OW_Residence Zip Code	9902F6A	
OW_First Owner ID Number	9902F6B	
OW_Second Owner ID Number	9902F6C	
OW_First Owner Legal Status	9902F6D	
OW_Second Owner Legal Status	9902F6E	

---

*Vehicle Document Bar Codes*



Field Name	Menu Command	Programming Code
VH_Major Code	9902F6F	
VH_Minor Code	9902F70	
VH_Transmission Code	9902F71	
VH_Vehicle Identification Number (VIN)	9902F72	
VH_MSRP/FLP	9902F73	
VH_Junked Indicator	9902F74	

Field Name	Menu Command	Programming Code
VH_Date Junked	9902F75	
VH_Stolen Indicator	9902F76	
VH_Date Stolen	9902F77	
VH_Date Recovered	9902F78	
VH_Vehicle Make	9902F79	
VH_Make Year (Model Year)	9902F7A	
VH_Vehicle Model	9902F7B	

Field Name	Menu Command	Programming Code
VH_Fuel Type	9902F7C	
VH_Body Style	9902F7D	
VH_Number of Doors	9902F7E	
VH_Number of Cylinders	9902F7F	
VH_Engine Size	9902F80	
VH_Vehicle Status Code	9902F81	
VH_Manufacture Gross Weight	9902F82	

Field Name	Menu Command	Programming Code
VH_Horsepower	9902F83	
VH_Unladen Weight	9902F84	
VH_Engine Displacement	9902F85	
VH_IRP Indicator	9902F86	
VH_IFTA Indicator	9902F87	
VH_VLT Clac From Date	9902F88	
VH_Vehicle ID Number	9902F89	





---

Field Name	Menu Command	Programming Code
VH_Vehicle Type Code (Type of Vehicle)	9902F8A	
VH_Number of Axles	9902F8B	



---

## Header Options

Field Name	Menu Command	Programming Code
File Type	9902H00	
Issuer Identification Number	9902H01	
AAMVA Version Number	9902H02	
Subfile Types	9902H03	

---

## Formatting Options for Select Data Fields

Field Name	Menu Command	Programming Code
Full Text	9902X00	
Alpha Code	9902X01	
Numeric Code	9902X02	
mmddyyyy	9902X03	
mm-dd-yyyy	9902X04	
mm/dd/yyyy	9902X05	

Field Name	Menu Command	Programming Code
mmddy	9902X06	
mm-dd-yy	9902X07	
mm/dd/yy	9902X08	
ddmmyyy	9902X09	
dd-mm-yyyy	9902X0A	
dd/mm/yyyy	9902X0B	
ddmmyy	9902X0C	





Field Name	Menu Command	Programming Code
dd-mm-yy	9902X0D	
dd/mm/yy	9902X2A	
yy	9902X0E	
dd	9902X0F	
mmm	9902X10	
mm	9902X20	
yyyy	9902X21	

Field Name	Menu Command	Programming Code
Non-delimited Alpha Code	9902X11	
Convert to Miles	9902X12	
Convert to Kilometers	9902X14	
Drop Leading Zeros	9902X13	
Add Padding to Left	9902X15	
Replace Leading Spaces	9902X19	
Value in Pounds	9902X16	

Field Name	Menu Command	Programming Code
Value in Kilograms	9902X17	
Numbers Only	9902X18	
Pounds (Numeric Only with Leading Zero)	9902X1A	
Pounds (Numeric Only without Leading Zero)	9902X1B	
Kilograms (Numeric Only with Leading Zero)	9902X1C	
Kilograms (Numeric Only without Leading Zero)	9902X1D	
Cubic Inches	9902X1E	

Field Name	Menu Command	Programming Code
Litres	9902X1F	
Street	9902X22	
City	9902X23	
Jurisdiction / State (Full Text)	9902X24	
Jurisdiction / State (Alpha Code)	9902X25	
Jurisdiction / State (Numeric)	9902X26	
Zip Code	9902X27	

---

Field Name	Menu Command	Programming Code
Pollution Control Values, Condition	9902X28	
Pollution Control Components Integrity	9902X29	
Fetch Data from Any Subfile	9902X2B	
Fetch Data from Any Subfile as per Current Field Size	9902X2C	



---

## Separators for Programming Mode

Field Name	Menu Command	Programming Code
Line Feed	9902S0A	
Vertical Tab	9902S0B	
Horizontal Tab	9902S09	
Carriage Return	9902S0D	
Space “ ”	9902S20	
Comma “ , ”	9902S2C	

---

Field Name	Menu Command	Programming Code
NULL	9902S00	
Start of Header	9902S01	
Start of Text	9902S02	
End of Text	9902S03	
End of Transmission	9902S04	
Enquiry	9902S05	
Acknowledge	9902S06	

---

Field Name	Menu Command	Programming Code
Bell	9902S07	
Backspace	9902S08	
Form Feed	9902S0C	
Shift Out	9902S0E	
Shift In	9902S0F	
Data Link Escape	9902S10	
Device Control 1	9902S11	

Field Name	Menu Command	Programming Code
Device Control 2	9902S12	
Device Control 3	9902S13	
Device Control 4	9902S14	
Negative ACK	9902S15	
Synchronous Idle	9902S16	
End of Text Block	9902S17	
Cancel	9902S18	

Field Name	Menu Command	Programming Code
End of Medium	9902S19	
Substitute	9902S1A	
Escape	9902S1B	
File Separator	9902S1C	
Group Separator	9902S1D	
Record Separator	9902S1E	
Unit Separator	9902S1F	

Field Name	Menu Command	Programming Code
Exclamation Point “!”	9902S21	
Quotation Mark “”	9902S22	
Cross Hatch “#”	9902S23	
Dollar Sign “\$”	9902S24	
Percent Sign “%”	9902S25	
Ampersand “&”	9902S26	
Closing Single Quote “”	9902S27	

Field Name	Menu Command	Programming Code
Opening Parentheses “(“	9902S28	
Closing Parentheses “)”	9902S29	
Asterisk “*“	9902S2A	
Plus “+“	9902S2B	
Hyphen “-“	9902S2D	
Period “.”	9902S2E	
Forward Slant “/“	9902S2F	

---

Field Name	Menu Command	Programming Code
0	9902S30	
1	9902S31	
2	9902S32	
3	9902S33	
4	9902S34	
5	9902S35	
6	9902S36	



Field Name	Menu Command	Programming Code
7	9902S37	
8	9902S38	
9	9902S39	
Colon “:”	9902S3A	
Semi-Colon “;”	9902S3B	
Less Than Sign “<”	9902S3C	
Equals Sign “=”	9902S3D	

Field Name	Menu Command	Programming Code
Greater Than Sign ">"	9902S3E	
Question Mark "?"	9902S3F	
At Sign "@"	9902S40	
A	9902S41	
B	9902S42	
C	9902S43	
D	9902S44	

---

Field Name	Menu Command	Programming Code
E	9902S45	
F	9902S46	
G	9902S47	
H	9902S48	
I	9902S49	
J	9902S4A	
K	9902S4B	

Field Name	Menu Command	Programming Code
L	9902S4C	
M	9902S4D	
N	9902S4E	
O	9902S4F	
P	9902S50.	
Q	9902S51	
R	9902S52	

Field Name	Menu Command	Programming Code
S	9902S53	
T	9902S54	
U	9902S55	
V	9902S56	
W	9902S57	
X	9902S58	
Y	9902S59	

Field Name	Menu Command	Programming Code
Z	9902S5A	
Opening Square Bracket “[“	9902S5B	
Reverse Slant “\”	9902S5C	
Closing Square Bracket “]”	9902S5D	
Caret “^”	9902S5E	
Underscore “_”	9902S5F	
Opening Single Quote “'”	9902S60	

---

Field Name	Menu Command	Programming Code
a	9902S61	
b	9902S62	
c	9902S63	
d	9902S64	
e	9902S65	
f	9902S66	
g	9902S67	

---

Field Name	Menu Command	Programming Code
h	9902S68	
i	9902S69	
j	9902S6A	
k	9902S6B	
l	9902S6C	
m	9902S6D	
n	9902S6E	



---

Field Name	Menu Command	Programming Code
o	9902S6F	
p	9902S70	
q	9902S71	
r	9902S72	
s	9902S73	
t	9902S74	
u	9902S75	

Field Name	Menu Command	Programming Code
v	9902S76	
w	9902S77	
x	9902S78	
y	9902S79	
z	9902S7A	
Opening Curly Bracket “{”	9902S7B	
Vertical Line “ ”	9902S7C	

---

Field Name	Menu Command	Programming Code
Closing Curly Bracket “}”	9902S7D	
Tilde “~”	9902S7E	
DEL	9902S7F	



# EasyParse for Motor Vehicle Documents Configuration Utility

EasyParse for Motor Vehicle Documents can also be configured using Honeywell's EasyParse for Motor Vehicle Documents Configuration Utility. This utility can generate bar codes to configure the plugin alone, delays alone and both plugin and delays in a single bar code.

To configure using the EasyParse for Motor Vehicle Documents Configuration Utility:

1. Start the EasyParse for Motor Vehicle Documents Configuration Utility. Select the required document from the list of available documents shown in the drop down box to populate available fields. By default, Header fields are shown.
2. Select the desired Data Field or Separator from the list boxes. Click on the *Insert* button (>>) or double click on the item to add it to the Data Output Format list box.
3. The Separator Fields list box can be extended to show all supported ASCII characters by checking the Show All Separators box.
4. Formatting options are available for different data fields within different documents. Select one of these fields and the options are displayed in the Data Format list box.
5. Select the desired Data Field followed by required Data Format option. Click on the *Insert* button (>>) or double click on the item to add it to the Data Output Format list box.
6. To select a Data Format, click on the desired option. To deselect, double click the option.
7. To move a selected field in the Data Output Format list box, click on the *Move Up* or *Move Down* buttons until the field has been moved to the desired location.
8. To remove a selected field in the Data Output Format list box, click on the *Remove* button (<<.)
9. To configure a delay after a separator, select the Separator from the Separator dropdown list. Enter the delay amount in milliseconds. (The delay must be in multiples of 5, starting from 5ms up to and including 5000ms.)
10. The Data Output Format list box and the Configure Delays section can be cleared by clicking on the *Clear All* button.

- 
11. To create a bar code from the Data Output Format list box and/or delays, click on the *Generate Barcode* button. A second window will appear with the bar code. To save the bar code, click on the *Save* button. The bar code will be saved as an html file. To print the bar code, click on the *Print* button.
  12. The selected configuration that includes the Data Output Format list box and delays can be saved into a file. Click on *Save to File* button and select the location to save then click on the *Save* button. The configuration will be saved as an xml file.
  13. To generate a bar code from a Saved to File configuration, select *Load from File* button. Select file, then click on the *Open* button. The saved configuration will populate in the Data Output Format list box and Configure Delays section. To generate a bar code, follow step number 11.
  14. To complete the configuration, scan the generated bar code.

# Inserting Delays between Fields

Delays can be introduced in the data transmission using Data Formatter. The Data Formatting string can be sent as a serial command, built in a menu code, or created in EZConfig-Scanning. Follow input format needed as outlined in the imager's User's Guide available at [www.honeywellaidc.com](http://www.honeywellaidc.com).

The EF command in the system data formatter will insert a delay between fields in the output.

To test the delay follow these steps:

1. Setup EasyParse for Motor Vehicle Documents to output data as TD\_Title Number [Horizontal Tab] TD\_Vehicle Make.
2. For a delay after TD\_Title Number, send the following data format string to the scanner:

```
DFMBK30124999999F30900EF1000F100.
```

The breakdown of the command line is shown below:

```
DFMBK3   inform the scanner the following string is data format
0        primary data format
124      terminal interface to apply data format. 124 = USB keyboard
         wedge
99       symbology ID (99 is a wildcard for all symbologies.)
9999     length of bar code to apply data format (9999 is a wildcard
         for all lengths.)
F30900   sends out all data up to but not including the 09 [horizontal
         tab] character, followed by 00 [null]
EF1000   inserts a delay of 5000ms (1000 x 5ms)
F100     sends the remainder data from the current virtual pointer
         position
.        informs scanner to save data to non-volatile flash.
```

3. The output will be TD\_Title Number, a delay of 5000ms, horizontal tab, then TD\_Vehicle Make.

*Note: The system data formatter is based on the position of the virtual pointer in the data buffer.*

*The EF delay command will only work with keyboard interfaces, i.e. USB keyboard or PS/2 keyboard. It will not work with any other interface.*





# ***EasyParse for Motor Vehicle Documents Version Identification***

Scan the bar code below to transmit what version of EasyParse for Motor Vehicle Documents software the imager is running.

Transmit EasyParse for Motor Vehicle Documents Version



*Note: If the characters @#\$EasyAAMVAVersion\$#@ are transmitted when the bar code is scanned, then the unit is not equipped with the EasyParse for Motor Vehicle Documents software plug-in.*



# ***End User License Agreement***

This License Agreement (“Agreement”) is a legal agreement between you and Honeywell International Inc. (“Licensor”) regarding the associated software (“Software”), which may include software owned by Honeywell and software licensed by Honeywell from its software suppliers (“Suppliers”).

The Agreement also applies to any updates, supplements, Internet-based services, and support services for this software, unless other terms accompany those items. If so, those terms apply.

By installing, activating, or using the Software, you agree to be bound by the terms and conditions of this Agreement. If you do not agree to be so bound, you may not install the Software or, if the Software is already installed, you must promptly remove it. The Software and any accompanying materials (including, without limitation, any images, photographs, animations, video, audio, music, text, and applets incorporated into the Software, the accompanying media, and printed materials) are owned by Licensor and its Suppliers and protected under U.S. and international copyright laws, and may be protected under additional intellectual property laws. The Software is licensed, not sold, and Licensor and its Suppliers retain all right, title, and interest therein other than those rights specifically granted to you under this Agreement. You accept responsibility for selection of the Software to achieve your intended results, and for installation, activation, use of, and results obtained from, the Software.

## ***License***

Licensor hereby grants you a non-exclusive License to use this Software, without right of sub-license, only in object or executable code form, and only in or with Licensor's products (“Products”). You may not rent, lease, or lend the Software. You may permanently transfer rights under this Agreement only as part of a permanent sale or transfer of the Products, and only if the recipient accepts this Agreement. If the Software is an upgrade, any transfer must also include all prior versions of the Software. You agree that the Software and any Software-related materials provided under this Agreement are and shall at all times remain the sole and exclusive property of Licensor and its Suppliers. Unauthorized copying of the Software is expressly forbidden. The Software may be patent-pending and/or patented; please refer to documentation accompanying the product, including labels and user guides, for specifics. You may be held legally responsible for any infringement of copyright or other intellectual property rights caused by your failure to abide by this Agreement.

If the Software is identified by Licensor as a demonstration version, Licensee may use the Software on multiple Products or platforms. If the Software is provided by Licensor as other than a demonstration version, Licensee may use the Software only on or with a single Product. User's guides and programming guides for the Software that are provided by Licensor in either hard or electronic copy may be copied and distributed.

The rights granted by this Agreement do not give you rights to implement Licensor patents or other Licensor intellectual property.

---

## ***Open Source***

If you use Open Source software in conjunction with the Software, you must ensure that your use does not: (i) create, or purport to create, obligations on Licensor or its Suppliers with respect to the Software; or (ii) grant, or purport to grant, to any third party any rights to Software that are not permitted by this Agreement; or (iii) grant, or purport to grant, to any third party any immunities with respect to Licensor's or its Suppliers' proprietary rights.

Any Open Source software listed under this Agreement is listed only for your convenience and solely for information purposes, and, if licensed, is licensed to you only under the terms set forth in the corresponding Open Source License, which you may find on the Internet at the designated URL, or in the header files of such software.

## ***Restrictions***

You shall not use, print, copy, or display the Software in whole or in part except as expressly permitted in writing. You shall not modify, translate, alter, create derivatives of, "reverse compile," decompile, merge with another program, or otherwise derive the source code for the Software, or defeat any "keys" or codes controlling authorized access or functionality, nor will you allow others to do the same.

## ***Note on Java Support***

The Software may contain support for programs written in Java. Java technology is not fault tolerant and is not designed, manufactured, or intended for use or resale as online control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of Java technology could lead to directly to death, personal injury, or severe physical or environmental damage.

## ***Indemnification***

Licensee agrees to defend, indemnify, and hold harmless Licensor from all damages and third-party claims, causes of action, or damages arising from unauthorized use or disclosure of Software, or resulting from use of Software in combination with software, hardware, systems, or other items not provided by Licensor.

---

DISCLAIMERS AND LIMITATIONS OF LIABILITY: THE SOFTWARE IS NOT FAULT TOLERANT, AND IS PROVIDED AS IS AND WITH ALL FAULTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AND EXCEPT AS OTHERWISE EXPRESSLY SET FORTH IN THIS AGREEMENT OR, WITH RESPECT TO THE OPEN SOURCE SOFTWARE LISTED FOLLOWING, EACH RESPECTIVE OPEN SOURCE LICENSE, LICENSOR, ITS SUPPLIERS AND LICENSORS, AND ANY OPEN SOURCE CONTRIBUTORS (1) DISCLAIM ANY AND ALL PROMISES AND REPRESENTATIONS WITH RESPECT TO THE SOFTWARE, INCLUDING ITS CONDITION, ITS CONFORMITY TO ANY REPRESENTATION OR DESCRIPTION, AND THE EXISTENCE OF ANY LATENT OR PATENT DEFECTS, (2) DISCLAIM ALL WARRANTIES, WRITTEN OR ORAL, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS; AND, (3) SHALL HAVE NO LIABILITY FOR ANY DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. IN NO EVENT SHALL LICENSOR OR ITS SUPPLIERS BE LIABLE FOR ANY AMOUNT IN EXCESS OF (1) THE INITIAL LICENSE FEE THAT LICENSOR RECEIVED FROM YOU FOR THE PRODUCTS, IN THE CASE OF LICENSOR, OR (2) U.S. TWO HUNDRED AND FIFTY DOLLARS (U.S. \$250.00), IN THE CASE OF LICENSOR'S SUPPLIERS.. ALL RISK AS TO QUALITY AND PERFORMANCE OF THE SOFTWARE IS WITH YOU.

### ***General***

This Agreement is the complete agreement and understanding of the parties with respect to the Software and supersedes all prior oral, written, or other representations and agreements. You acknowledge that the Software is of U.S. origin, and agree to comply with all applicable international and national laws that apply to the Software, including the U.S. Export Administration Regulations, as well as end-user, end-use, and country destination restrictions issued by the U.S. and other governments. If this product is acquired under the terms of a U.S. Government contract, use, duplication, and disclosure are subject to the terms of this license and the restrictions contained in the Rights in Technical Data and Computer Software clause at 252.227-7013 (DOD contracts); and subdivisions (a) through (d) of 52.227-19 as applicable. This Agreement shall be governed by the laws of the State of New York, without regard to its conflicts of law provisions.

---

## ***Distributors and Resellers***

In addition to the License rights granted in this License Agreement, Distributors and Resellers of Licensor's Products shall have the right to install and sublicense the Software to End Users solely for the purpose of using the Software on Licensor's products for the End User's own business. Distributors and Resellers of Licensor's Products shall have the right to advertise or otherwise market the Software for use on Licensor's products. User's guides and programming guides for the Software that are provided by Licensor in either hard or electronic copy may be copied and distributed. Distributors and Resellers of Licensor's Products shall provide this License Agreement with each sublicense to an End User of the Software. Distributors and Resellers of Licensor's Products shall promptly discontinue distribution of the Software to any End User which does not comply with the obligations in this License Agreement and shall notify Licensor and cooperate with Licensor in investigating instances of violation thereof.

## ***Copyright, Attribution, and Open Source***

Remote Mastermind™ software is copyright protected and the property of Honeywell Scanning and Mobility ("HSM").

The Software, including but not limited to Remote Mastermind, OPOS, and JPOS, may contain one or more of the following open source software components; references to specific versions are for convenience only, please refer to the URL and header file information for current versions:

1. The following open source software is subject to the Apache License, Version 2.0:

Commons-collections-3.2.jar  
Commons-fileupload-1.1.1.jar  
Commons-io-1.3.jar  
Commons-logging-1.1.jar  
log4j-1.2.9.jar  
quartz-all-1.6.1-RC1.jar

You may obtain a copy of the Apache License Version 2.0 at: <http://www.apache.org/licenses/LICENSE-2.0>.

You may obtain a copy of the software at: <http://commons.apache.org/>.

2. This following open source software was developed by the Apache Software Foundation (<http://www.apache.org>), and is subject to the Apache License, Version 1.1:

Xerces Java Parser 1.4.4 Release (Xerces-J-bin.1.4.4.zip)

You may obtain a copy of the Apache License Version 1.1 at: <http://www.apache.org/licenses/LICENSE>.

You may obtain a copy of the software at: <http://xerces.apache.org/xerces-j/>.

- 
3. The following open source software is subject to the “Academic Free License (AFL) Version 2.1 from the Open Source Initiative“, and the “BSD License from the Open Source Initiative“, 2005-2006:

Dojo.js and DojoFileStorageProvider.jar

You may obtain a copy of the Academic Free License

at: <http://www.opensource.org/licenses/academic.php>, and of the BSD License at: <http://www.opensource.org/licenses/bsd-license.php>.

You may obtain a copy of the software at: <http://Dojotoolkit.org>.

4. The following open source software is subject to the Common Public License - v 1.0:

jcl2.3.0-RC3.zip

You may obtain a copy of the Common Public License

at: <http://www.eclipse.org/legal/cpl-v10.html>

You may obtain a copy of the software

at: <http://sourceforge.net/projects/jposloader/>

Any provisions of the Honeywell End User License Agreement which differ from the Common Public License are offered by Honeywell alone and not by any other party.

Source code for the jcl2.3.0-RC3 software is available from [Honeywell](#).

5. The following open source software from Adobe labs is subject to the BSD License from the Open Source Initiative:

TTComboBox.h

TTComboBox.cpp

You may obtain a copy of the BSD License

at: <http://www.opensource.org/licenses/bsd-license.php>

You may obtain a copy of the software

at: [http://www.codeproject.com/KB/combobox/Neat\\_Tooltip\\_for\\_Combobox.aspx](http://www.codeproject.com/KB/combobox/Neat_Tooltip_for_Combobox.aspx)

6. The following open source software is subject to the BSD License from the Open Source Initiative (2006):

Spry\_1\_6\_1\_022408

You may obtain a copy of the BSD License

at: <http://www.opensource.org/licenses/bsd-license.php>.

You may obtain a copy of the software

at: <http://labs.adobe.com/technologies/spry/home.html>.

7. The following open source software is subject to the GNU Lesser General Public License (LGPL), Version 3 – 2007:

swing-layout-1.0.3.jar

You may obtain a copy of the LGPL

at: <http://www.gnu.org/copyleft/lesser.html>.

You may obtain a copy of the swing-layout-1.0.3.jar library

at: <https://swing-layout.dev.java.net/>.

- 
8. The following open source software is subject to the GNU LGPL v 2.1:  
rtxcomm.jar, rtxSerial.dll, rtxParallel.dll  
You may obtain a copy of the GNU LGPL v 2.1  
at: <http://www.gnu.org/licenses/old-licenses/lgpl-2.1.html>.  
You may obtain a copy of the software at: <http://rtx.org>.
9. The following open source software (Copyright (C) 1995-2005 Jean-loup Gailly and Mark Adler) is subject to the Zlib license:  
Zlib 1.2.3 (zlib1.dll)  
You may obtain a copy of the License  
at: [http://www.zlib.net/zlib\\_license.html](http://www.zlib.net/zlib_license.html).  
You may obtain a copy of the software at: <http://www.zlib.net/>.
10. The following open source software is subject to the GNU General Public License Version 2, June 1991:  
jsmooth-0.9.9-7-setup.exe  
You may obtain a copy of the License  
at: <http://jsmooth.sourceforge.net/license.php>.  
You may obtain a copy of the software  
at: <http://jsmooth.sourceforge.net/>.
11. Software that includes OPOS may include the open source components TTComboBox.h and TTComboBox.cppone, which are subject to the following license and terms:

© 2010 Honeywell International Inc.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- \* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- \* Redistributions in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
- \* Neither the name of Honeywell International Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.



---

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.





# *Customer Support*

## ***Technical Assistance***

If you need assistance installing or troubleshooting your device, please contact us by using one of the methods below:

**Knowledge Base:** [www.hsmknowledgebase.com](http://www.hsmknowledgebase.com)

Our Knowledge Base provides thousands of immediate solutions. If the Knowledge Base cannot help, our Technical Support Portal (see below) provides an easy way to report your problem or ask your question.

**Technical Support Portal:** [www.hsmsupportportal.com](http://www.hsmsupportportal.com)

The Technical Support Portal not only allows you to report your problem, but it also provides immediate solutions to your technical issues by searching our Knowledge Base. With the Portal, you can submit and track your questions online and send and receive attachments.

**Web form:** [www.hsmcontactsupport.com](http://www.hsmcontactsupport.com)

You can contact our technical support team directly by filling out our online support form. Enter your contact details and the description of the question/problem.

**Telephone:** [www.honeywellaidc.com/locations](http://www.honeywellaidc.com/locations)

For our latest contact information, please check our website at the link above.









**Honeywell Scanning & Mobility**

9680 Old Bailes Road

For Mill, SC 29707

[www.honeywellaidc.com](http://www.honeywellaidc.com)